

Support

Customer Service

SoftBank Customer Centers
From a SoftBank handset, dial toll free at
157 (General Information)
113 (Customer Assistance)

SoftBank Global Call Center
From outside Japan, dial
+81-3-5351-3491
(International charges apply.)
Call this number immediately if handset/USIM Card is lost or stolen while outside Japan.

■Call these numbers toll free from landlines.

Subscription Areas	Contact	
Hokkaido, Aomori, Akita, Iwate, Yamagata, Miyagi, Fukushima, Niigata, Tokyo, Kanagawa, Chiba, Saitama, Ibaraki, Tochigi, Gunma, Yamanashi, Nagano, Toyama, Ishikawa, Fukui	General Information	☎ 0088-240-157
	Customer Assistance	☎ 0088-240-113
Aichi, Gifu, Mie, Shizuoka	General Information	☎ 0088-241-157
	Customer Assistance	☎ 0088-241-113
Osaka, Hyogo, Kyoto, Nara, Shiga, Wakayama	General Information	☎ 0088-242-157
	Customer Assistance	☎ 0088-242-113
Hiroshima, Okayama, Yamaguchi, Tottori, Shimane, Tokushima, Kagawa, Ehime, Kochi, Fukuoka, Saga, Nagasaki, Oita, Kumamoto, Miyazaki, Kagoshima, Okinawa	General Information	☎ 0088-250-157
	Customer Assistance	☎ 0088-250-113

More Information

Handset User Support
Via Yahoo! Keitai Main Menu:
From above the search field,
select **メニュー** ➔ **English** ➔
User Support.

Online English Manual
See SOFTBANK MOBILE Corp.
Website (<http://www.softbank.jp>).
May be unavailable at purchase.
Call Customer Service or try later.


Emergency Numbers

- Police 110
- Fire & Ambulance 119
- Maritime Safety Agency.... 118

GH68-17539A (Rev. 1.0)

SoftBank 8215C

First Step Guide



Emergency Numbers

Customer Service

More Information

English Interface

International Call

Customizing Address

And More...

Safety Precautions

Do not short-circuit Charger Port.

Keep metal objects away from the Charger Port. Keep handset away from jewelry. Battery may leak, overheat, burst, or ignite causing injury. Use a case to carry handset.

Avoid battery leakage, breakage or fire injury.

- Do not:**
- Heat or dispose of battery in a fire.
 - Disassemble, modify, or break battery.
 - Damage or solder on to battery.
 - Use a damaged or deformed battery.
 - Use a non-specified charger.
 - Force battery into handset.
 - Charge or place battery near fire, heat sources or expose it to extreme heat.
 - Use battery for other equipments.

Do not insert foreign objects into handset.

Do not place metal or flammable objects in handset or Charger. This may cause fire or electric shock. Keep handset out of the reach of children.

Keep handset away from liquid-filled containers.

Keep handset and Charger away from chemicals/liquids. Fire or electric shock may result.

Avoid sources of fire.

To prevent fire or explosion, do not use handset near gas or fine particles (Coal, dust, metal, etc.).

Keep handset/Charger out of microwave ovens.

Battery or handset may leak, burst, overheat, or ignite.

Do not subject handset to shocks.

Subjecting handset or Charger to shocks may cause malfunction or injury. Should handset break, remove battery and contact the SoftBank Customer Center, Customer Assistance. Discontinue handset use. Fire or electric shock may occur.

Keep handset off and Charger disconnected near filling station or places with risk of fire/explosion.

Handset use near petrochemicals or other flammables may lead to fire or explosion.

Preventing accidents

- For safety, never use handset while driving. Pull over beforehand. Mobile phone use while driving is prohibited by the revised Road Traffic Law (Effective November 1 2004).

- Do not use headphones while driving or riding a bicycle. Accidents may result.
- Do not turn the volume up so high that ambient sounds cannot be heard, especially when walking in or around traffic to avoid accidents.

Do not swing handset by the strap.

Injury or breakage may result.

Use only the specified voltage.

Non-specified voltages may cause fire or electric shock.

- **AC Charger: AC 100V-240V Input**
- **In-Car Charger: DC 12V/24V Input**

Do not use In-Car Charger inside vehicles with a positive earth.

Fire may result. Use In-Car Charger only inside vehicles with a negative earth.

Do not plug multiple cords in one outlet.

Excess heat or fire may occur.

Do not bend, twist, pull, or set objects on the cord. Do not put heavy objects on the cords or heat or pull the cords.

Fire or electric shock may result.

Do not short-circuit Charger Port.


Keep the metal away from Port. Overheating, fire, or electric shock may result.

For more information, see User Guide P.xxx


Before Using Handset

Accessories


• Battery [SCBAL1]




• Utility Software¹ (CD-ROM)




• Stereo Earphones [SCLAD1]



• Earphone Conversion Cable with Microphone [SCLAJ2]



• USB Cable [SCDAJ1]



• SBM Charger Connector Adapter (SC-A) [SCDAJ2]²



¹ Utility Software updates/upgrades may become available via SOFTBANK MOBILE Corp. Website (<http://www.softbank.jp>) without prior notification.
² Required to connect specified AC Charger (purchased separately) and 8215C, to power handset or charge battery. Two Connector Adapters are included.

Manner Profile



Minding Mobile Manners

Please use handset responsibly. Inappropriate handset use can be both dangerous and bothersome to others. Please take care not to disturb others with handset use. Adjust handset use to your surroundings accordingly.

Activating/Canceling Manner Profile

- Press **[*][#]** for 1+ seconds





USIM Card Installation



USIM Card must be inserted to use 8215C. Turn 8215C off and remove battery before inserting/removing USIM Card. To prevent damaging it, avoid touching the IC chip when inserting or removing USIM Card.

Battery Installation

Do not touch battery contacts.




USIM PINs

- **PIN**
4- to 8-digit security code; prevents unauthorized use. Set **PIN certification** to **On** to require PIN entry at power on.
 - **PIN2**
4- to 8-digit security code required for Reset Call Cost or Edit Cost Limit, etc.
- Change PIN and PIN2 as required.

- **Canceling PIN Lock (PUK/PUK2 Code*)**
Incorrectly entering PIN or PIN2 three consecutive times activates PIN Lock and limits 8215C function access. Enter PUK (PIN Unlocking Key) Code to cancel PIN Lock. For more information, contact Customer Service.
- ★ Entering PUK/PUK2 incorrectly ten consecutive times locks USIM Card and disables 8215C. Write down PUK and PUK2. Unlocking USIM Card requires special service. Contact Customer Service.

Change Phone Password or Network Password on 8215C.

Charging



- Open Port Cover and insert Adapter Connector**
- Plug Charger into an AC 100V outlet**
 - While charging, battery indicator charges as follows: flashes when battery is full.
 - Charging time is approximately 150 minutes.
- Unplug Charger, then disconnect handset**

Security Codes

- **Phone Password**
4-digit number (9999 by default) required to use or change handset functions. Entered digits appear as *. If incorrect, error message appears; try again.
- **Center Access Code**
4-digit number specified at subscription; use to subscribe to fee-based information/access Voice Mail via landlines.

- **Network Password**
4-digit number specified at subscription; use for Call Barring, etc. Entering it incorrectly three consecutive times locks Call Barring settings. To resolve, Network Password and Center Access Code must be changed. For details, contact Customer Service.

Change Phone Password or Network Password on 8215C.

Specifications

SoftBank 8215C

Weight	Approximately 120 g
Continuous Talk Time	Voice Call: 200 minutes Video Call: 100 minutes
Continuous Standby Time (Turning off Display)	395 hours

Charging Time (power off)	AC Charger: Approximately 150 minutes
Dimensions (W x H x D)	Approximately 49 x 99.5 x 16.7 mm (8215C closed)
Maximum Output	0.25W

- Values calculated with battery installed.
- Actual times may be reduced by alternating between operations/transmissions and Standby.

