13

**Handset
Customization**

☓ Date & Time Settings

Date & Time	Start Here ● ➜ *Settings* ➜ ● ➜ In Sound/Display menu, *Date & Time* ➜ ●
Setting the date and time	*Set Date/Time* ➜ ● ➜ Enter the year ➜ Enter the month ➜ Enter the day ➜ Enter the time ➜ ●
Correcting Clock manually	*Time Correction* ➜ ● ➜ *Manual* ➜ ● ➜ *Yes* ➜ ●
Disabling auto Clock correction	*Time Correction* ➜ ● ➜ *Auto Corr. Setting* ➜ ● ➜ *Off* ➜ ●
Setting auto Clock correction timing	*Time Correction* ➜ ● ➜ *Auto Corr. Setting* ➜ ● ➜ *On* ➜ ☺ ➜ Select item ➜ ● (/) ➜ ⓨ ➜ 📖
Activating Daylight Saving	*Daylight Saving* ➜ ● ➜ *On* ➜ ●
Changing Time Zone	*Set Time Zone* ➜ ● ➜ ⊙ Select area ➜ ●
Adding custom time zone	*Set Time Zone* ➜ ● ➜ ☺ ➜ Enter city name ➜ ● ➜ (♢) + or - ➜ ⊙ ➜ Enter time difference ➜ ●
Changing time format to 12 hour	*Time Format* ➜ ● ➜ *12 Hour* ➜ ●
Changing date format	*Date Format* ➜ ● ➜ Select option ➜ ●
Starting the Calendar week on Monday	*Calendar Format* ➜ ● ➜ *Monday-Sunday* ➜ ●

✗ **Display & Illumination Settings 1**

Language

Start Here ◉ ➡ *Settings* ➡ ◉ ➡ Sound/Display menu

Switching interface between Japanese and English	*Language* or *言語選択* ➡ ◉ ➡ *English* or *日本語* ➡ ◉

Image & Text

Start Here ◉ ➡ *Settings* ➡ ◉ ➡ In Sound/Display menu, *Display* ➡ ◉

Showing preloaded images for incoming calls, etc.	*System Graphics* ➡ ◉ ➡ Select item ➡ ◉ ➡ *Preset Animation* (or *Pattern 1* to *Pattern 3*) ➡ ◉
Showing Data Folder images for incoming calls, etc.	*System Graphics* ➡ ◉ ➡ Select item ➡ ◉ ➡ Select folder ➡ ◉ ➡ Select image ➡ ◉ ➡ Specify image area ➡ ◉ ● Some images may be usable without specifying image area.
Showing Customized Screen for incoming calls, etc.	*System Graphics* ➡ ◉ ➡ Select item ➡ ◉ ➡ *Customized Screen* ➡ ◉ ➡ ◉ ● Not available for *Power On* or *Power Off*.
Changing font of numbers entered in Standby	*Dial Number* ➡ ◉ ➡ Select pattern ➡ ◉
Showing a message each time handset is powered on	*Greeting Message* ➡ ◉ ➡ *Edit Message* ➡ ◉ ➡ Enter message ➡ ◉ ➡ *Switch On/Off* ➡ ◉ ➡ *On* ➡ ◉

Display & Backlight

Start Here ◉ ➡ *Settings* ➡ ◉ ➡ In Sound/Display menu, *Display* ➡ ◉

Disabling display transition effects	*Display Effects* ➡ ◉ ➡ *Off* ➡ ◉
Changing Display/key Backlight illumination time	*Backlight* ➡ ◉ ➡ *Time Out* ➡ ◉ ➡ Select time ➡ ◉ ● For custom illumination time, select *Other*.
Changing Display Brightness	*Backlight* ➡ ◉ ➡ *Brightness* ➡ ◉ ➡ Adjust level ➡ ◉
Changing inactivity time after which Display turns off	*Display Saving* ➡ ◉ ➡ Select time ➡ ◉

✗ **Display & Illumination Settings 2**

Sub Display　　　　　Start Here ● ➔ *Settings* ➔ ● ➔ In Sound/Display menu, *Display* ➔ ● ➔ *Sub-Display* ➔ ●

Changing inactivity time after which Sub Display turns off	*Duration* ➔ ● ➔ Select time ➔ ●
Hiding new received messages	*Messages* ➔ ● ➔ *Not Display* ➔ ●
Changing Clock view	*Display Date&Time* ➔ ● ➔ Select type ➔ ●
Changing Clock font	*Clock Type* ➔ ● ➔ Select pattern ➔ ●
Hiding caller info	*Caller Display* ➔ ● ➔ *Off* ➔ ●

Standby Display　　　　　Start Here ● ➔ *Settings* ➔ ● ➔ In Sound/Display menu, *Display* ➔ ● ➔ *Standby Display* ➔ ●

Changing Clock/Calendar	*Clock/Calendar* ➔ ● ➔ Select type ➔ ●
Selecting Mobile Widget display option	*Show Widget* ➔ ● ➔ Select option ➔ ●
Showing Network service provider name in Standby	*Show Operator Name* ➔ ● ➔ *On* ➔ ●

Key Backlight　　　　　Start Here ● ➔ *Settings* ➔ ● ➔ ⊙ *Phone/🔲*

Disabling key Backlight illumination	*Set Key Light* ➔ ● ➔ *Off* ➔ ●

Key Illumination　　　　　Start Here ● ➔ *Settings* ➔ ● ➔ In Sound/Display menu, *Sounds & Alerts* ➔ ●

Changing Key Illumination pattern by action	*Set Key Illumi* ➔ ● ➔ Select action ➔ ● ➔ *Key Pattern* ➔ ● ➔ Select pattern ➔ ●
Disabling Key illumination by action	*Set Key Illumi* ➔ ● ➔ Select action ➔ ● ➔ *Switch On/Off* ➔ ● ➔ *Off* ➔ ●

♪ **Incoming Transmission Settings**

Handset Response	Start Here ● ➡ *Settings* ➡ ● ➡ In Sound/Display menu, *Sounds & Alerts* ➡ ●
Changing ringtone volume	*Volume* ➡ ● ➡ Select item ➡ ● ➡ Adjust level ➡ ●
Answering calls with other keys	*Any Key Answer* ➡ ● ➡ *On* ➡ ● ● Use ⓪⁰ - ⑨, ✳, #, ⁂, ✧, ⑳ or ⓐ in addition to 📞.
Muting ringer with other keys	*Any Key Answer* ➡ ● ➡ *Only Mute* ➡ ● ● Use ⓪⁰ - ⑨, ✳, #, ⁂, ✧, ⑳, ⓐ, ◀ or ▶ in addition to ☎.

Handset Response (Lights)	Start Here ● ➡ *Settings* ➡ ● ➡ In Sound/Display menu, *Sounds & Alerts* ➡ ●
Setting illumination color	*Event Light* ➡ ● ➡ Select item ➡ ● ➡ *Light Color* ➡ ● ➡ Select color ➡ ●
Selecting illumination option	*Event Light* ➡ ● ➡ Select item ➡ ● ➡ *Switch On/Off* ➡ ● ➡ *On*, *Link to Sound* or *Off* ➡ ●
Changing Key Illumination patterns	*Event Light* ➡ ● ➡ Select item ➡ ● ➡ *Key Pattern* ➡ ● ➡ Select pattern ➡ ● ● Regardless of Key Pattern setting, ringtones control illumination when Switch On/Off is set to *Link to Sound*.
Setting illumination color for missed transmissions	*Status Light* ➡ ● ➡ Select item ➡ ● ➡ *Light Color* ➡ ● ➡ Select color ➡ ●
Enabling/disabling illumination for missed transmissions	*Status Light* ➡ ● ➡ Select item ➡ ● ➡ *Switch On/Off* ➡ ● ➡ *On* or *Off* ➡ ●

♪ Sound Settings

System Sounds	Start Here ⊙ ➜ *Settings* ➜ ⊙ ➜ In Sound/Display menu, *Sounds & Alerts* ➜ ⊙
Enabling Keypad Tones	*System Sounds* ➜ ⊙ ➜ *Keypad Tones* ➜ ⊙ ➜ Select tone ➜ ⊙
Changing S! Circle Talk tone	*System Sounds* ➜ ⊙ ➜ *S! Circle Talk* ➜ ⊙ ➜ Select tone ➜ ⊙
Changing other System Sounds	*System Sounds* ➜ ⊙ ➜ Select item ➜ ⊙ ➜ *Tone* or *Sound* ➜ ⊙ ➜ Select folder ➜ ⊙ ➜ Select tone/file ➜ ⊙ ● For files with limited usage period, choose *Yes* and press ⊙.
Disabling System Sounds	*System Sounds* ➜ ⊙ ➜ Select item ➜ ⊙ ➜ *Tone* or *Sound* ➜ ⊙ ➜ *Off* ➜ ⊙ ● Not available for *S! Circle Talk*. ● For *Keypad Tones*, omit *Tone* or *Sound* selection step.
Changing System Sound duration	*System Sounds* ➜ ⊙ ➜ Select item ➜ ⊙ ➜ *Duration* ➜ ⊙ ➜ Select/enter time ➜ ⊙ ● Not available for *Keypad Tones* or *S! Circle Talk*.
Changing System Sound volume	*Volume* ➜ ⊙ ➜ *General Volume* ➜ ⊙ ➜ Adjust level ➜ ⊙

Additional Sound Settings	Start Here ⊙ ➜ *Settings* ➜ ⊙ ➜ Sound/Display menu
Disabling Speaker when using Headphones	*Ringer Output* ➜ ⊙ ➜ *Earphone* ➜ ⊙
Activating Speaker surround	*Sounds & Alerts* ➜ ⊙ ➜ *Surround* ➜ ⊙ ➜ *On* ➜ ⊙

✗ Connectivity Settings 1

Network	Start Here ● ➜ *Settings* ➜ ● ➜ ⊙ *Network*

Selecting a Network manually	*Select Network* ➜ ● ➜ *Manual* ➜ ● ➜ Select Network ➜ ●
Adding preferred Networks	*Select Network* ➜ ● ➜ *Set Preferred* ➜ ● ➜ Select target location ➜ ● ➜ *Insert* ➜ ● ➜ Select Network ➜ ●
Adding preferred Networks to the end	*Select Network* ➜ ● ➜ *Set Preferred* ➜ ● ➜ ● ➜ *Add to End* ➜ ● ➜ Select Network ➜ ●
Deleting preferred Networks	*Select Network* ➜ ● ➜ *Set Preferred* ➜ ● ➜ Select Network ➜ ● ➜ *Delete* ➜ ●
Adding Networks	*Select Network* ➜ ● ➜ *Add New Network* ➜ ● ➜ *Add* ➜ ● ➜ Enter country code ➜ ● ➜ Enter Network code ➜ ● ➜ Enter name ➜ ● ➜ *Select NW Type* ➜ ● ➜ Select type ➜ ● ● After selecting *Add New Network* and pressing ●, Network list appears if Network has already been added. To add more, press ● again and proceed.
Editing Networks	*Select Network* ➜ ● ➜ *Add New Network* ➜ ● ➜ Select Network ➜ ● ➜ *Change* ➜ ● ➜ Edit in the same manner as adding Networks ➜ ●
Deleting Networks	*Select Network* ➜ ● ➜ *Add New Network* ➜ ● ➜ Select Network ➜ ● ➜ *Delete* ➜ ●
Switching Network service between 3G and GSM manually	*Select Service* ➜ ● ➜ *Manual* ➜ ● ➜ Select service ➜ ●
Refreshing Network connection	*Re-search Signal* ➜ ●
Retrieving Network Information	*Retrieve NW Info* ➜ ● ➜ *Yes* ➜ ● ➜ ●
Checking Network status	*Network Info* ➜ ●
Editing connection names for mobile data communication	*External Device* ➜ ● ➜ Select name ➜ ● ➜ *Edit* ➜ ●
Clearing connection names for mobile data communication	*External Device* ➜ ● ➜ ✉ ➜ *Reset* ➜ ● ➜ Enter Handset Code ➜ ● ➜ *Yes* ➜ ●

⚒ Connectivity Settings 2

IP Service	Start Here ⦿ ➡ *Settings* ➡ ⦿ ➡ ⊙ *Phone/🖻* ➡ *Locks* ➡ ⦿
Enabling IP Service	*IP Service Setting* ➡ ⦿ ➡ *On* ➡ ⦿ ➡ Enter Handset Code ➡ ⦿ ● Enable IP Service to use S! Friend's Status and S! Circle Talk.

Location Information	Start Here ⦿ ➡ *Settings* ➡ ⦿ ➡ ⊙ *Network* ➡ *Location Info* ➡ ⦿
Adding/editing Location Information destination URLs	*URL Setting* ➡ ⦿ ➡ *\<Empty\>* (or select URL) ➡ ☺ ➡ *Edit* ➡ ⦿ ➡ Enter URL ➡ ⦿ ● Default URL is not editable.
Specifying Location Information destination URL	*URL Setting* ➡ ⦿ ➡ Select URL ➡ ⦿
Viewing Location Information destination URL	*URL Setting* ➡ ⦿ ➡ Select URL ➡ ☺ ➡ *Display* ➡ ⦿
Deleting Location Information destination URLs	*URL Setting* ➡ ⦿ ➡ Select URL ➡ ☺ ➡ *Delete* ➡ ⦿ ➡ *Yes* ➡ ⦿
Hiding Location Information	*Datum On/Off* ➡ ⦿ ➡ *Off* ➡ ⦿ ➡ Enter Handset Code ➡ ⦿
Changing Location Information confirmation option	*Location Property* ➡ ⦿ ➡ Select option ➡ ⦿

✗ Reset Settings

Restoring Default Settings	Start Here ⬤ ➜ *Settings* ➜ ⬤ ➜ ⊙ *Phone/🔁* ➜ *Master Reset* ➜ ⬤
Restoring default handset settings	*Reset Settings* ➜ ⬤ ➜ Enter Administrator Code ➜ ⬤ ➜ *Yes* ➜ ⬤ ➜ *Yes* ➜ ⬤ ● Some default settings may not be restored.
Clearing all Phone Book entries, Data Folder files, etc.	*Reset All* ➜ ⬤ ➜ Enter Administrator Code ➜ ⬤ ➜ *Yes* ➜ ⬤ ➜ *Yes* ➜ ⬤ ● Delete IC Card data beforehand. (Procedures to delete IC Card data vary by Lifestyle-Appli; contact Osaifu-Keitai® service providers for details.) ● Files and records deleted by Reset All cannot be restored. Reset All deletes all downloaded S! Applications and Lifestyle-Applications. ● Handset Code and Administrator Code return to the default settings.

● A confirmation may appear before entering Administrator Code; end the current function to proceed.
● When Double Number is active, regardless of usage mode setting, Reset Settings restores all default settings (Double Number is canceled), and Reset All clears all user files.