

Entertainment



S! Quick News	10-2
Using S! Quick News (Japanese).....	10-2
S! Info Channel	10-3
Using S! Info Channel (Japanese).....	10-3
S! Contents Store	10-5
Downloading Contents (Japanese)	10-5
Advanced Features	10-6
S! Quick News.....	10-6
S! Info Channel.....	10-6
Weather Indicators.....	10-6

10



Using S! Quick News (Japanese)

Registered news can be updated automatically and checked from Standby.

- Packet transmission fees are incurred for using S! Quick News.

Registering News

<Example> Register news on S! Quick News List

- 1 Press and hold



S! Quick News List

- 2 Add News \Rightarrow \Rightarrow YES \Rightarrow
- 3 Select an item \Rightarrow
Follow onscreen instructions.

Checking Updated Information

- 1 [S! Quick News List] \Rightarrow Select an item \Rightarrow
- 2 Select information \Rightarrow
To check next updated information, press .

More Features

Advanced

S! Quick News

- Manually Update List
- View Descriptions of Registered News
- Delete Registered News/Items

P. 10-6

Customize

S! Quick News

- Set Automatic Updates for S! Quick News
- Hide S! Quick News in Standby
- Set Ticker Speed
- Set Information to Appear in S! Quick News
- Hide S! Quick News Images
- Reset S! Quick News Registered Contents

P. 14-25



Using S! Info Channel (Japanese)


This information service automatically receives the latest news, weather and other information.

- Packet transmission fees are incurred for using S! Info Channel/Weather Indicators.

Subscribing for Service

Subscribe by registering to receive service.

- 1 ● ⇒ **Entertainment** ⇒ ● ⇒ **S! Info Ch./Weather** ⇒ ●



S! Info Channel Menu

- 2 **Register/Cancel** ⇒ ● ⇒ **YES** ⇒ ●
●
Follow onscreen instructions.

Checking Latest Information

A Desktop Icon notifies you when new information is received.

- 1 ● ⇒ **Desktop Icons** ⇒ ●



Web Page

Follow onscreen instructions.

Tip

- To check from a menu:
[S! Info Channel Menu] ⇒ *What's New* ⇒ ●
- To check previous information:
[S! Info Channel Menu] ⇒ *History* ⇒ ● ⇒
Select a date ⇒ ● ⇒ Unread or read
backnumbers are indicated with or .

Weather Indicators

After subscribing, weather indicators showing current weather appear in Standby.

Weather Indicators

	Clear (Daytime)		Later
	Clear (Night)		Partial
	Cloudy		Pollen (Low)
	Rain		Pollen (High)
	Snow		UV Rays (Low)
	Thunder		UV Rays (High)

<Example> Cloudy, partial rain

- For a complete list of indicators, see Appendix (P. 15-19).

Checking Weather Report

- 1 [S! Info Channel Menu] ⇒ **Weather Indicator** ⇒ ● ⇒ **Weather** ⇒ ●



More Features

Advanced

S! Info Channel

- Receive Previous Unreceivable Information
- Store Images/Melodies from Web Pages
- Add Phone Numbers/Mail Addresses from Web Pages

 **P. 10-6**

Weather Indicators


- Manually Update Weather Information

 **P. 10-6**

Customize


S! Info Channel

- Set Whether to Display Desktop Icon For New Received Information
- Set Font Size for Web Pages

 **P. 14-25**

Weather Indicators

- Set Whether to Automatically Update Weather Information
- Set Whether to Display Weather Indicators in Standby
- Set Whether to Display Desktop Icon For New Received Information


 **P. 14-26**



Downloading Contents (Japanese)

Download contents via Yahoo! Keitai.

1 ● ➔ **Entertainment** ➔ ●



2 **S! Contents Store** ➔ ●
Follow onscreen instructions.



S! Quick News

Start Here

[S! Quick News List] P. 10-2

Manually Update List

[S! Quick News List] → Select an item →
⊕ → *Refresh this* or *Refresh all* → ● →
YES → ●

View Descriptions of Registered News

[S! Quick News List] → Select an item →
⊕ → *Outline* → ●

Delete Registered News/Items

[S! Quick News List] → Select an item →
⊕
● To Delete the Selected Item
→ *Delete this* → ● → YES → ●
● To Delete All
→ *Delete all* → ● → YES → ● (twice) →
Enter Security Code → ● (twice)

S! Info Channel

Start Here

[S! Info Channel Menu] P. 10-3

[Web Page] P. 10-3

Receive Previous Unreceivable Information

[S! Info Channel Menu] → *Get Latest Contents* → ● → YES → ●

Store Images/Melodies from Web Pages

[Web Page] → ⊕ → *Save File* → ● (→
Select a file → ●) → *Save* → ● → YES
→ ● (→ Select a folder → ●) (→ YES or
NO → ●)

☞ Select *Play* and press ● to play melody file.
☞ Select *Property* and press ● to check file
information.

Add Phone Numbers/Mail Addresses from Web Pages

[Web Page] → ⊕ → *Add to Phone Book* →
● → YES → ●

- To Save to Handset
→ *Phone* → ● → Select store method →
● (→ Search Phone Book → Select Phone
Book → ● (twice)) → Edit items → ⊕ (→
YES or NO → ●) (→ Enter entry number →
●)
- To Save to USIM Card
→ *USIM* → ● → Select store method →
● (→ Search Phone Book → Select Phone
Book → ● (twice)) → Edit items → ⊕ (→
YES → ●)

Weather Indicators

Start Here

[S! Info Channel Menu]..... P. 10-3

Manually Update Weather Information

[S! Info Channel Menu] → *Weather Indicator* → ● → *Manual Update* → ● →
YES → ●