

Handset Security	10-2
Operations Security	10-2
Information Security.....	10-3

Function Control	10-4
Using Function Control.....	10-4
Additional Functions	10-5

10

Handset Security




Operations Security

Function Lock

Restrict access to handset functions.

Auto	Lock when Display turns off or handset is closed
Once	Lock immediately; setting is canceled once handset is unlocked
At Power On	Lock when handset is turned on; Handset Code entry window opens

- 1 → **Settings** → → **Locks** →



Locks Menu

- 2 **Function Lock** →
- 3 **Select option** → → **Enter Handset Code** →

Unlocking Temporarily

While handset is locked, enter Handset Code →

Available Operations while Function Lock is Active

- Power handset on/off, answer calls, place callers on hold, end calls, etc.

PIN Entry

Activate PIN Entry to require PIN entry each time handset is powered on.

- 1 **In Locks menu, PIN Entry** → → **Switch On/Off** →
- 2 **On** → → **Enter PIN** →

Secure Remote Lock

Lock a lost handset remotely via PC or another handset. Secure Remote Lock disables all operations except powering handset on.

For more about Secure Remote Lock, see SoftBank Mobile Website (P.14-21) or contact SoftBank Mobile Customer Center, General Information (P.14-36).



Advanced

- Changing PIN ● Setting Secure Remote Lock activation message (P.10-5)

Information Security

Application Lock

Restrict access to these functions:

Phone Book


Mail

Calendar/Tasks

Notepad

Yahoo! Keitai

- 1 → **Settings** → → → **Phone/** → **Locks** →



Locks Menu

- 2 **Application Lock** →

- 3 **Select item** → (✓)

For Phone Book, select **No Refer** (to hide entry names in message lists, Call Log, etc.) or **Refer** and press .

- 4 → **Enter Handset Code**
→

Temporary Access to Functions

- When accessing functions, enter Handset Code and press .

History Lock

Restrict access to Call Log and sent/received mail records.

- 1 **In Locks menu, History Lock** →

- 2 **Select item** → (✓)

- 3 → **Enter Handset Code**
→

Temporary Access to Records

- When accessing records, enter Handset Code and press .

Show Secret Data

Activate Show Secret Data to access Secret entries.

- 1 **In Locks menu, Show Secret Data** →

- 2 **On** → → **Enter Handset Code** →

When Show Secret Data is Active

- Predictive is not available for text entry.



Using Function Control

Restrict access to the following functions remotely. (Available for administrators.)

Camera	S! Mail
Infrared	Attach File
Memory Card	Yahoo! Keitai
USB	PC Site Browser
Messaging	S! Appli
Voice Call (placing)	Streaming
Video Call (placing)	Flash®
USIM (writing)	

■ When Accessing Restricted Functions


A message (example shown below) appears; the function is inaccessible.



Message may not appear for some functions.

Checking Restriction Status

- 1 → **Settings** → → → **Phone/** → **Locks** →
- 2 **Function Control** →



- Restriction status appears for each function.

- A message appears while Function Control is in progress.
- May be unavailable depending on subscription. For details, contact the nearest SoftBank Shop or SoftBank Mobile Customer Center, General Information (P.14-36).



PIN Entry

Changing PIN

- → Settings → ● → Phone/☎ → Locks
- ● → PIN Entry → ● → Change PIN → ●
- Enter current PIN → ● → Enter new PIN
- ● → Re-enter new PIN → ●
- Activate PIN Entry first.

Secure Remote Lock

Setting Secure Remote Lock activation message

- Start Here ● → Settings → ● → Phone/☎
- Locks → ● → Set Lock Message → ● →
- See below
- Saving Message**
- Message → ● → Enter Handset Code → ● →
- Enter message → ● → Yes → ●
- Checking Message**
- Check Message → ●
- Suppressing Message**
- Display Setting → ● → Don't Show → ● →
- Enter Handset Code → ●

