

Handset Security..... 10-2
Operations Security 10-2
Information Security..... 10-3

Function Control..... 10-4
Using Function Control..... 10-4
Additional Functions..... 10-5

10

Handset Security




Operations Security

Function Lock

Restrict access to handset functions.

Auto	Lock when Display turns off or handset is closed
Once	Lock immediately; setting is canceled once handset is unlocked
At Power On	Lock when handset is powered on; Handset Code entry window opens

- 1 → **Settings** → → → **Phone/** → **Locks** →



Locks Menu

- 2 **Function Lock** →
- 3 **Select option** → → **Enter Handset Code** →

Unlocking Temporarily

While handset is locked, enter
Handset Code →

Available Operations while Function Lock is Active

- Power handset on/off, answer calls, place callers on hold, end calls, etc.

PIN Entry

Activate PIN Entry to require PIN entry each time handset is powered on.

- 1 **In Locks menu, PIN Entry** → → **Switch On/Off** →
- 2 **On** → → **Enter PIN** →

Secure Remote Lock

Lock a lost handset remotely via PC or another handset. Secure Remote Lock disables all operations except powering handset on, and activates IC Card Lock. For more about Secure Remote Lock, see SoftBank Mobile Website (P.14-23) or contact SoftBank Mobile Customer Center, General Information (P.14-40).



Advanced

- Changing PIN
- Setting Secure Remote Lock message (P.10-5)

Information Security

Application Lock

Restrict access to these functions:

Phone Book


Mail

Calendar/Tasks

Notepad

Yahoo! Keitai

- 1 → **Settings** → → → **Phone/** → **Locks** →



Locks Menu

- 2 **Application Lock** →

- 3 **Select item** → (✓)

For Phone Book, select **No Refer** (to hide entry names in message lists, Call Log, etc.) or **Refer** and press .

- 4 → **Enter Handset Code**
→

Temporary Access to Functions

- When accessing functions, enter Handset Code and press .

History Lock

Restrict access to Call Log and sent/received mail records.

- 1 In Locks menu, **History Lock** →

- 2 **Select item** → (✓)

- 3 → **Enter Handset Code**
→

Temporary Access to Records

- When accessing records, enter Handset Code and press .

Show Secret Data

Activate Show Secret Data to access Secret entries.

- 1 In Locks menu, **Show Secret** →

- 2 **On** → → **Enter Handset Code** →



Using Function Control

Restrict access to the following functions remotely. (Available for administrators.)

Camera	Attach File
Infrared	Yahoo! Keitai
Bluetooth	PC Site Browser
Memory Card	IP Service
USB	S! Appli
Messaging	Osaifu-Keitai
Voice Call (placing)	PC Mail
Video Call (placing)	Streaming
USIM (writing)	Flash®
S! Mail	Mobile Widget

- A message appears while Function Control is in progress.
- May be unavailable depending on subscription. For details, contact the nearest SoftBank Shop or SoftBank Mobile Customer Center, General Information (P.14-40).

■ When Accessing Restricted Functions


A message (example shown below) appears; the function is inaccessible.



Message may not appear for some functions.

Checking Restriction Status

- 1 → **Settings** → → → **Phone/Keitai** → **Locks** →
- 2 **Function Control** →



- Restriction status appears for each function.



PIN Entry

Changing PIN	<ul style="list-style-type: none"> ● → Settings → ● → Phone/📞 → Locks → ● → PIN Entry → ● → Change PIN → ● → Enter current PIN → ● → Enter new PIN → ● → Re-enter new PIN → ●
	<ul style="list-style-type: none"> ● Activate PIN Entry first.

Secure Remote Lock

Setting Secure Remote Lock message	<ul style="list-style-type: none"> Start Here ● → Settings → ● → Phone/📞 → Locks → ● → Lock Message → ● → See below
	<p>Saving Message</p> <ul style="list-style-type: none"> Message → ● → Enter Handset Code → ● → Enter message → ● → Yes → ●
	<p>Checking Message</p> <ul style="list-style-type: none"> Check Message → ●
	<p>Suppressing Message</p> <ul style="list-style-type: none"> Display Setting → ● → Don't Show → ● → Enter Handset Code → ●

