

S! Appli

Before Using S! Appli	16-2
Downloading S! Appli.....	16-2
Using S! Appli	16-3
Activating S! Appli.....	16-3
Terminate/Suspend & Resume.....	16-3
Using S! Appli Startup History.....	16-3
Managing Applications.....	16-4

Before Using S! Appli

S! Appli are Java™-based applications designed to run on SoftBank handsets. Download games and other real-time applications for use on handset.

- Separate subscription required to use downloaded applications (not required for pre-installed S! Appli).
- For usage on pre-installed applications, see Help menu for each S! Appli.

Note

- For more information, visit SOFTBANK MOBILE Corp. Website (<http://www.softbank.jp>).

Network S! Appli

Network S! Appli requires Network connection.

- Transmission fees apply.

License Information

> **Main Menu** ► **S! Appli** ► **Information**

Downloading S! Appli

Download up to 100 S! Appli files to handset/microSD Card.

- End suspended S! Appli if any. However, S! Appli may not be ended during calls.

Main Menu ► **S! Appli** ► **S! Appli List**

1 **Download S! Appli** → **YES**

Handset connects to the Network, and download site appears.

2 Select an S! Appli

Properties appear.

3 Follow onscreen instructions

4 Select a save location

Downloaded S! Appli is saved to Data Folder automatically.

- Download may take some time.

5 **YES** to activate

Downloaded S! Appli starts.

- To exit: **NO**

■ **Download Lifestyle-Appli**

> **Main Menu** ► **Tools** or **S! Appli** ► **Osaifu-Keitai**

► **Lifestyle-Appli** ► **Download** ► **YES** ► Select a Lifestyle-Appli

- Lifestyle-Appli:  P.13-10

Note


- Alternatively, download S! Appli from **Main Menu** ► **Data Folder** ► **S! Appli** ► **Download S! Appli** ► **YES**
- Alternatively, download Lifestyle-Appli from **Main Menu** ► **Data Folder** ► **Lifestyle-Appli** ► **Download** ► **YES**


Using S! Appli

Activating S! Appli


Main Menu ► S! Appli ► S! Appli List

1 Select an S! Appli


Application starts and  appears.

- See application Help menu for usage information.
- Confirmation appears when selecting Network S! Appli.
- For a microSD Card S! Appli, press  [microSD] before Step 1.

Note



- Alternatively, **Main Menu ► Data Folder ► S! Appli**
► Select an S! Appli
- Closing handset/incoming transmissions pause S! Appli.
- AV output compatible applications may be viewed on a TV set ( P.11-18).

Tip

- Settings** ● Volume ● Backlight On/Off ● Vibration ● Update S! Appli
Information on microSD Card from Another Handset ( P.18-25)

Terminate/Suspend & Resume

Terminating/Pausing S! Appli

- 1 While running an S! Appli, 
- 2 **Suspended** or **Stopped**
 appears for a suspended application.

Resuming/Terminating Paused S! Appli

Main Menu ► S! Appli ► S! Appli List

- 1 **Replayed** or **Stopped**
Resumed application starts from paused point.

Using S! Appli Startup History

Main Menu ► S! Appli ► S! Appli History

- 1 Highlight a record →  [Menu] →
Start, S! Appli info or **Delete**

Managing Applications

Moving S! Appli between Handset and microSD Card

Main Menu ► S! Appli ► S! Appli List

- 1 Highlight an S! Appli →  [Menu] → **Move to microSD** or **Move to phone**
 - Some S! Appli may not be moved to microSD Card.

Deleting S! Appli

Main Menu ► S! Appli ► S! Appli List

- 1 Highlight an S! Appli →  [Menu] → **Delete** → **YES**
 - Some pre-installed S! Appli may not be deleted.

Viewing S! Appli Properties


Main Menu ► S! Appli ► S! Appli List

- 1 Highlight an S! Appli →  [Menu] → **S! Appli info**

Setting Security Level while Running S! Appli

- Security Level cannot be set for some applications.

Main Menu ► S! Appli ► S! Appli List

- 1 Highlight an S! Appli →  [Menu] → **Security level**
- 2 Select an item (See below)

Item	Operation/Description
Network Access	Connect to the Network
Auto Invocation	Activate S! Appli
Multimedia Recording	Activate Camera
Data Reading Access	Read data in Data Folder
Data Rewrtng Accss	Write/delete data in Data Folder
Location Access	Retrieve Location information

- 3 **Always Allowed, Ask First Time***, **Ask Every Time** or **Not Allowed**

* Confirmation appears the first time application is activated.

Reset Security Level Settings

Reset security level settings to default or condition when downloading.

> In Step 2, **Reset Sec. Setting** → **YES**