

Internet Services	5-2
Service Basics	5-2
Yahoo! Keitai	5-3
Using Yahoo! Keitai.....	5-3
PC Site Browser	5-5
Browsing PC Sites.....	5-5
Browsing.....	5-6
Basic Operations	5-6

Bookmarks & Saved Pages	5-8
Using Bookmarks & Saved Pages....	5-8
RSS Feeds	5-9
Updating Blogs & News.....	5-9
Additional Functions	5-10
Troubleshooting.....	5-17

5

Internet



Service Basics

Access the Mobile Internet via Yahoo! Keitai, or view PC Internet sites via PC Site Browser.

- Service requires a separate contract; retrieve Network Information to use these services.
- For more about Yahoo! Keitai, see SoftBank Mobile Website (P.14-23).


Transmission/Information Fees

Some page content may automatically activate Internet connection incurring transmission fees. Information fees may also apply.






Security

Electronic certificates are saved on handset to support SSL (encryption protocol for Internet transmissions of important/sensitive information).

Opening Secure Pages

- A confirmation appears. Choose **Yes** and press  to proceed.
- When a security notice appears, subscribers must decide for themselves whether or not to open the page. Opening secure pages constitutes agreement to the terms of usage. SoftBank, VeriSign Japan, Cybertrust, Entrust Japan, GMO GlobalSign, RSA Security, SECOM Trust Systems and Comodo Japan cannot be held liable for any damages associated with the use of SSL.

Advanced

-   Clearing cache (temporarily saved information)  Clearing authentication information (And more on P.5-10)
-  Disabling manufacture number auto send for authentication  Resetting browser settings and stored information (Bookmarks, Saved Pages, etc.) (And more on P.5-16)



Using Yahoo! Keitai


Using Yahoo! Keitai Main Menu

Browse Yahoo! Keitai sites from Yahoo! Keitai Main Menu.


Internet pages may not open depending on connection/Server status, etc.

1 ➔ Connection starts



- Yahoo! Keitai Main Menu appears.
- To disconnect, press .

2 ➔ Highlight menu item

- Corresponding page opens.
- Repeat  to open additional links.

3 ➔ Yes ➔ ➔ Page closes

Returning to Previous Pages

[Internet Page]  ➔ Previous page opens

- Follow these steps to return to the initial page:



[Internet Page]  ➔ Forward ➔ 

Returning to Yahoo! Keitai Main Menu

[Internet Page]  ➔ Yahoo! Keitai

➔ 

User Authentication

Enter user ID or password ➔  ➔ 

Accessing *メニューリスト* Directly

 ➔ Yahoo! ➔  ➔ Menu List ➔ 

Using History



1  ➔ Yahoo! ➔  ➔ History ➔ 

2 Select record ➔  ➔ Connection starts

- Corresponding page opens.

3  ➔ Yes ➔  ➔ Page closes

Entering URLs Directly








1  ➔ Yahoo! ➔  ➔ Enter URL ➔ 

2 Enter URL ➔  ➔ Connection starts

- Corresponding page opens.

3  ➔ Yes ➔  ➔ Page closes

Advanced

-   Switching browsers  Using previously entered URLs  Deleting History records  Opening History properties  Sorting History records  Sending History records via mail (P.5-10)



Playing Media during Download

Play files while they transfer from the server (progressive download) or stream media files.


- Save progressive download files, as needed, after playback. (Copy protected files cannot be saved.)
- Streaming media files cannot be saved even after playback.
- Packet transmission fees apply even while playback is paused.

1 On a page, select file ➔

- Playback starts.


Pausing Playback



- To resume playback, press .
- Progressive download continues even while playback is paused.

Stopping Playback




- Progressive download continues on the page even while playback is stopped. (Press  to resume playback.)

Stopping Progressive Download

During playback,  ➔ Previous page returns ➔ 

Playback Sound

- Sound is heard from Speaker/Headphones regardless of  Sound Output setting.



Advanced

-   Customizing media playback settings  Streaming from Media Player (P.5-13)

Browsing PC Sites

View PC Internet sites via PC Site Browser.

- Internet pages may not open depending on connection/Server status, etc.
- Browsing PC sites may incur high charges depending on subscribed price plan.

1 \Rightarrow **Yahoo!** \Rightarrow \Rightarrow **PC Site Browser** \Rightarrow

2 **Homepage** \Rightarrow \Rightarrow **Connection starts**



Internet Page

- Yahoo! JAPAN Home opens.
- If a message appears, follow onscreen prompts.
- To disconnect, press .

3 **Highlight menu item** \Rightarrow

- Corresponding page opens.
- Repeat to open additional links.

4 \Rightarrow **Yes** \Rightarrow \Rightarrow **Page closes**

Returning to Previous Pages

[Internet Page] \Rightarrow Previous page opens

- Follow these steps to return to the initial page:

[Internet Page] \Rightarrow **Forward** \Rightarrow

Returning to Yahoo! JAPAN Home

[Internet Page] \Rightarrow **Homepage** \Rightarrow

User Authentication

Enter user ID or password \Rightarrow \Rightarrow

Using History

In , **History** \Rightarrow \Rightarrow Select record \Rightarrow

Entering URLs Directly

In , **Enter URL** \Rightarrow \Rightarrow Enter URL \Rightarrow

Hiding Softkeys

[Internet Page] \Rightarrow **Convenient Func.** \Rightarrow \Rightarrow **Softkey Area** \Rightarrow \Rightarrow **Off** \Rightarrow

- To show Softkeys temporarily, press .

Browsing in Wideview

[Internet Page]

- Use Multi Selector according to page orientation.

Advanced

- Switching browsers
- Using previously entered URLs
- Deleting History records
- Opening History properties
- Sorting History records
- Sending History records via mail (P.5-10)
- Hiding navigation map for continuous scroll
- Changing scroll unit
- Hiding PC Site Browser messages (P.5-12)
- Selecting script execution option
- Enabling/disabling Ajax (for asynchronous communication) (P.5-16)




Selecting Text

Activate pointer navigation to enable text selection (Drag Mode). Select text to copy or look up words in dictionaries. Follow these steps to use a dictionary:
(Text may not be selectable or linked page may open depending on the site or page.)

1 On a page, point to first character ➡ ● (Long)

- Drag Mode is activated.

2 Highlight text range



3 ●

4 辞書 ➡ Select dictionary



- Dictionary opens with text inserted.

5 Search ➡ ● ➡ Select word, etc. ➡ ●

Starting Over

- After ③, point to first character ➡ ●
➡ From ②

Additional Page Operations

Enter text or select/execute items.



Text Entry

1 On a page, select text entry field ➡ ●

2 Enter text ➡ ●

- Internet page returns.

Using Entered Text (Input Memory)

- [Internet page] Select text entry field
➡ ● ➡ <=> ➡ Insert/Font Size ➡ ●
➡ Input Memory ➡ ● ➡ Select text
➡ ●

Pull-down Menu Item Selection

1 On a page, select menu list field ➡ ●

2 Select item ➡ ●

When Multiple Selection is Supported

- Select items as needed and press 戻る.

Page Item Indicators

Selection Items

Buttons ● or boxes □ appear.

1 On a page, select button or box ➡ ●



- ●/□ changes to ●/☑.

Execution Items

Execute the assigned command.

1 On a page, select command ➡ ●



Using Bookmarks & Saved Pages

Bookmarks

Bookmark sites for quick access.

Saving Bookmarks

Some pages may not be saved.

- 1 On a page, → **Bookmarks** → → **<Add New Entry>** →
- 2 Check/edit URL →
- 3 Check/edit title →
- 4 Save →

Opening Bookmarks

- 1 → **Yahoo!** → → **Bookmarks** →
- 2 **Select title** →
 - Corresponding page opens.

Switching Bookmarks Lists

After , → **Change List** → → **Select type** →

Opening Bookmarks Online

[Internet Page] → **Bookmarks** → → **Select title** →

Saved Pages

Save page content; handset opens saved pages without connecting to the Internet.

Saving Pages

Some pages may not be saved.

- 1 On a page, → **Saved Pages** → → **Save** →
- 2 **Check/edit title** →

Opening Saved Pages

- 1 → **Yahoo!** → → **Saved Pages** →
- 2 **Select page** →
 - Corresponding page opens.

Switching Saved Pages Lists

After , → **Change List** → → **Select type** →

Opening Saved Pages Online

[Internet Page] → **Saved Pages** → → **Open List** → → **Select page** →

Advanced

- Deleting titles
- Editing titles
- Changing title order
- Sorting titles into folders
- Deleting pages
- Editing page titles
- Changing page order (And more on P.5-13 - 5-14)



Updating Blogs & News

Register RSS-compatible sites; view content updates without opening source sites.

Packet transmission fees apply.

Subscribing to RSS Feeds

Indicator below appears for RSS-compatible sites.



RSS Indicator

Available for PC Site Browser.

- 1 On a compatible page, **Register In RSS Feed** → ●
- 2 Select feed → ● (□/☑) → **Complete selection** → ●
- 3 **Save** → ●
 - Choose **Yes** to update immediately or **No** and press ●.

Via RSS Icons

Use RSS icons to subscribe to RSS feeds from sites that are not RSS-compatible. Available for PC Site Browser.

- 1 On a page, select icon → ●
- 2 **Yes** → ● → **Save** → ●

Checking Updates

Follow these steps to update all feeds:

- 1 ● → **Yahoo!** → ●
- 2 **PC Site Browser** → ● → **RSS Feed** → ●




RSS Feed List

- 3 **Reload All** → ● → ●

- If a confirmation appears, follow onscreen prompts.

- 4 **Select feed** → ●



Title List

- 5 **Select title** → ●

- Information appears.

Updating Single RSS Feeds

[RSS Feed List] **Select feed** → ● → **Reload** → ● → ●

- If a confirmation appears, follow onscreen prompts.

Accessing Source Sites

After 5, select linked title → ● → **Yes** → ●

- If a message appears, follow onscreen prompts.

Advanced

- Disabling feed updates
- Sorting feeds into folders
- Deleting feeds
- Sorting feeds
- Opening feed properties
- Exchanging feeds with other devices
- Sending feeds via mail (P.5-15)



Connecting & Browsing

General

Switching browsers	<p>On a page, Switch Browser → This Page or Linked Page → Select browser</p> <ul style="list-style-type: none"> A confirmation may appear when switching to PC Site Browser.
Using previously entered URLs	<p>Start Here → Yahoo! → See below</p> <p>Yahoo! Keitai Enter URL → URL Entry Log → Select URL</p> <p>PC Site Browser PC Site Browser → Enter URL → URL Entry Log → Select URL</p>

History

Follow these steps to switch History lists:

Change List → **Select browser**

Deleting History records	<p>Start Here → Yahoo! → History → See below</p> <p>One Record Select record → Delete → Yes</p> <p>All Records Delete All → Enter Handset Code → Yes</p>
--------------------------	--

Opening History properties	<p>Yahoo! → History → Select record → Details</p>
Sorting History records	<p>Yahoo! → History → Sort → By Domain or By Date</p>
Sending History records via mail	<p>Yahoo! → History → Select record → Send URL → S! Mail or SMS → Complete message</p> <ul style="list-style-type: none"> S! Mail Composition window opens automatically depending on character count.

Memory Operation

For PC Site Browser, perform the following sequence instead of **Browser Settings**.

PC Site Browser → **PC Site Browser Settings**

Clearing cache (temporarily saved information)	<p>Yahoo! → Browser Settings → Memory Op. → Delete Cache → Yes</p>
Clearing cookies	<p>Yahoo! → Browser Settings → Memory Op. → Delete Cookies → Yes</p>
Clearing authentication information	<p>Yahoo! → Browser Settings → Memory Op. → Delete Auth Info → Yes</p>



Page Operations

■ Yahoo! Keitai & PC Site Browser

Using linked info	Dialing Numbers On a page, highlight number → ● → <i>Call or Video Call</i> → ●
	Sending Messages On a page, highlight number or mail address → ● → <i>Create Message or Create</i> → ● → <i>S! Mail or SMS</i> → ● → <i>Complete message</i> → ☺ • For mail addresses, omit mail type selection step.
Copying text	On a page, ⌂ → <i>Copy Text</i> → ● → <i>Select first character</i> → ● → <i>Highlight text range</i> → ●
Looking up copied words in dictionaries	On a page, ⌂ → <i>Convenient Func.</i> → ● → <i>Copy & Search Dict.</i> → ● → <i>Select first character</i> → ● → <i>Highlight text range</i> → ● → <i>Select dictionary</i> → ● → <i>Search</i> → ● → <i>Select word, etc.</i> → ●
Using Web Search	On a page, ⌂ → <i>Convenient Func.</i> → ● → <i>Web Search</i> → ● → <i>Enter search text</i> → ●
Searching current page	On a page, ⌂ → <i>Convenient Func.</i> → ● → <i>Search</i> → ● → <i>Enter search text</i> → ● • Press ● to jump to next search result, if any.
Jumping to page top/bottom	On a page, ⌂ → <i>Convenient Func.</i> → ● → <i>Jump In Page</i> → ● → <i>Page Top or Page Bottom</i> → ●
Opening page properties	On a page, ⌂ → <i>Convenient Func.</i> → ● → <i>Details</i> → ● → <i>Select item</i> → ●
Sending URLs via mail	On a page, ⌂ → <i>Convenient Func.</i> → ● → <i>Send URL</i> → ● → <i>S! Mail or SMS</i> → ● → <i>Complete message</i> → ☺ • S! Mail Composition window opens automatically depending on character count.

Handling Flash® files

Start Here On a page, ⌂ → *Convenient Func.* → ● → *Flash® Menu* → ● → See below

Pausing/Playing

Pause, Resume or Replay → ●

Selecting Image Quality

Quality → ● → *Select quality* → ●

Saving files to Data Folder

Start Here On a page, ⌂ → *Save Items* → ● → See below

Files on Page

Select file → ● → *Save* → ● → *Enter name* → ● → *Save here* → ●

- On a page with background image, select *Save Items* and press ● first.
- Some files are saved automatically.
- Confirm signal is strong, battery is adequately charged and that there is enough free memory beforehand.

Background Images

Save BG. Image → ● → *Save* → ● → *Enter name* → ● → *Save here* → ●

Updating page content

On a page, ⌂ → *Reload* → ●

- To update content in Saved Pages, open a page and follow the steps above.

Changing encoding to read garbled text

On a page, ⌂ → *Settings* → ● → *Char-code* → ● → *Select option* → ●

Opening function shortcuts

On a page, ⌂ → *Help* → ●



■ Yahoo! Keitai

Changing Font Size	On a page, [3 3] (Long) to enlarge or [1 3] (Long) to reduce
--------------------	--

■ PC Site Browser

Switching view	On a page, [←] → <i>Small Screen</i> or <i>PC Screen</i> → ●
Zooming on pages (Zoom Factor)	On a page, [3 3] (Long) to enlarge or [1 3] (Long) to reduce
Jumping to specific locations	On a page, [5 2] (Long) → <i>Quick Movement</i> map appears → <i>Select target location</i> → ●
Enlarging specific areas	On a page, point to area → [7 5] (Long) <ul style="list-style-type: none"> • Use [↔] to move pointer in enlarged view; highlight item and press ● to execute it. • To close enlarged view, press a key other than [↔].

Internet Page Settings

■ Yahoo! Keitai & PC Site Browser

For PC Site Browser, perform the following sequence instead of *Browser Settings* → ●.

PC Site Browser → ● → *PC Site Browser Settings* → ●

Disabling automatic image display/sound playback	[Start Here] ● → <i>Yahoo!</i> → ● → <i>Browser Settings</i> → ● → <i>Downloads</i> → ● → See below
	<i>Image Display</i> <i>Images</i> → ● → <i>Do not Show</i> → ●
	<i>Sound Playback</i> <i>Sounds</i> → ● → <i>Do not Play</i> → ●

Changing Font Size	● → <i>Yahoo!</i> → ● → <i>Browser Settings</i> → ● → <i>Font Size</i> → ● → <i>Select size</i> → ●
Using pointer navigation	[Start Here] ● → <i>Yahoo!</i> → ● → <i>Browser Settings</i> → ● → <i>Cursor Settings</i> → ● → See below
	<i>Activating</i> <i>Cursor Mode Settings</i> → ● → <i>Normal Mode</i> → ●
	<i>Changing Pointer Speed</i> <i>Speed Settings</i> → ● → <i>Select speed</i> → ●
Using handset as primary download storage	● → <i>Yahoo!</i> → ● → <i>Browser Settings</i> → ● → <i>Download to</i> → ● → <i>Prefer Phone</i> → ● <ul style="list-style-type: none"> • Some files may be saved to Memory Card regardless of this setting.

■ Yahoo! Keitai

Changing scroll unit	● → <i>Yahoo!</i> → ● → <i>Browser Settings</i> → ● → <i>Scroll Unit</i> → ● → <i>Select unit</i> → ●
----------------------	---

■ PC Site Browser

Hiding navigation map for continuous scroll	● → <i>Yahoo!</i> → ● → <i>PC Site Browser</i> → ● → <i>PC Site Browser Settings</i> → ● → <i>Scroll Settings</i> → ● → <i>Page Navigation</i> → ● → <i>Off</i> → ●
Changing scroll unit	● → <i>Yahoo!</i> → ● → <i>PC Site Browser</i> → ● → <i>PC Site Browser Settings</i> → ● → <i>Scroll Settings</i> → ● → <i>Scroll Unit</i> → ● → <i>Select unit</i> → ●
Hiding PC Site Browser messages	● → <i>Yahoo!</i> → ● → <i>PC Site Browser</i> → ● → <i>PC Site Browser Settings</i> → ● → <i>Warning Message</i> → ● → <i>Off</i> → ●



Streaming & Progressive Download

General

Customizing media playback settings	Start Here → During playback, → Settings → → See below
	Changing Playback Size Display Size → Select size → • Playback size may not change depending on file.
	Setting Backlight Status Backlight → Select option → • Selecting Norm. Setting applies Display Backlight settings.
	Adjusting Sound Effects Sound Effects → Select effect →

Streaming

Streaming from Media Player	Start Here → Media → Streaming → → See below
	Resuming from Stopped Point Last Played →
	Using Bookmarks Bookmarks → Select title →
	Using History History → Select record →

Bookmarks

Deleting titles	Start Here → Yahoo! → Bookmarks → → See below
	One Title Select title → Delete → Yes →
	All Titles → Delete All → Enter Handset Code → Yes →
Editing titles	→ Yahoo! → Bookmarks → Select title → Edit → Title: → Enter title →
Editing bookmarked URLs	→ Yahoo! → Bookmarks → Select title → Edit → URL: → Edit →
Sending bookmarked URLs via mail	→ Yahoo! → Bookmarks → Select title → Send → As Message → S! Mail or SMS → Complete message → • S! Mail Composition window opens automatically depending on character count.
Changing title order	→ Yahoo! → Bookmarks → Select title → Change Order → Select target location →
Opening title properties	→ Yahoo! → Bookmarks → Select title → Details →



Sorting titles into folders

Start Here	→	Yahoo!	→	Bookmarks	→	See below
Creating Folders						
↔	→	Create Folder	→	Enter name	→	
Moving to Folders						
Select title	→	↔	→	Move	→	Select folder
→	→	Move	→			
Moving from Folders						
Select folder	→	→	Select title	→	↔	→
→	→	Move	→			
Renaming Folders						
Select folder	→	↔	→	Rename	→	Enter name
→	→					
Deleting All Titles within a Folder						
Select folder	→	→	Select title	→	↔	→
Delete All	→	→	Enter Handset Code	→	→	→
→	→	Yes	→			
Deleting Folders						
Select folder	→	↔	→	Delete	→	Enter Handset Code
→	→	→	Yes	→	→	→

Saved Pages

Start Here	→	Yahoo!	→	Saved Pages	→	See below
Deleting pages						
One Page						
Select page	→	↔	→	Delete	→	Yes
→	→					
All Pages						
↔	→	Delete All	→	→	Enter Handset Code	→
→	→	Yes	→	→		
Editing page titles						
→	→	Yahoo!	→	→	Saved Pages	→
Select page	→	↔	→	Rename	→	Enter title
→	→					
Changing page order						
→	→	Yahoo!	→	→	Saved Pages	→
Select page	→	↔	→	Change Order	→	→
Select target location	→	→	→			
Opening page properties						
→	→	Yahoo!	→	→	Saved Pages	→
Select page	→	↔	→	Details	→	→
Switching page list view						
→	→	Yahoo!	→	→	Saved Pages	→
Select page	→	↔	→	List View or Preview View	→	→
→	→					



RSS Feeds		
Disabling feed updates	<ul style="list-style-type: none"> ● → <i>Yahoo!</i> → ● → <i>PC Site Browser</i> → ● → <i>RSS Feed</i> → ● → <i>Select feed</i> → (-) → <i>Manage RSS Feed</i> → ● → <i>Restrict Update</i> → ● 	
Sorting feeds into folders	<p>Start Here ● → <i>Yahoo!</i> → ● → <i>PC Site Browser</i> → ● → <i>RSS Feed</i> → ● → See below</p> <p>Creating Folders</p> <ul style="list-style-type: none"> (+) → <i>Manage RSS Feed</i> → ● → <i>Create Folder</i> → ● → <i>Enter name</i> → ● <p>Moving to Folders</p> <ul style="list-style-type: none"> <i>Select feed</i> → (+) → <i>Manage RSS Feed</i> → ● → <i>Move</i> → ● → <i>Select folder</i> → ● → <i>Move</i> → ● <p>Renaming Folders</p> <ul style="list-style-type: none"> <i>Select folder</i> → (+) → <i>Manage RSS Feed</i> → ● → <i>Rename</i> → ● → <i>Enter name</i> → ● <p>Deleting Folders</p> <ul style="list-style-type: none"> <i>Select folder</i> → (+) → <i>Delete</i> → ● → <i>Enter Handset Code</i> → ● → <i>Yes</i> → ● 	
	Deleting feeds	<p>Start Here ● → <i>Yahoo!</i> → ● → <i>PC Site Browser</i> → ● → <i>RSS Feed</i> → ● → See below</p> <p>One Entry</p> <ul style="list-style-type: none"> <i>Select feed</i> → (+) → <i>Delete</i> → ● → <i>Yes</i> → ● <p>All Entries</p> <ul style="list-style-type: none"> (+) → <i>Manage RSS Feed</i> → ● → <i>Delete All</i> → ● → <i>Enter Handset Code</i> → ● → <i>Yes</i> → ● <ul style="list-style-type: none"> • Alternatively, perform <i>Delete RSS Feed List</i> in Memory Op. (PC Site Browser Settings) to delete all feeds.

Sorting feeds	<ul style="list-style-type: none"> ● → <i>Yahoo!</i> → ● → <i>PC Site Browser</i> → ● → <i>RSS Feed</i> → ● → (-) → <i>Manage RSS Feed</i> → ● → <i>Sort</i> → ● → <i>Select option</i> → ● 	
Opening feed properties	<ul style="list-style-type: none"> ● → <i>Yahoo!</i> → ● → <i>PC Site Browser</i> → ● → <i>RSS Feed</i> → ● → <i>Select feed</i> → (+) → <i>Manage RSS Feed</i> → ● → <i>Details</i> → ● 	
Exchanging feeds with other devices	<p>Start Here ● → <i>Yahoo!</i> → ● → <i>PC Site Browser</i> → ● → <i>RSS Feed</i> → ● → (-) → <i>Manage RSS Feed</i> → ● → See below</p> <p>Exporting All Feeds</p> <ul style="list-style-type: none"> <i>Export All</i> → ● → <i>Select storage media</i> → ● <p>Importing (Adding Feeds)</p> <ul style="list-style-type: none"> <i>Import</i> → ● → <i>Select file</i> → ● → <i>As New Items</i> → ● → <i>Yes or No</i> → ● <ul style="list-style-type: none"> • If a confirmation appears, follow onscreen prompts. <p>Importing (Overwriting Existing Feeds)</p> <ul style="list-style-type: none"> <i>Import</i> → ● → <i>Select file</i> → ● → <i>Delete All</i> → ● → <i>Enter Handset Code</i> → ● → <i>Yes</i> → ● → <i>Yes or No</i> → ● <ul style="list-style-type: none"> • If a confirmation appears, follow onscreen prompts. 	
	Sending feeds via mail	<ul style="list-style-type: none"> ● → <i>Yahoo!</i> → ● → <i>PC Site Browser</i> → ● → <i>RSS Feed</i> → ● → <i>Select feed</i> → (+) → <i>Manage RSS Feed</i> → ● → <i>As Message</i> → ● → <i>Complete message</i> → (Y)



Security Settings

■ Yahoo! Keitai & PC Site Browser

For PC Site Browser, perform the following sequence instead of **Browser Settings** ➔ ●.

PC Site Browser ➔ ● ➔ **PC Site Browser Settings** ➔ ●

Disabling manufacture number auto send for authentication	● ➔ Yahoo! ➔ ● ➔ Browser Settings ➔ ● ➔ Security Settings ➔ ● ➔ Manufacture No. ➔ ● ➔ Off ➔ ●
Disabling referer information delivery to the Server	● ➔ Yahoo! ➔ ● ➔ Browser Settings ➔ ● ➔ Security Settings ➔ ● ➔ Send Referer ➔ ● ➔ Not Send ➔ ●
Enabling/disabling cookies	● ➔ Yahoo! ➔ ● ➔ Browser Settings ➔ ● ➔ Security Settings ➔ ● ➔ Cookies ➔ ● ➔ Select option ➔ ●
Hiding confirmations before entering/exiting secure pages	● ➔ Yahoo! ➔ ● ➔ Browser Settings ➔ ● ➔ Security Settings ➔ ● ➔ Secure Prompt ➔ ● ➔ Do not Show ➔ ●
Opening electronic certificates saved on handset	● ➔ Yahoo! ➔ ● ➔ Browser Settings ➔ ● ➔ Security Settings ➔ ● ➔ Root Certificates ➔ ● ➔ Select certificate ➔ ●
Changing validity of entered user ID/password	● ➔ Yahoo! ➔ ● ➔ Browser Settings ➔ ● ➔ Security Settings ➔ ● ➔ Keep Auth Info ➔ ● ➔ Select option ➔ ● <ul style="list-style-type: none"> ● Per Browsing retains entered user ID/password during browsing sessions. On retains such authentication information even after powering handset off. ● Authentication information may not be retained depending on the site.

■ PC Site Browser

Selecting script execution option	● ➔ Yahoo! ➔ ● ➔ PC Site Browser ➔ ● ➔ PC Site Browser Settings ➔ ● ➔ Security Settings ➔ ● ➔ Script Settings ➔ ● ➔ Select option ➔ ●
Enabling/disabling Ajax (for asynchronous communication)	● ➔ Yahoo! ➔ ● ➔ PC Site Browser ➔ ● ➔ PC Site Browser Settings ➔ ● ➔ Security Settings ➔ ● ➔ Restrict Ajax ➔ ● ➔ Select option ➔ ●

Resetting

For PC Site Browser, perform the following sequence instead of **Browser Settings** ➔ ●.

PC Site Browser ➔ ● ➔ **PC Site Browser Settings** ➔ ●

Resetting browser settings and stored information (Bookmarks, Saved Pages, etc.)	● ➔ Yahoo! ➔ ● ➔ Browser Settings ➔ ● ➔ Init. Browser ➔ ● ➔ Enter Handset Code ➔ ● ➔ Yes ➔ ●
Restoring default handset settings	● ➔ Yahoo! ➔ ● ➔ Browser Settings ➔ ● ➔ Reset Settings ➔ ● ➔ Enter Handset Code ➔ ● ➔ Yes ➔ ●



Connecting & Browsing

? What is the bar at Display bottom?

- This is a data progress bar; the number beside it indicates transmitted (green) or received (red) data.

Page Operations

? Internet page does not open completely

- Portions of page content may not appear in tabbed browsing; close other tabs.

? Text overlaps

- The site may be designed for browsing on PCs; try *Tiny* font size.
- Text may overlap when Zoom Factor is used; adjust scale.

? Cannot access other functions while browsing the Internet

- Multi Job may be active. When switching between browsers, additional function activation is disabled; close either browser and retry.

