Calendar & Tasks1	11-
Calendar	11-
Tasks	
Alarms1	11-
Using Alarms	11-
Wakeup TV11	1-1
Using Wakeup TV1	1-1
Charging Theater11	1-1
Using Charging Theater 1	1-1
Relaxation Time11	1-1
Playing Animation with Music &	
Illumination 1	1-1
Household Accounts11	1-1
Managing Household Expenses 1	1-1
Calculator11	1-1
Using Calculator 1	1-1
Expenses Memo11	1-1
Adding Expenses1	1-1
Osaifu-Keitai®11	
Osaifu-Keitai® (Japanese)1	1-2
Locking IC Card1	1-2
Simulated Call11	1-2
Faking Incoming Calls 1	1-2
Stopwatch11	1-2
Using Stopwatch1	1-2
Countdown Timer11	1-2
Using Countdown Timer 1	1-2
World Clock11	1-2
Opening World Clock1	1-2

Hour Minder	11-28
Using Hour Minder	11-28
Pedometer	11-29
Using Pedometer	11-29
Compass	11-31
Using Compass	11-31
S! GPS Navi	11-32
Using S! GPS Navi	11-32
Document Viewer	11-35
Opening PC Documents	11-35
Notepad	11-36
Saving Text	11-36
ASCII Art	11-37
Using ASCII Art	11-37
Voice Recorder	11-38
Recording/Playing Voice	11-38
Scan Barcode	11-39
Scanning Barcodes	11-39
Create QR Code	11-40
Creating QR Codes	11-40
Scan Card	11-41
Scanning Business Cards	11-41
Scan Text	11-42
Scanning Text	11-42
Kanji/English Grabber	
Using Kanji/English Grabber	11-43
Additional Functions	11-44
Troubleshooting	11-59

11

Handy Extras



Calendar

Opening Calendar

① → Tools → ② → In PIM/ Life menu, Calendar → ②



Calendar Window

• Press (>) to toggle Calendar view.

Key Assignments

■ All Views

Open Previous Page	¥ +;°
Open Next Page	#.3
Open Help	() e-g

■ 1Month/3Month View

Select Date	:
Go to Current Date	5 %

■ 6Month View

Go to Current Month	5 %
Select Month	•

■ Week View

Select Date	⊙
Select Time Block	③

Spinguru Log Calendar (Spinguru Log)

Long Press ② in Calendar window to switch to Spinguru Log Calendar (Spinguru Log). Select a date and press ② to save/ check schedules, view operation history (mail records, call log, etc.), and more.



Spinguru Log Menu

Timeline Window


Opening Help

■ To return, press **①**.

Returning to Calendar Window
[Spinguru Log Menu] (Clong)

Accessing Operation History, Etc. [Timeline Window] (1) (Long)





Saving Schedules

Follow these steps to save subject, Category, start/end date/time, Alarm and schedule details:

(Enter Subject or Description to save entry.)

In Calendar window, select date **→** •









- Preset → Select Category **→** ●
- Enter start date/time

 ◆ ●



date/time

◆



- Alarm Time:

 ◆ Select time **→** (**1**)
- Description:

 ◆ Enter schedule details **→** •
- (¬y) → Saved

Selecting Category from History In ②, History Select Category **→** () **→** From ()

Selecting Custom Category In @. . Definable → Select

Category **→ ● →** From **⑤**

All-Day Schedule In ⑤. ፟ **Prom** ⑤

Custom Alarm Time

In ②, Alarm Time: → • • Other → ● **Enter date/time ●** ● **P**

From (3)



At Alarm Time

Alarm activates; sounds/vibrates by related settings.



Stopping Alarm to Return to Standby

While Alarm sounds/vibrates, press ,
 or .

Stopping Alarm to Open Schedule

 While Alarm sounds/vibrates, press a key other than , or .

When Another Function is Active

 Alarm may not activate until handset returns to Standby.

Incoming Calls

 Active Alarm stops for incoming calls.
 Information window opens after handset returns to Standby.

Opening Schedules/Tasks

In Calendar window, select date ▶ ●



Schedule List

- 刻 Select schedule or task 🕈 💿
- 🝙 💿 🕈 Standby returns

Opening Task List In ②, select task ⇒ → Go to Tasks → ⑥

Accessing Secret Entries

[Calendar Window] ② → Unlock

Temporarily → ● ➡ Enter Handset

Code → ●

Opening Related Message

Open schedule-related messages saved from Messaging message list.

- In schedule list, select schedule ▶ ●
- - To return to schedule window, press ...

Deleting Message from Schedule
After ①, ⑥ → Related Mail: → ⑥ →
Yes → ⑥ → ♡

Advanced



Searching entries Checking memory status Deleting all entries Deleting entries by specifying week (Week View) Deleting entries by specifying month (1Month/3Month/6Month View) Deleting entries in six months (6Month View) (P.11-46)

Information Link

Set to show or hide the following information in Calendar.

Reservation	TV Timer and TV
List	Recording Timer entries
Birthday	Birthdays entered in Phone Book
What is today?	Preset anniversaries,
(Japanese)	commemorative days, etc

- In Calendar window,
- Calendar Settings

 ◆ ●
- Data to Show **▶** ●
- Select item **→** (/ / /)





Spinguru Log Information Link

 In Spinguru Log, operation history of various functions are also displayable.

- Editing TV Timer/TV Recording Timer
- In schedule list, select entry
- Edit **→** •
- Edit **→** 💬

Deleting Entries

In ②, Delete ▶ ● Yes ▶ ●

- Timer is canceled
- **Making Birthday Calls**
- In schedule list, select entry
- Call

 ◆

 Select phone number **→** (•)
 - Omit number selection step if only one number is saved.

Sending Birthday Messages

In ②, Mail → ● Select number/ **▶** (Y/)

- Omit number/address selection step if only one number or address is saved.
- For phone numbers, select S! Mail or SMS and press .

Deleting Schedules

- One Entry
- In schedule list, select schedule **▶** 🖾
- Delete → This Appointment **→** (•) **→** Yes
- All Entries of the Day
- In Calendar window, select date **→** (🖾)
- Delete


 ◆ ()

 All This Day

Tasks

Saving Tasks

Follow these steps to save subject, due date/time, Alarm and task details: (Enter Subject or Description to save entry.)











Enter due date/time

◆ ●



- Alarm: **→**
- Alarm Time:

 ◆ Select time **→ (> (>)**
- Description:

 ◆ Enter task details

 ◆

 ●
- (¬y) → Saved





At Alarm Time

Alarm activates; sounds/vibrates by related settings.



Stopping Alarm to Return to Standby

 While Alarm sounds/vibrates, press ①, ি or ঋ্ঞি .

Stopping Alarm to Open Task

 While Alarm sounds/vibrates, press a key other than , or .

When Another Function is Active

 Alarm may not activate until handset returns to Standby.

Incoming Calls

· Active Alarm stops for incoming calls. Information window opens after handset returns to Standby.


Opening Tasks





Task List

• Use • to open Completed or Incomplete task list.





Standby returns

Accessing Secret Entries

After ①, ☑ → Unlock Temporarily **→** • Enter Handset Code **→** •

Marking Tasks as Completed

After ①, select task ▶ 🖘

Deleting Tasks


- One Entry
 - In task list, select task ▶ 🖾
- Delete **→** (•)
- This Task → Yes → ●
- **All Completed Tasks**
- In task list,
- Delete **→** (•)
- All Comp. Tasks ▶ () ▶



Using Alarms

Setting Alarm

Follow these steps to set Alarm to sound at a specific time on a specific day of the week: (Set Snooze--Alarm repeats at set interval--Alarm Volume and Duration.)





Alarm List









- Selected Days → ●
- Snooze: ▶ ●
- Select interval

 ◆ ●

 For custom intervals, select Other.
- Alarm Volume: → ●
- Adjust level → ●
- 🔟 Duration: 🖈 💿

- Select time
 - For custom Duration, select Other.
- (½7) → Saved
 For more settings, repeat ② ②.

Activating Alarm Once or Daily In ②, Once or Every Day (All) → ● From ③

- Selecting/Canceling All Days
 In ⑤, ⑥ ❖ Check All or Uncheck All
 ❖ ⑥
- Excluding Holidays
 In ⊕, select day ♦ (□/√) ♦
 Complete selection ♦ Except
 - Complete selection \Rightarrow Except Holidays \Rightarrow \bigcirc (\checkmark) \Rightarrow \checkmark From \bigcirc



At Alarm Time

Alarm activates; sounds/vibrates by related settings.



Stopping Alarm

• Press a key.

When Another Function is Active

 Alarm may not activate until handset returns to Standby.

Incoming Calls

• Active Alarm stops for incoming calls. Information window opens after handset returns to Standby.

When Snooze is Set

Alarm repeats at the set interval. Other Alarms do not activate while handset is Snoozing.

Canceling Snooze

While Snoozing, ● * Yes * ●

■ Snooze is automatically canceled after a period of time.

Canceling Alarm






 Reactivate entry to use the same settings.

Reactivating Entry

In ②, Switch On → ●

Deleting Alarm

One Entry





All Entries

In Alarm list, select entry



Using Wakeup TV

Setting Wakeup TV

Follow these steps to activate TV at a specific time on a specific day of the week:

- Complete TV Area setup beforehand.
- TV may not activate in poor signal conditions.
- Tools ⇒ In PIM/Life menu, Wakeup TV ⇒ ●



Wakeup TV List

2 --:-- ▶ ● ▶ Enter hour (24-hour format) ▶ Enter minutes ▶ ●



Wakeup TV Menu

- Repeat: ▶ ●
- Selected Days → ●
- Select day → (□/☑) → Complete selection → ☑
- Channel: →

 O
- Select channel **→** ●
- (∑r) ⇒ Saved• For more settings, repeat ② ③.
- Standby returns

- Activating TV Once or Daily
 In ②, Once or Every Day (All) ▶
 - **⇒** From ⑤

Selecting/Canceling All Days

In ⑤, ৷ Check All or Uncheck All

Excluding Holidays

- In \bigcirc , select day \triangleright \bigcirc $(\bigcirc / \bigvee) \triangleright$ Complete selection \triangleright *Except*
- $Holidays \Rightarrow \bullet (\boxed{\lor}) \Rightarrow \boxdot \Rightarrow \text{From } \odot$

Canceling Alarm

 Alarm activates at Wakeup TV time. To cancel Alarm, follow these steps:

Adjusting Alarm Volume

[Wakeup TV Menu] Alarm Volume: →

Adjust level
 From
 From



At Wakeup TV Time

TV activates after Alarm.



Stopping Alarm Instantly

- While Alarm sounds/vibrates, press a key. When Another Function is Active
- TV may not activate depending on the function

After TV is On for a Period of Time

• A confirmation appears. Choose Yes and press () to exit TV.

Canceling Wakeup TV

- In Wakeup TV list, select entry **→** 🖾
- Wakeup TV Off

 ◆

 • Reactivate entry to use the same

In ②, Wakeup TV On → •

settings. Reactivating Entry

Deleting Wakeup TV


- One Entry
- In Wakeup TV list, select entry **▶** 🖾
- Reset Alarm **→** •
- Yes **♦** (•)
- All Entries
- In Wakeup TV list, select entry **▶** 🖾
- Yes **→** (•)

Play Slide Show or video while charging.

Enabling Charging Theater

Example: Setting Slide Show Enabling Charging Theater sets Viewer Position Move Settings to *Off(Standby)*.









 Omit steps for sub folder when using images saved in Pictures folder. Setting Video
In ②, Video ▶ ● Select file ▶ ●
Changing Playback Time
In ③, Playback Time ▶ ● ▶ Select
time ▶ ●
Enabling Video Audio Output
In ⑤, Video Sound Output ▶ ● ▶
On ▶ ●
Disabling Repetitive Video Playback
In ③, Video Repeat ▶ ● ▶ Once

Activating Charging Theater

Start charging in Standby; Slide Show or video plays according to settings.

Incoming Calls while Charging Theater is Active

Charging Theater ends.

Play **▶** •

Playing Animation with Music & Illumination

Play preset animations or downloaded Flash® files with music and illumination. Set playback time, volume, etc. as needed.

- ① Tools ● In PIM/ Life menu, Relaxation Time ● ⑥
- Select type

 ◆ Animation appears.
 - For *Flash*®. select a file and press •.
 - Key LEDs do not illuminate for soundless Flash® files.
 - Message appears when Playback Time is set to *Continuous Play* (except when charging battery); press to proceed.

Setting Relaxation Time

Follow these steps to set playback time, volume and Key Illumination pattern:

- → Tools → In PIM/ Life menu, Relaxation Time → ●
- Settings → ●



- Playback Time → ●
- Select time →
 - For custom playback time, select Other.
- G Volume → •
- Adjust level **→** ●
- Effect Illumination → ●

- 🛜 Key Pattern 🕈 💿
- Select pattern → → 🕏
- Standby returns

Changing Illumination Pattern In ③, Pattern/Color → ● Select

In ⑤, Pattern/Color ➤ ⑥ ➤ Select pattern ➤ ⑥ ➤ Select color ➤ ⑥ ➤ છ

Light color is unselectable for some patterns.

Setting Music to Control Illumination
In ③, Switch On/Off ▶ ● ▶ Link to
Sound ▶ ● ▶ ∞

Key Illumination varies by music when Link to Sound is set.

Disabling Illumination
In \bigcirc , Switch On/Off \Rightarrow \bigcirc \Rightarrow Off \Rightarrow \bigcirc \Rightarrow \bigcirc




Managing Household Expenses

Scan receipts with mobile camera to manage expenses on handset.

Setup

Specify closing day, closing month and budget for the month.

 Tools → ● In PIM/ Life menu, Household Accounts **→ ●**



Household Accounts Window







Account Setup Menu






date (end of the month): use • to move between date and month fields









Restricting Access to Household **Accounts by Handset Code** [Account Setup Menu] Locks → • **→** On **→ (•)** Resetting Household Accounts [Account Setup Menu] Master Reset → () → Yes → ()



Saving Entries

Scanning Receipts

Scan receipts with mobile camera to enter date, expense items, fees/prices and total amount automatically.

Scan may fail if receipt is too long, folded, faded, etc.; some formats are not supported.

- In Household Accounts window, select scan receipt panel ▶ ●
- Frame receipt on Display



Scan Window


 Frame date, expense items and total amount. Align text parallel to reference lines.





• To cancel, press 🖘.







 To add, delete or edit expense items, see P.11-16 "Entering Manually."





Entry is saved.

Opening Operation Guide [Scan Window] (\$\frac{\partial}{2}\$)

■ Press to return to scan window.

■ Key Assignments in Scan Window

Toggle Focus Mode	3 **
Focus Lock	3.7
Mobile Light On/Off	#,3
Adjust Brightness	•
Open Help	() es



- **Entering Manually**
- In Household Accounts window, select manual input panel

 ●



Expense Input Window

- Shop → → Select shop/ facility → ●





- ltem → ► Enter name
- Category → Select Category → ●
- Value → ► Enter amount
- Saved

Adding Expense Items

After ③, select item field ⇒ ⊚ ⇒

Add Items ⇒ ● From ⑤

Deleting Expense Items

After \odot , select item $\Rightarrow \boxtimes \Rightarrow$ Delete $\Rightarrow \bigcirc \Rightarrow \forall es \Rightarrow \bigcirc \Rightarrow \odot$

Changing Categories of All Items at Once [Expense Input Window] Category Change → ⑥ → Select Category → ⑥ → ⑤



Opening Expense Records

- Opening Entries
- In Household Accounts window, select totals panel
- Select date → ●



Daily Expense Log

- Select entry

 ◆

 ○

 Details appear.
- **Deleting an Entry**

[Daily Expense Log] Select entry ▶ ⑤

Delete Receipt → ● Yes → ●

Deleting All Entries

[Daily Expense Log] ^(S) → Delete Day Data or Delete Month Data → ^(S) → Yes → ^(S)

Viewing Expense Trends

Follow these steps to view monthly expenses, budgets and balances:

- In Household Accounts window, select charts panel
- Results by Month → ●



Results by Month Window

- Press to toggle budget and balance.
- Use to open previous or next year.


Viewing Other Expense Trends In ②, select item ▶ ●

Monthly Result Charts




- In Balance chart, gray area of each bar represents balance; bar turns pink when balance is zero or less
- In Expenses chart, orange bar extends to the left as monthly expense increases, with the middle of the chart indicating average monthly expense for the year.

Using Calculator





Calculator Window





Key Assignments	
+ (Add)	•
- (Subtract)	<u></u>
× (Multiply)	③
÷ (Divide)	②
= (Sum)	•
C·CE (Clear)	(MEAR SI)
CM (Clear Memory)	(E)
RM (Recall Memory)	*·
M+ (Add to Memory)	¥7)
. (Decimal)	¥ +1°
+/- (Positive/Negative Value)	# , 👸
% (Percentage)	(F) (8)

Memory Calculation

- Clear Memory before starting new Memory calculations.
- Numbers saved in Memory remain until handset is powered off.


Incoming Calls

 Calculations are not affected. End the call to return to Calculator.

Using % Function

Use (a) to find definite percentage of a known value.

Example: Calculate 30% of 800,000 Enter $800,000 \Rightarrow x \Rightarrow 30 \Rightarrow \%$







Adding Expenses

Entering Expenses

 Tools → ● In PIM/ Life menu, Expenses Memo \rightarrow



Expenses Memo Menu

- Add New

 ◆
- Enter amount **→** •



Select Category **→** (•) **→** Saved

Saving under Custom Category In ⑤, Other ♦ ⑥ ♦ Enter name ♦ ⑥ **Renaming Lists** [Expenses Memo Menu] Select list

name **→ (•)**

Resetting All List Names [Expenses Memo Menu]

→ Reset Title → • Yes → •

Checking Entries

In Expenses Memo menu, select list **→** (•)



Expenses Memo List

Standby returns

Saving Entries to Notepad [Expenses Memo List] Select entry ⇒ Save to Notepad ⇒
●

Deleting Entries

- One Entry
- In Expenses Memo list, select entry **→** (□)
- Delete Item **→** (•)
- Yes **▶** (•)
- **All Entries**
- In Expenses Memo list, select entry **→** (□)
- Yes **▶**
 - All entries on the list are deleted.

Osaifu-Keitai® (Japanese)

Osaifu-Keitai® describes IC Card-equipped handsets that support e-money or credit functions/services, Osaifu-Keitai® encompasses a range of IC Card-based services on FeliCa-compatible SoftBank handsets. 945SH supports Osaifu-Keitai®. To use e-money, e-ticketing and reward points, etc., hold handset over a compatible reader/writer at shops, restaurants, and other retail outlets, etc.

Basics

Before using Osaifu-Keitai®, activate Lifestyle-Appli, complete registration, customize settings and charge accounts.

Starting Lifestyle-Appli

● **Tools →** In PIM/Life menu, **→** • Select application **→** •

Important Lifestyle-Appli Usage Notes

- Contact Osaifu-Keitai[®] service providers for Lifestyle-Appli registration and usage details
- Keep service passwords/customer service contact information, etc. in a separate place.

Using Osaifu-Keitai®

Follow these steps to conduct a transaction: Example: Making an electronic payment

- Lifestyle-Appli activation is not necessary.
- Transactions are possible even while handset is off (if battery is adequately charged).
- Calls/Internet transmissions do not affect. transactions
- Place $\sqrt{}$ logo over reader/ writer > Confirm scan results



Place this part over reader/writer

Align handset parallel to reader/writer.

Important Osaifu-Keitai® Usage Note

 SoftBank Mobile is not liable for damages resulting from accidental loss/alteration of IC Card data/settings.

When Placed Over Sensor


- If recognition is slow, move handset around slightly.
- Handset may respond automatically for some services.




Locking IC Card

IC Card Lock

Restrict access to/prevent unauthorized use of Osaifu-Keitai® on handset.










IC Card Settings Menu






Canceling IC Card Lock In \bigcirc , IC Card Lock \Rightarrow \bigcirc \Rightarrow Off \Rightarrow \bigcirc ★ Enter Handset Code
 ◆ ●



Remote Lock

Disable Osaifu-Keitai® remotely by mail or phone.


Lock	Send mail to activate Remote Lock
Call Remote	Call from a specified phone to activate Remote Lock
Lock	to activate Remote Lock



Preparation on Handset











Mail Remote Lock Menu

- 🕞 Remote Lock PW **→** 💿
- Enter password **→** ●
- Switch On/Off **→** ●
- 🛜 On **→** 💿 **→** 🐨

Canceling Mail Remote Lock
In ⑤, Switch On/Off ❖ ⑥ ❖ Off ❖
⑥ ❖ ♡

■ Activating Remote Lock via Mail If handset cannot receive mail, IC Card Lock remains unset

- Send S! Mail or e-mail to handset with password as subject
 - After handset receives message, IC Card Lock is set and notice is sent as a reply.

- **Call Remote Lock**
- Preparation on Handset
- Tools → In PIM/ Life menu, *Osaifu-Keitai* **→ ●**
- IC Card Settings

 ◆

 ●
- Remote Lock

 ◆ Enter Handset Code **→ (•)**
- Call Remote Lock **→** ●



Call Remote Lock Menu

Phone No. to Lck 1 or Phone No. to Lck 2 > (•)



- Phone Book

 ◆

 Select entry

 ◆

 Select phone number **→** (•)
 - Select Phone Number to enter directly.
- On **→** (**•**) **→** (**•**)

Enabling Activation via Public Phone In ⑤. Set Public Phone → ⑥ → On **▶ (•) ▶** From **(•)**

Canceling Call Remote Lock

In ⑤. Switch On/Off → ⑥ → Off →

(▶)

- Activating Remote Lock via Phone If handset cannot receive calls, IC Card Lock remains unset.
- Using one of the specified phones, call handset Send Caller ID.
- End the call
 - The call is recorded as a Missed Call.
- Within three minutes, repeat በ - 🕗 twice
 - After the third Missed Call, IC Card Lock is set; a message announces Remote Lock activation. Confirm the message and end the call.

If Series is Interrupted by Another Call


• Missed Call count is reset. Start over from the beginning.

Faking Incoming Calls

Handset rings to emulate an incoming call.

- Save name and phone number to show as Caller ID.
- Ringer may be muted by handset settings.
 To override Silent setting, see P.11-51.

Setting Simulated Call








Simulated Call Menu










Assign Tone

◆ ● Select tone/file

• ●



When Name and Phone Number are Unset

Handset rings with Caller ID "Withheld."
 Canceling Simulated Call

[Simulated Call Menu] Switch On/Off

→ • → Off → • → ·

Setting Wait Time

[Simulated Call Menu] Receive Timing

 → ● Select time
 → ⑨

Using Simulated Call



- Handset rings and incoming Voice Call window opens.
- Ringtone stops after a period of time.

In incoming Voice Call window, press

 Voice Call window opens. (Softkeys are dummies.)



When Receive Timing is Not Immediately

- Press ③ or during wait time to cancel Simulated Call activation.
- Simulated Call activation is canceled by incoming calls, Alarms, etc. during wait time.



Stopwatch stops if battery runs low.





Stopwatch Window

- Stopwatch starts
- **Stopwatch stops Stopwatch stops**
 - Press to resume.
- - Records are deleted when Stopwatch ends.

Using Countdown Timer

● ★ Tools ★ ● ★ ⊙
 Clock/Gauge ★ Countdown
 Timer ★ ●



Timer Entry Window


- Enter minutes → Enter seconds
 - Tap +10min, +1min or +30sec as needed.





Countdown Timer Window

- Press (to change time.
- Press to stop/resume countdown.
- Set time elapses → Tone sounds



Using Timer Records

After ①, ⑤ → Input History → ⑥ →
Select record → ⑥ → ⑥ → From ②

Resetting Countdown Timer

Stop countdown and

Incoming Calls

 Countdown is not affected by incoming calls. End the call to return.

When Set Time Elapses

Tone sounds.



Stopping Tone Instantly

• Press • or ... (Tone stops automatically after a period of time.)

When Timer Time Elapsed during a Call

• Tone sounds after the call.



Opening World Clock

 \bullet \rightarrow Tools \rightarrow \bullet Clock/Gauge **→** World Clock







Advancing One Hour (Daylight Saving) [Set Time Zone Window] (27)

■ To cancel, press (Y). **Adding Custom Time Zone**


Enter time difference

◆

●

Opening World Clock in Standby

 Settings → ● → In Sound/Display menu, Display **→** ●













Set Time Zone Window



Using Hour Minder

Setting Hour Minder


Follow these steps to activate the hourly time signal at selected hours:





Hour Minder Menu













From

For custom Duration, select *Other*.

Selecting/Canceling All Hours

In ②, → Check All or Uncheck All → ●

At Hour Minder Time

Hour Minder activates; sounds/vibrates by related settings.



Stopping Tone Instantly

Press a key.

When Another Function is Active

Hour Minder does not activate.
 Incoming Calls

Active Hour Minder stops for incoming calls.

Canceling Hour Minder



Advanced



© Changing Hour Minder tone/video © Setting handset to vibrate at Hour Minder Time © Changing illumination settings © Sounding Hour Minder tone even in Manner mode © Activating Hour Minder based on World Clock time (P.11-52)

Using Pedometer

Getting Started

- Count based on a pace of approximately 100 steps per minute over even terrain.
- Accuracy may be affected by course, terrain, walking style, etc.
- Avoid holding the handset; use a body worn case or a strap, or place handset inside a pocket or bag.
 - Avoid sudden/erratic movements.
- Steps are not counted in the following cases:
 - While handset is off
 - For the first few steps
 - While handset vibrates
- Handset use may affect accuracy.
- Weight and pace entry required to view full Pedometer data.
- Use Pedometer only as a rough guide.

Adjusting Counter Sensitivity

- ◆ Tools ◆ ◆ Clock/Gauge
 ◆ Pedometer ◆ ◆ □ ◆
- Pedometer → → □ →
 Settings → > Step Sensitivity →
- Select option
 ●
- Select Low when steps seem overcounted; select High when they seem undercounted

Saving Body Information





Pedometer Window

- If Pedometer is disabled, a confirmation appears. Choose Yes or No and press .
- ② **⇒** Settings **⇒ ⊙ ⇒** Body Info. **⇒ ⊙**



Body Info Menu

- Height → ► Enter height
- Weight → ► Enter weight → ●
- Pace → → Yes or No → ●

 Choose Yes to enter pace
- automatically based on height.

 Enter pace → → (¾)
- Editing Body Information
 [Body Info Menu] Select item ▶
- For *Pace*, automatic calculation confirmation appears (when height is entered).

Enabling Pedometer

In Pedometer window,

Pedometer On

Output

Pedometer Output

Pedom

Disabling Pedometer
[Pedometer Window]

Pedometer Off

●



Viewing Step Count Records

In Pedometer window,



Steps Window

- Press 🕏 to toggle Daily/Hourly view.
- Press #3 or ** to scroll down or up by one page.







Pedometer Window Tabs

• Press to open Exercise and then Calories.

Resetting Today's Step Count

[Pedometer Window]

→ Reset

Day's Data → → Yes → ●


Resetting Log

[Steps Window] ^(□) → Walk Data Reset → (□) → Yes → (□)

■ Today's data is also reset.

Setting Targets

Information window opens, etc. when target is achieved for these items:



- In Pedometer window,

 Settings

 Target

 Output

 Targ
- 🔁 Target Settings 🕈 💿



 Other target settings may consequently change.

Editing Targets

[Pedometer Window] ③ → Settings → ⑥ → Target → ⑥ → Target Settings → ⑥ → Select item → ⑤ → Enter value/time → ⑥

When Target is Achieved

 A tone sounds and Information window opens. (Select *Goal Achievement* and press to open Pedometer Calendar.)
 Follow these steps to mute achievement tone:

About Exercise (Ex)

 Ex and MET indicate amount and intensity of physical activity, respectively.
 Ex for walking is calculated by multiplying 3 METs by walking duration (hour).



Using Compass

Opening Compass





Compass Window

Compass opens; use as a rough guide.

Adjusting Compass

In Compass window, ●

● • Follow onscreen instructions.

Compass Indicator

• When map is open, compass indicator appears; follow these steps to hide it: ● Tools • ● Clock/Gauge ⇒ S! GPS Navi ⇒ • NAVI Settings → ● Compass Indicator **→** • **→** Off **→** •



Using S! GPS Navi

Use this GPS navigation service to pinpoint current location, find routes to destinations, and more.

- Provide current location to administrator upon request.
- Available in clamshell open or Viewer position.

Precautions

- Location Information accuracy may be affected when GPS satellite/radio station signal reception is poor. Use S! GPS Navi under the open sky.
- SoftBank Mobile is not liable for any damages resulting from the provided Location Information.

Positioning

• Pinpoints current location using signals transmitted from GPS satellites.

Location Information Accuracy

- Probable distance from the actual position is classified into three accuracy levels, from level 1 (low) to 3 (high), indicated by the number of &s.
- A confirmation appears when accuracy level is 1 or 2; follow these steps: Yes or No ▶ •

ightharpoonup

Starting Navi-Appli





SI GPS Navi Menu



• To disable confirmation, press before 🕙.



Opening Navi Appli List [S! GPS Navi Menu] Navi Appli List

■ To activate Navi Appli, select one and press .

Selecting a Navi-Appli for S! GPS Navi [S! GPS Navi Menu] NAVI Settings ▶ Select Navi Appli→ Select application

◆

●



Opening Location Log

- In S! GPS Navi menu. Location Logs **→** (●)
- Select record **→** Details appear.
- List returns

Pinpointing Current Location

In S! GPS Navi menu, Locate Me

◆ (●)



- To disable confirmation, press before 🙉
- Yes

 ◆

 Positioning starts
 - Map of your current location appears.

Using My Location

Saving Location Information

Follow these steps to save current location as a new entry:

In S! GPS Navi menu, My Location List

◆

●



My LocationList Menu

- New Entry **→** •
- Name

 ◆

 Enter name
- Location Info

 ●
- From Current Loc.

 ◆ Positioning complete
- - When accuracy level is 1 or 2, choose **No** and press • to proceed to •.



Saving as Home

In ②. 自宅 → ● From ④ Saving from Location Log In ⑤. From Location Logs • ⑥ •

- **Opening Entries**
- In My LocationList menu, select entry **→** •
- Location Info **→** (•) Details window opens.
- Details window closes
- **Deleting Entries**
- In My LocationList menu, select entry

Advanced

🖄 Sending current location via mail Changing map source URL Disabling positioning Selecting Location Information transmission option Using My Location & Location Log Saving Location Log records to My Location Deleting Location Log records (P.11-53)

Using Ichi Navi (Japanese)

Locate other S! GPS Navi-compatible handset users or lost handset.

- Ichi Navi requires a separate contract and initial settings.
- If Double Number is active, service uses Line A regardless of usage mode setting.
- For more about Ichi Navi, see SoftBank Mobile Website (P.17-24).



 Handset connects to the Internet. Follow onscreen instructions.

Providing Location Information

Provide current location to administrator upon request.

- Location may be provided automatically upon administrator's request without confirmation.
- May be unavailable depending on subscription. For details, contact the nearest SoftBank Shop or SoftBank Mobile Customer Center, General Information (P.17-43).

Location Information request arrives




 A confirmation appears. (Message shown above is for reference only.)





Information

Information window opens after your location is provided manually (by pressing (III) upon Location Information request or automatically upon administrator's request. Select the item and press () to open log.





Opening PC Documents

Supported File Formats:

PDF (.pdf)
Microsoft® Excel® (.xls)
Microsoft® Word (.doc)

- Microsoft® PowerPoint® (.ppt)
- Some files may not appear correctly.
- Downloaded files are also supported. • When transferring files from PCs, save to
- corresponding Memory Card folder (P.17-25).






Zooming In/Out with Loupe (Magnifier) In open file, [®] (Long) → Specify portion → 🖾 → Zoom Out or Zoom In **▶** ●

Key Assignments	
View Whole Page	•
Scroll	•••
View Upper Left	1 *
Toggle Full Screen View On/Off	2 m/ (3 m)
View Upper Right	3 3
Zoom Out	4 con /
Continuous Zoom Out	4 cong) (Long)
View Center	5
Zoom In	6 12 / <
Continuous Zoom In	(Long)
View Lower Left	7 *
Jump to Page	8 *P
View Lower Right	9 3
Open Help	() pg
Next Page	#,ŏ
Previous Page	X + + + + + + + + + + + + + + + + + + +
Fit Width	<u>*,)</u>
Rotate 90 Degrees	(Y2)

Saving Text


New Notepad Entry





Notepad List







Sorting Entries Temporarily [Notepad List] (\$\forall p\$)

Press to toggle sort options (Modified, Created, Category and Accessed).

Changing Landscape Notepad List View
[Notepad List] Select entry ♥ ⑤ ♥

Setting/Manage ♥ ⑥ ♥ Landscape

Display ♥ ⑥ ♥ Select option ♥ ⑥

Inserting Notepad Text during Text Entry

[Text Entry Window] ⑥ ♥ Notepad

■ Not available in Notepad text entry window.

Opening Notepad

In Notepad list, select entry

→ ●

Text appears.



Deleting Entries

One Entry

In Notepad list, select entry

⇒ □




Selected Entries

In Notepad list, select entry →

Setting/Manage →

O



👔 Delete 🕈 💿 🕈 Yes 🕈 💿

Unchecking All In €, Uncheck All • ●

All Entries

In Notepad list, select entry →

Setting/Manage →

O



Advanced



© Editing Notepad Searching text within all entries Inserting Notepad text into message text Sending entries via S! Mail Creating text files Importing text files Checking memory status Opening properties (P.11-54)

Using ASCII Art

Inserting ASCII Art

- In message text entry window, □ → Call ASCII Art → ●
- Select entry → ●




Previewing ASCII Art

In ②, select entry ▶ ☒

■ Press ⑥ to insert ASCII Art.

Editing Entries





ASCII Art List

Select entry → ● → Edit → ●

Opening Entries

In ②, select entry ▶ ③ ▶ View ▶ ●

Adding New Entries

In ②, <Empty> → ● Create ASCII Art → ●

Deleting Entries

- In ASCII Art list, select entry

 → □ → Delete → ●
- Yes → ●

Recording/Playing Voice

Recording

- Recording stops if battery runs low while recording.
- Record conversations during calls via Record Caller Voice.





Recording Window



- For Extended Voice, recording is saved automatically.
- A Save → ●

 Play Before Saving
 In ②, Playback → → Playback
 starts → □ → Playback stops



Starting Over

Playback

- In recording window, ☐ →
 Ring Songs Tones → ●
- Select file → ●

Playback Operations

Volume Control	③
Pause/Resume	•
Stop	(NEAR CO)



Advanced

Scanning Barcodes

Scan UPC/JAN (1D barcodes) or QR Codes (2D barcodes).

Some barcodes may not be scanned.







Frame barcode in center of Display



Scan Window

 Use Focus Adjustment Bar as a guide (better focus in darker blue).



Scan starts

- If recognition takes time, slowly adjust the distance between handset and barcode
- To cancel, press (\(\frac{\pi}{2}\)).

Tone sounds ◆ Scan results appear



Split Data

- After scanning, a confirmation appears. Follow onscreen prompt(s).
- Scan results do not appear until all split data is scanned.

Starting Over



Key Assignments in Scan Window

Toggle Focus Mode	3 🐉
Switch to Photo Camera	7 *
Focus Lock	*.J
Mobile Light On/Off	#,ప
Adjust Brightness	•
Open Help	() pg


Advanced

🥙 Scanning during text entry Scanning continuously Reading saved barcode images Saving scan results Saving to Notepad Saving linked info to Phone Book Opening saved scan results Using linked info Using images as Wallpaper Saving images & melodies Copying text (And more on P.11-55 - 11-56)



Creating QR Codes

Create QR Codes from these items on handset:



Large items are divided into multiple QR Codes.

Procedure

Follow these steps to create QR Codes from Data Folder files:



- Create QR Code →
 - Bata Folder →

 O
 - Select folder

 Select file or entry

 OR Code is created.

 - QR Code is saved to Data Folder (Pictures).

From Phone Book Entries
In ②, Phone Book → ● → Select
entry → ● → □
From My Details
In ②, My Details → ● → □
From Entered Text
In ③, Text Input → ● → Enter text
→ ● → □
Switching Storage Media
In ③, ② → Save to → ● → Phone
or Memory Card → ● → ●
Attaching to S! Mail
In ③, ② → Send As Message → ●
→ Complete message → ♡

- Incoming Calls

 QR Code creation is not affected by
- QR Code creation is not affected by incoming calls. End the call to return.

Scanning Business Cards

Scan business cards and save names, addresses, etc. to Phone Book.

- English business cards may not be scanned correctly.
- Some cards may not be scanned.






Rrame card on Display



Scan Window









If Text Exceeds Phone Book Entry Item Character Limit

• A confirmation appears. Follow these steps to delete overage:

Yes **→** •

Switching Storage Media

After ⑤, ⑥ ♦ Save to ♦ ⑥ ♦
Select storage media ♦ ⑥ ♦ ⑥
Saving Scanned Image as Phone Book

Picture

After \bigcirc , \bigcirc \Rightarrow Add Image \Rightarrow \bigcirc \Rightarrow On \Rightarrow \bigcirc

Starting Over

After \bigcirc , \bigcirc \Rightarrow Yes \Rightarrow \bigcirc \Rightarrow From \bigcirc

Key Assignments in Scan Window

Toggle Focus Mode	3 of 1
Switch to Photo Camera	7 2
Focus Lock	\$
Mobile Light On/Off	# s š
Adjust Brightness	•••
Open Help	() es


Advanced

Scanning Text

Scan text and save it to Notepad, etc. Available Modes:

	Capture text in full screen and scan a selected line
Line	Capture a few lines of text and scan a selected line


- To toggle mode, press 💬 in scan window.
- Some text may not be scanned.





• To change mode, press 🐑 in scan window.

Frame text in center of Display



Scan Window

- Scan starts
 To cancel, press ூ.
- Select line **▶ ● ▶** Scan results appear







Correcting Text Type After ⑤, ⑥ ♦ Change Mode ♦ ⑥ ♦ Select type ♦ ⑥ ♦ From ⑥ Editing Scanned Text After ⑤, ⑥ ♦ Select/Edit ♦ ⑥ ♦ Select character ♦ Select alternative from list or edit directly ♦ From ⑥ Starting Over In ⑥, ⑥ ♦ Yes ♦ ⑥ ♦ From ⑥

Key Assignments in Scan Window

Toggle Focus Mode	3 🕏
Switch to Photo Camera	7 m
Focus Lock	*,
Mobile Light On/Off	#.ప
Adjust Brightness	•••
Open Help	0 %

Advanced




Scanning and pasting during text entry Scanning more text Saving scan results Saving linked info to Phone Book Opening saved scan results Using linked info Pasting to message text Copying text (P.11-57 - 11-58)

Using Kanji/English Grabber

Scan a kanji compound or English word and look it up in dictionaries. Some kanji/English words may not be scanned.











- Scanned word appears with reading
- (for kanji) or meaning (for English).



- If there is only one search result, definition/translation window opens; omit (3).
- Select word, etc. **→**
 - Definition/translation window opens.



Key Assignments in Scan Window

Toggle Focus Mode	3 nes
Switch to Photo Camera	7 *
Focus Lock	**)
Zoom In/Out	③
Mobile Light On/Off	#.3
Adjust Brightness	•••
Open Help	() to 8

Advanced



Calendar View Settings ● → Tools → ● In PIM/Life menu, Calendar Changing default view Default View → ● Select type → ● Jumping to ● → Tools → ● → In PIM/Life menu. Calendar → ● ● 8 → Enter date → ● specified date Start Here () → Tools → () → In PIM/Life menu. By Days of the Week Select color ⇒ ● Changing date **Bv Date** color Not available in 6Month View. Resetting "By Date" Colors Reset Color Select option Reset Color Select option Output Description Des → Yes → ● ● → Tools → ● In PIM/Life menu, Calendar Selecting task view → (a) → (b) → Calendar Settings → (a) → (b) → (b) → (c) option Adding stamps ● → Tools → ● In PIM/Life menu, Calendar (1Month/3Month ⇒ Select date ⇒ (2 ♣) ⇒ Select stamp ⇒ (●) View) **Hiding schedules** ⇒ Select date ⇒ ○ ⇒ Select entry ⇒ ○

	Start Here
Saving additional holidays	Adding Holidays <empty> → ● → Enter name → ● → Enter date → ● → Select frequency → ● → ⊙</empty>
	Editing Added Holidays Select holiday © Edit Name: Enter name O Date: Enter name Select frequency Select frequency Select frequency
Hiding/showing holidays	● → Tools → ● In PIM/Life menu, Calendar → ● → ⊜ → Calendar Settings → ● Set Holiday → ● → → Private or Public → Select holiday → ● (□/☑)
Saving/Editing Schedules	
Setting Location	● * Tools * ● * In PIM/Life menu, Calendar • • Select date * • Select entry * • • * Location: • • Enter location * • • • • • • • • • • • • • • • • • •
Creating Categories	Start Here
	Renaming Categories Select Category
	Changing Icons Select Category
	Resetting



Saving repetitive schedules	 Tools In PIM/Life menu, Calendar Select date Select entry Repeat: Select frequency Enter repeat time \omega \omega Repeat time is not available for Every Year.
Saving SI Friend's Status information	Start Here
	Availability Answer Status: ● ◆ Edit ◆ ② ◆ ② ◆ ② • Set Category first.
	Comment: Comment: Set Category first.
Editing entries	 Tools In PIM/Life menu, Calendar Select date Select entry Select item Edit in the same manner as saving schedules
Changing Alarm tone/video & duration	Start Here
	Alarm Tone/Video Assign Tone/Video: Select folder Select tone/file Select start point if required.
	Duration Duration: ◆ ● Select time ◆ ● ◆ ♥ ◆ ♥ • For custom Duration, select Other and press ●.

Changing Alarm volume	● Tools ● In PIM/Life menu, Calendar ● ⑤ Alarm Settings ● Alarm Volume: ● Adjust level ●
Selecting Vibration option	● **Tools ** ● **In PIM/Life menu, Calendar ** ● ** ⑤ *** Alarm Settings ** ● ** Vibration: ** ● ** Select option ** ●
Changing illumination settings	Start Here ● → Tools → ● → In PIM/Life menu, Calendar → ● → □ → Alarm Settings → ● Effect Illumination: → ● → See below
	Setting Alarm Tone to Control Illumination Switch On/Off
	Changing Illumination Pattern Pattern/Color → ● Select pattern → ● → Select color → ● → ② Light color is unselectable for some patterns.
	Changing Key Illumination Pattern Key Pattern
	Disabling Illumination Switch On/Off ⇒ ● → Off ⇒ ● → ②
Sounding Alarm tone even in Manner mode	● Tools ● In PIM/Life menu, Calendar ● ● ③ → Alarm Settings ● ● For Manner Mode: ● ● Ring ● ● Yes ●

■ Managing Schedules

■ Managing Schedules	
Searching entries	Start Here ● → Tools → ● In PIM/Life menu, Calendar → ● → See below
	By Part of Subject 6♣ ▶ Enter text ▶ ●
	By Category
Checking memory status	 Tools In PIM/Life menu, Calendar Select date Memory Status
Deleting all entries	● Tools ● In PIM/Life menu, Calendar ● □ □ Delete ● All Appointments ● Yes ●
Deleting entries by specifying week (Week View)	Start Here ● → Tools → ● In PIM/Life menu, Calendar → ● → See below
	Within One Week Select date ⇒ ② ⇒ Delete ⇒ ● ⇒ All This Week ⇒ ● ⇒ Yes ⇒ ●
	Up to the End of Previous Week Select date ⇒ ② ⇒ Delete ⇒ ● ⇒ Up to Last Week ⇒ ● ⇒ Yes ⇒ ●
Deleting entries by specifying month (1Month/3Month/ 6Month View)	Start Here ● → Tools → ● In PIM/Life menu, Calendar → ● → See below
	Within One Month Select date ⇒ ② ⇒ Delete ⇒ ● → All This Month ⇒ ● → Yes ⇒ ●
	Up to the End of Previous Month Select date → ② → Delete → ● → Up to Last Month → ● → Yes → ● Not available in 6Month View.

Deleting entries in	● → Tools → ● → In PIM/Life menu,
	Calendar → ● → 🖾 → Delete → ● → All
(6Month View)	This 6Months → ● → Yes → ●

Tasks

Task List

Hiding tasks	 Tools → ● → In PIM/Life menu, Tasks → Select task → □ → Edit → ● → Secret:
	⇒ • On ⇒ • •

Saving/Editing Tasks	
Editing tasks	● Tools ● In PIM/Life menu, Tasks ■ Select task ■ □ Edit ■ ● Select item ■ Edit in the same manner as saving tasks ■ □
Setting priority	● Tools ● In PIM/Life menu, Tasks ● Select task ● Delet Priority: ● Select priority: ● Select priority
	Start Here ● → Tools → ● → In PIM/Life menu, Tasks → ● → Select task → ⑤ → Edit → ● → Alarm: → ● → See below
Changing Alarm tone/video & duration	Alarm Tone/Video Assign Tone/Video: Select folder Select tone/file Select start point if required.
	Duration Duration: Select time Select
Changing Alarm volume	● * Tools * • * In PIM/Life menu, Tasks * • * ② * Alarm Settings * • * Alarm Volume: • • * Adjust level * •

Selecting Vibration option	 Tools In PIM/Life menu, Tasks In PIM/Life men
	Start Here
	Setting Alarm Tone to Control Illumination Switch On/Off
Changing illumination settings	Changing Illumination Pattern Pattern/Color → ● → Select pattern → ● → Select color → ● → ② Light color is unselectable for some patterns.
	Changing Key Illumination Pattern Key Pattern
	Disabling Illumination Switch On/Off → ● → Off → ● → ∞
Sounding Alarm tone even in Manner mode	 Tools In PIM/Life menu, Tasks In a settings In a

■ Managing Tasks

Searching tasks	Start Here → Tools → In PIM/Life menu, Tasks → □ → Find → See below
	By Part of Subject By Subject
	By Due Date By Due Date
Sorting tasks by priority	→ Tools → ● → In PIM/Life menu, Tasks → → □ → Sort → ● → Priority → ●
Checking memory status	 Tools → ● → In PIM/Life menu, Tasks → → □ → Memory Status → ●
Deleting all tasks	● Tools ● ● In PIM/Life menu, Tasks → ● □ Delete ● ● All Tasks ● ● Yes ●

Alarms	
Editing entries	 Tools In PIM/Life menu, Alarms Select entry Select item Edit in the same manner as saving entries
Saving entry name	● * Tools * • In PIM/Life menu, Alarms • • Select entry * • * Subject: * • * Enter name * • * Enter name * • *
Changing Alarm tone/video	
	Using Preset Tone or Data Folder File Select folder
	Using Customized Screen Tone/Video Customized Screen
Setting handset to vibrate at Alarm Time	● Tools ● ● In PIM/Life menu, Alarms ● Select entry ● Vibration: ● On or Link to Sound ● ● ⑨ • Select Link to Sound to allow compatible SMAF files to control vibration.

	Start Here ● → Tools → ● → In PIM/Life menu, Alarm → ● → Select entry → ● → Effect Illumination: → ● → See below
	Setting Alarm Tone to Control Illumination Switch On/Off → ● → Link to Sound → ● → ② → ②
	Changing Illumination Pattern
Changing	Pattern/Color ⇒ ● Select pattern ⇒ ● ⇒
illumination	Select color ⇒ ● ⇒ ∞ ⇒ ∞
settings	Light color is unselectable for some patterns.
	Changing Key Illumination Pattern
	Key Pattern → ● → Select pattern → ● → ♡ → ♡
	 Regardless of Key Pattern setting, ringtones control illumination when Switch On/Off is set to Link to Sound.
	Disabling Illumination
	Switch On/Off \Rightarrow \textcircled{o} \Rightarrow Off \Rightarrow \textcircled{v} \Rightarrow \textcircled{v}
Sounding Alarm	● → Tools → ● In PIM/Life menu, Alarms
tone even in	◆ ◆ Settings ◆ ● ◆ For Manner Mode ◆
Manner mode	● → Ring → ● → Yes → ●
Activating Alarm	● → Tools → ● In PIM/Life menu, Alarms
based on World	→ ● Settings → ● Link to World Clk →
Clock time	● → On → ●

Wakeup TV	
Editing entries	● → Tools → ● In PIM/Life menu, Wakeup TV → ● → Select entry → ● → Select item → ● Edit in the same manner as saving entries → ⊙
Changing Alarm tone/video	Start Here
	Using Preset Tone or Data Folder File Select folder
	Using Customized Screen Tone/Video Customized Screen
Changing illumination settings	Start Here
	Setting Alarm Tone to Control Illumination Switch On/Off Link to Sound Link to Sound
	Changing Illumination Pattern Pattern/Color → ● → Select pattern → ● → Select color → ● → ♡ → ♡ • Light color is unselectable for some patterns.
	Changing Key Illumination Pattern Key Pattern → ● → Select pattern → ● → ∞ → ∞ • Regardless of Key Pattern setting, ringtones control illumination when Switch On/Off is set to Link to Sound.
	Disabling Illumination Switch On/Off \Rightarrow \bullet \Rightarrow \circ \Rightarrow \circ

Sounding Alarm tone even in Manner mode	Tools →
Household Ac	counts
Renaming icon labels	Start Here
	Shops Shop → ● → Select icon → ② → Enter name • ●
	Payment Methods Paid → ● → Select icon → 圖 → Enter name → ●
	Categories Category Change
Importing Household Accounts data	● * Tools * ● * In PIM/Life menu, Household Accounts * ● * ② * Import AI • ● * Select file * ● * Yes * ● • Current Household Accounts data is overwritten.
Exporting Household Accounts data	● Tools ● ● In PIM/Life menu, Household Accounts ● ● ② ► Export AI. ● ● Yes ● ● • Data is exported as a CSV file and saved to handse Data Folder (Other Documents). • Files are saved to Memory Card, if inserted.

Calculator

Copying calculation results	While result appears,
Changing exchange rate for currency conversion	● * Tools * ● * In PIM/Life menu, Calculator * ● * ② * Money Converter * ● * Exchange Rate * ● * Domestic or Foreign * ● * Enter rate * ●
Converting currencies	● Tools ● In PIM/Life menu, Calculator ● Enter amount of money ■ Money Converter ● To Domestic or To Foreign ● ● • Set Exchange Rate first.

Expenses Memo

Changing Category of saved entry	● * Tools * ● In PIM/Life menu, Expenses Memo * ● * Select list * ● * Select entry * ● * Select Category * ●
Changing amount	● * Tools * ● In PIM/Life menu, Expenses Memo * ● * Select list * ● * Select entry * ② * Change Amount * ● * Edit * ●
Renaming Categories	● Tools ● ● In PIM/Life menu, Expenses Memo ● ■ Edit Category ● ■ Select Category ● ■ Enter name ●

Osaifu-Keitai®

Enabling to view e-money balances	● Tools ● In PIM/Life menu, Osaifu-Keitai ● IC Card Settings ● Balance Info ● <mp> Empty> ● Lifestyle-Appli or S! Appli ● Select application ● ● For use with compatible Lifestyle-Applications. ● Start Lifestyle-Appli once before adding it to Balance Info list.</mp>
Moving applications up/down Balance Info list	● Tools ● In PIM/Life menu, Osaifu-Keitai ● IC Card Settings ● Balance Info ● Select application ● Move ● Select target location ●
Removing applications from Balance Info list	● * Tools * ● In PIM/Life menu, Osaifu-Keitai * ● * IC Card Settings * ● * Balance Info * ● * Select application * ⑤ * Delete * ●
Customizing handset response to reader/writer commands	● Tools ● In PIM/Life menu, Osaifu-Keitai ● IC Card Settings ● Interface Settings ● Select item ● Off ●
Opening IC Card properties	● ★ Tools ★ ● In PIM/Life menu, Osaifu-Keitai ★ ● ★ IC Card Settings ★ ● ★ IC Card Status ★ ●

Changing IC Card Lock notice recipient	Start Here
	Disabling Notice Off
Changing required Missed Call count for Call Remote Lock	 Tools In PIM/Life menu, Osaifu-Keitai IC Card Settings Remote Lock Call Remote Lock Count for Lock Enter Missed Call count ✓
Restoring default Osaifu-Keitai® settings	● Tools ● In PIM/Life menu, Osaifu-Keitai ● IC Card Settings ● Reset Settings ● Enter Handset Code ● Yes ●

Simulated Call	
Starting via Simulated Call menu	Tools In PIM/Life menu, Simulated Call Receive Simulated Call Simulated Call regardless of Receive Timing setting. Settings remain even after starting Simulated Call during setup.
Clearing caller information	● * Tools * ● In PIM/Life menu, Simulated Call * ● * Set Caller * ● □ * Yes * ● * ♡ * ♡
Overriding Silent volume setting	● Tools ● ● In PIM/Life menu, Simulated Call ● ● For Silent Mode ● ● Ring ● ● Yes ● ● ♡
Countdown Timer	
	Start Here

Illumi. ⇒ ● > See below **Changing Illumination Pattern**

Select color ⇒ ● 🎔

Disabling Illumination

Changing

illumination settings

Pattern/Color ⇒ ● Select pattern ⇒ ● ⇒

Key Pattern ⇒ ● ⇒ Select pattern ⇒ ● ⇒ 🕏

• Light color is unselectable for some patterns. Changing Key Illumination Pattern

Switch On/Off \Rightarrow \bigcirc \Rightarrow Off \Rightarrow \bigcirc \Rightarrow \bigcirc



Hour Minder	
Changing Hour Minder tone/video	● * Tools * • • • • Clock/Gauge * Hour Minder * • • Advanced * • Assign Tone/Video: • • • Select folder * • • • • Select tone/file * • • • • • • • • • • • • • • • • • •
Setting handset to vibrate at Hour Minder Time	● Tools ● ● ◇ Clock/Gauge ● Hour Minder ● Advanced ● Vibration: ● On or Link to Sound ● ● ♡ ♥ • Select Link to Sound to allow compatible SMAF files to control vibration.
	Start Here
Changing illumination settings	(y) ★ (y) ★ (y) Changing Illumination Pattern Pattern/Color ★ (a) ★ Select pattern ★ (b) ★ Select color ★ (b) ★ (y) ★ (y) Light color is unselectable for some patterns.
Schrigs	Changing Key Illumination Pattern Key Pattern
	Disabling Illumination Switch On/Off ⇒ ● → Off ⇒ ● →

Sounding Hour Minder tone even in Manner mode	● Tools • • • • Clock/Gauge Hour Minder • • Advanced • • For Manner Mode: • • Ring • • Yes • • •
Activating Hour	● Tools ● ● ⊖ Clock/Gauge Hour
Minder based on	Minder ● Advanced ● Link to
World Clock time	World Clk: ● ● On ● ⊕ ⊕ ⊕

Pedometer	
Using Pedometer Calendar	● * Tools * ● * • Clock/Gauge * Pedometer * ● * • Select date * ● • Degree of achievement appears. • Press ** or ##3 to view previous or next month.
Checking accumulated data	● Tools ● ● ○ Clock/Gauge ► Pedometer ● ● ○ Accumulated Data ● ○ Change in body information is reflected in the data.
Resetting accumulated data	● Tools ● ● ○ Clock/Gauge Pedometer ● ● □ Accumulated Data ● □ Reset Walk Data ● Yes ● • Averages are also reset.
Setting daily step count reset time	● Tools ● ⊖ Clock/Gauge Pedometer ● ● ⊜ Settings ● ● Count Reset Time ● ● Enter time ● ● Yes ● ●

Customining	Changing Tone Goal Sound
Customizing achievement notice	Changing Tone Volume Goal Volume
	Selecting Vibration Option Vibration
	Changing Duration Duration Select time For custom Duration, select Other and press .

S! GPS Navi

Sending current location via mail	● Tools ● ● ○ Clock/Gauge S! GPS Navi ● Location Mail ● Positioning complete ● Complete message ● ♡ ● When accuracy level is 1 or 2, choose No and press ● after positioning, then complete message.
	Start Here
Changing map	<not set=""> → ● Description = The set of the</not>
source URL	Setting Destination URL Select URL
	Viewing/Editing/Deleting URLs
	Select URL ⇒ 🖾 ⇒ Display, Edit or Delete ⇒ •
	Follow onscreen prompt.

Disabling positioning	Tools
Selecting Location Information transmission option	● Tools ● → ⊖ Clock/Gauge → S! GPS Navi ● ● NAVI Settings ● ● Send Location Info ● ● Select option ●
	Start Here ● → Tools → ● → ⓒ Clock/Gauge → S! GPS Navi → ● → My Location List or Location Logs → ● → Select entry or record → See below
	Opening Map
Using My Location & Location Log	Showing Routes via Navi Appli (a) ⇒ Go to ⇒ (b) ⇒ Yes ⇒ (c) Follow onscreen instructions.
	Inserting into Message Text (a) ** As Msg. Text ** (a) ** Complete message (b) ** (b)
	Saving to Phone Book (a) ⇒ Save to Ph.Book (b) ⇒ As New Entry ⇒ (c) → Complete other fields (c) → To add to an existing entry, select As New Detail.
Saving Location Log records to My Location	Navi ● Description Select record Description Select Name Enter name Description
Deleting Location Log records	 Tools Olock/Gauge S! GPS Navi Location Logs Select Pelete or Delete All Pelete Omit record selection step when deleting all records.



Suppressing	
Information window	● → Tools → ● → ۞ Clock/Gauge → S! GPS Navi → ● → NAVI Settings → ● → Inform
after sending	Navi ⇒ ● ⇒ NAVI Settings ⇒ ● ⇒ Inform
Location Information	Location ⇒ ● Do not Show ⇒ ●
automatically	

Notepad

	Start Here ● → Tools → ● → ⊙ Doc./Rec. → Notepad → ● → Select entry → □ → See below
Editing Notepad	Editing Text Edit Text ● Edit ●
	Changing Category Change Category Select Category
Searching text within all entries	● * Tools * ● * ⊙ Doc./Rec. * Notepad • • Select entry * ○ * Search * • • Enter text * •
Inserting Notepad text into message text	● Tools ● ⊖ Doc./Rec. Notepad ● Select entry ● Send ● As Message Text ● S! Mail or SMS ● Complete message ⊕ ● SI Mail Composition window opens automatically depending on character count.
Sending entries via S! Mail	● * Tools * ● * ◆ Doc./Rec. * Notepad • • Select entry * ⊜ * Send * ● * Via Message * • Complete message * •
Creating text files	 Tools O Doc./Rec. Notepad O Select entry O Setting/Manage O Create Text File O Enter name O Save here

Importing text files	Tools Doc./Rec. Notepad Select entry Select file Import Text File Select file Select file
Checking memory status	● Tools • • ⊙ Doc./Rec. Notepad • • Select entry • □ Setting/Manage • • Memory Status • •
Opening properties	 Tools → ⊙ → ⊙ Doc./Rec. → Notepad Select entry → ⊙ → Details → ⊙

Voice Recorder

Voice Recorder	
Saving longer recordings	● Tools ● ● Doc./Rec. Voice Recorder ● ● ● Record Time ● ● Extended Voice ● ● ● Recording starts ● Recording ends • Insert Memory Card to record in Extended Voice mode. (Recording is saved automatically.)
Sending Voice files via S! Mail	● Tools ● ● O Doc./Rec. Voice Recorder ● ● ● Recording starts ● ■ Recording ends ■ Save and Send ■ ■ Complete message ♥ ♡ ■ Available in For Message mode.
Switching storage media	● Tools ● Doc./Rec. Voice Recorder ● © Save Recording to ● ● Select option ● ● • Available in For Message mode. • Set to Ask Each Time to select media after every recording.

Scan Barcode	
	Start Here In a text entry window, (a) ⇒ Scan ⇒ (b) ⇒ Scan Code ⇒ (b) ⇒ Frame barcode in center of Display ⇒ (c) ⇒ See below
Scanning during text entry	Pasting All Scan Results
	Pasting a Part of Scan Results (a) ⇒ Select first character → ● → Highlight text range → ●
Scanning continuously	● Tools ● ● Doc./Rec. Barcode/ Scan ● Scan Barcode ● ⑤ ⑤ Continuous Scan ● On ● Frame barcode in center of Display ● Choose Yes to continue scanning or No and press ● to view scan results.
Reading saved barcode images	● * Tools * ● * ⊙ Doc./Rec. * Barcode/ Scan * ● * Open Barcode * ● * Select file * ●
Saving scan results	● Tools ● O Doc./Rec. Barcode/ Scan ● Scan Barcode ● Frame barcode in center of Display ● © Save ● ●
Saving to Notepad	● * Tools * ● * ◆ Doc./Rec. * Barcode/ Scan * ● * Scan Barcode * ● * Frame barcode in center of Display * ● * ② * Notepad * ●

Saving linked info to Phone Book	● Tools ● O Doc./Rec. ■ Barcode/ Scan ● Scan Barcode ● Frame barcode in center of Display ● Select number or mail address ● Save to Ph.Book ● As New Entry ● Complete other fields ● O ■ To add to an existing entry, select As New Detail. ● When MEMORY: appears in scan results, press ● to enter the items underlined with a dotted line automatically in Phone Book entry window.
Opening saved scan results	Tools Doc./Rec. Barcode/ Scan Scanned Results Select file Select a file and press to rename files, open properties or delete files. Some files may not open.
	Start Here ● → Tools → ● → Doc./Rec. → Barcode/Scan → ● → Scan Barcode → ● →
	Frame barcode in center of Display
Using linked info	See below Dialing Numbers

Using images as Wallpaper	● Tools ● Onc./Rec. Barcode/ Scan ● Scan Barcode ● Frame barcode in center of Display ● Select image ② Set as Wallpaper ● Vertical or Horizontal ● ● • For images smaller or larger than Display, Wallpaper Display options appear; follow onscreen prompts.
Saving images & melodies	● * Tools * ● * ⊙ Doc./Rec. * Barcode/ Scan * ● * Scan Barcode * ● * Frame barcode in center of Display * ● * Select file * ⑤ * To Data Folder * ●
Opening or playing files	● Tools ● ● ⊙ Doc./Rec. ▶ Barcode/ Scan ● ● Scan Barcode ● ● Frame barcode in center of Display ● ● Select file ● ●
Using images for System Graphics	● Tools ● Doc./Rec. ■ Barcode/ Scan ● Scan Barcode ● Frame barcode in center of Display ● Select image ● As System ● Select item ● Specify image area ● Some images may be usable without specifying image area.

Pasting to message text	Start Here ● → Tools → ● → Doc./Rec. → Barcode/Scan → ● → Scan Barcode → ● → Frame barcode in center of Display → ● → □ → Send Message → ● → See below
	All Text ● → S! Mail or SMS → ● Complete message → ● S! Mail Composition window opens automatically depending on character count.
	Selected Text ③ ◆ Select first character ◆ ● → Highlight text range ◆ ● ★ S! Mail or SMS ◆ ● ★ Complete message ◆ ♥ • S! Mail Composition window opens automatically depending on character count.
Copying text	Start Here ● → Tools → ● → ⊙ Doc./Rec. → Barcode/Scan → ● → Scan Barcode → ● → Frame barcode in center of Display → ● → See below
	Text ② → Copy → ● → Select first character → ● → Highlight text range → ●
	Number, Address or URL Select number, mail address or URL → ⑤ → Copy Telephone, Copy Address or Copy URL ● ⑥

Scan Card

Saving to Notepad	● Tools ● ● ⊖ Doc./Rec. ■ Barcode/ Scan ● ● Scan Card ● ● Frame card in center of Display ● ● ● ⊜ ● Notepad ● ●
Pasting to message text	Start Here ● → Tools → ● → ⊖ Doc./Rec. → Barcode/Scan → ● → Scan Card → ● → Frame card in center of Display → ● → ● → © → Send Message → ● → See below
	All Text
	Selected Text ③ Select first character → ● → Highlight text range → ● → S! Mail or SMS → ● Complete message → ⊙ • S! Mail Composition window opens automatically depending on character count.
Copying text	Tools ● → Doc./Rec. Barcode/ Scan ● Scan Card ● Frame card in center of Display ● ● ● □ Copy ● Select first character ● Highlight text range ●

Scan Text

Scanning and pasting during text entry	In a text entry window, Scan * Scan
Scanning more text	● Tools ● ● Doc./Rec. Barcode/ Scan ● Scan Text ● Frame text in center of Display ● Select line ● ● Continue Part or Scan More ● Select Continue Part to enter additional text or Scan More to enter text after a line break.
Saving scan results	● * Tools * ● * ❖ Doc./Rec. * Barcode/ Scan * ● * Scan Text * ● * Frame text in center of Display * ● * Select line * ● * ● * ② * Save * ●
Saving linked info to Phone Book	● Tools ● Doc./Rec. Barcode/ Scan ● Scan Text ● Frame text in center of Display ● Select line ● Select number or mail address ● Save to Ph.Book ● As New Entry ● Complete other fields ▼ To add to an existing entry, select As New Detail.
Opening saved scan results	● → Tools → ● → ⊙ Doc./Rec. → Barcode/ Scan → ● → Scanned Results → ● → Select file → ● • Select a file and press ⑤ to rename files, open properties or delete files. • Some files may not open.

	<u>- </u>
Using linked info	Start Here
	Dialing Numbers Select phone number ● ●
	Sending Messages Select mail address → ● Complete message → ②
	Accessing Internet Sites Select URL
	Start Here
	line → ● → ● ⇒ Send Message → ● ⇒ See below
Pasting to message text	
•	Nee below All Text Image: Self state of the stat
•	➤ See below All Text → S! Mail or SMS → ● Complete message → ⊙ S! Mail Composition window opens automatically depending on character count.
•	See below All Text S! Mail or SMS
•	⇒ See below All Text

Copying text	Start Here ● → Tools → ● → ⊙ Doc./Rec. → Barcode/Scan → ● → Scan Text → ● → Frame text in center of Display → ● → Select line → ● → ● → See below
	Text ⑤ → Copy → ⑥ → Select first character → ⑥ → Highlight text range → ⑥
	Number, Address or URL Select number, mail address or URL © Copy Telephone, Copy Address or Copy URL © • •

Kanji/English Grabber

	In a text entry window, ☺ 🏓 Scan 🐤 🍑 🖈
	Kanji/English Grabber ⇒ ● Frame word in
entry	Loupe ⇒ ● ⇒ Scan results appear ⇒ ●

Osaifu-Keitai®



Cannot use Osaifu-Keitai® (S! FeliCa)

· Battery may be low. Charge battery or install a charged battery.



Recognition via reader/writer takes time

• Check Dogo area. Foreign articles can block/hamper recognition.



Call Remote Lock does not activate even after specified number of Missed Calls

- · Missed Call count is reset by calls from other numbers. If series is interrupted, start over from the beginning.
- When Call Forwarding is active, Missed Calls may not be recorded.

Wakeup TV



TV does not activate with specified channel

• If Wakeup TV Time arrives while TV is active, channel does not switch to the specified one.

Voice Recorder



Cannot record properly

• If incompatible microphone is connected, recording may fail.



Noise/skipping occurs

 Avoid shocks to handset while recording; may cause noise or skipping.



Recording takes time to start

• Recording window may take longer to open as more Voice files are saved on Memory Card.

Scanning Barcode/Card/Text



Cannot read barcodes properly

- Scan may fail if barcode is dirty or unclear.
- · Scan may fail if barcode is scanned under inadequate light.
- · Scan may fail if multiple barcodes are captured at one time.



Cannot read barcodes during text entry

· Scanning is not available during calls or when mobile camera is active.



Cannot read split QR Codes in **Data Folder automatically**

• When scan fails, follow onscreen instructions and select next barcode image manually.



Cannot scan business cards properly

- Scan fails if business card is printed in light-colored text on a dark background. handwritten or printed in casual/ decorative fonts, decorated with a background pattern, or designed with both vertical and horizontal text.
- · Scan may fail if business card is printed in light-colored text on a light background, printed in italics or extremely small fonts, decorated with a logo or logo-like text, printed on a glossy paper or other material, or dirty/folded.



Cannot scan text properly

- Scanning over 35 characters at one time may yield poor results.
- In Line mode, adjust to frame text in []. Letters at the ends may be distorted.

