9

**Widgets &
Entertainment**

Customizing Standby Display (Japanese)

Paste various widgets (applications) to Standby to access/activate information/functions immediately from Standby.

S! Quick News & S! Friend's Status Widget

Widget

XX/XX/XX(Mon)
15:05

Obtaining Widgets

1 ● ➜ *Widget* ➜ ●

Mobile Widget Menu

2 *Widget Store* ➜ ●
● Follow onscreen instructions.

Installing Widgets
● Some widgets may need to be installed manually; follow these steps:
[Mobile Widget Menu] *Widget Contents* ➜ ● ➜ Select widget ➜
⊙ ➜ *Install* ➜ ● ➜ *Yes* ➜ ●

Activating Widgets Not Saved in Standby
[Mobile Widget Menu] *Widget Contents* ➜ ● ➜ Select widget ➜
● ➜ ●

Saving Widgets to Standby

1 ☉

2 ☉ Select 🔲 (OPEN) ➜ ●

Widget Tab
Standby Shortcut Tab

3 Select widget ➜ ●
● Corresponding icon appears.

4 ☉ Specify target location ➜ ●

Using Pointer
● After ❶, Long Press ⓨ to activate pointer navigation; select widgets, etc.
● To cancel pointer navigation, Long Press ⓨ.

Advanced

●Opening properties ●Canceling automatic updates ●Receiving updates automatically while outside Japan ●Hiding confirmation outside Japan ●Disabling cookies ●Deleting cookies (**P.9-16**)

Using Widgets

1 � ➡ ⊙ **Select widget** ➡ ●

2 ●
 - Widget activates; follow onscreen instructions.

Using Sheets

Paste widgets and Standby Shortcuts on each sheet; toggle sheets to use them.

 Saving Widgets on Other Sheets

1 **In Mobile Widget menu,**
 Widget Contents ➡ ●

2 **Select widget** ➡ ⓧ-ル

3 *Paste to Standby Display* ➡ ●

4 **Select sheet** ➡ ●

5 **Specify target location** ➡ ●

Toggling Sheets

1 ⓢ ➡ ⓨ

 ↓ ⓨ

シート2

 - To toggle further, press ⓨ or マナー.
 - Sheet name appears at the top, then disappears.
 - Save widgets as needed; corresponding icons appear on the current sheet.

Using Locked Sheets
 ⓢ ➡ **Select** 🔒 ➡ ● ➡ **Enter Handset Code** ➡ ●

Widgets & Entertainment

9

Advanced

🔧 ●Logging in to Yahoo! JAPAN ●Moving widgets ●Slowing pointer speed ●Editing sheet names ●Locking sheets (And more on **P.9-16** - **9-17**)

9-3

Removing Widgets from Standby

1. ⑤ ➡ ⟡ Select widget ➡ ⊛

2. *Operation* ➡ ●

 | Operation |
   |---|
   | Change Layout |
   | Remove |
   | To Front |
   | To Back |
   | Update View |

3. *Remove* ➡ ●

4. *Yes* ➡ ●

Deleting Widgets

1. **In Mobile Widget menu,**
   Widget Contents ➡ ●

2. **Select widget ➡** ⊛
   - *S!速報ニュース/S!ともだち状況* cannot be deleted.

3. *Delete* ➡ ● ➡ *Yes* ➡ ●

Deleting All Widgets
In 2, *S!速報ニュース/S!ともだち状況* ➡
⊛ ➡ *Delete All* ➡ ● ➡ Enter
Handset Code ➡ ● ➡ *Yes* ➡ ●
- If there is a widget saved in Standby, a confirmation appears; follow onscreen prompt.

Using S! Quick News &
S! Friend's Status Widget

841SH s is preloaded with *S!速報ニュース/S!ともだち状況* (S! Quick News & S! Friend's Status widget) that shows S! Quick News and S! Friend's Status information in Standby.

【S!速報ニュースとは?】 ─ S! Quick News & S! Friend's Status Widget

View Settings

■ **Setting View Pattern**

1. ⑤ ➡ ⟡ Select S! Quick News & S! Friend's Status widget ➡ ⊛

2. *Settings* ➡ ● ➡ *Pattern Setting* ➡ ●

3. Select item ➡ ● (☑/☐) ➡ ⟨Y⟩

■ **Switching View**

1. ⑤ ➡ ⟡ Select S! Quick News & S! Friend's Status widget ➡ ⊛

2. *Operation* ➡ ● ➡ *Switch Pattern* ➡ ●
   - Repeat the steps above to switch the view.

Widgets & Entertainment

9

9-4

Receiving Content Updates (Japanese)

View content updates or breaking news.
Packet transmission fees apply.

Registering S! Quick News Items

1 **●** ➡ *Entertainment* ➡ **●**
➡ *S! Quick News* ➡ **●**

2 *S! Quick News List* ➡ **●**

> ▒Ⅲ   15:05 ▢▢
> 🔲 登録はこちら   ⬚
> 📱S!速報ニュースとば ▸
> ー <未登録>
> ー <未登録>
> ー <未登録>

S! Quick News List

3 *登録はこちら* ➡ **●** ➡ *Yes*
➡ **●**
● Handset connects to the Internet.

4 **Select item** ➡ **●**
● Follow onscreen instructions.

Opening Information

1 **In S! Quick News List,
select item** ➡ **●**
● Title list appears.

2 **Select title** ➡ **●**
● Information appears.
● Press 🔙 to return to title list, or 🅨 to
open next title.

Updating Items Manually
[S! Quick News List] Select item ➡
🅨 ➡ *更新* ➡ **●** ➡ *一件* or *全件* ➡ **●**

Indicators

📰	Unread Special news	📄	Unread General news
📰	Read Special news	📄	Read General news
📰	Unread News Flash	✖	Auto update disabled
📰	Read News Flash		

Advanced

  ● **Updating S! Quick News List automatically** ● **Checking update schedule** ● **Deleting S! Quick News items** ● **Resetting S! Quick News List** ● **Changing background image** ● **Accessing source sites** ● **Disabling image download** (**P.9-18**)

S! Information Channel & Weather Indicator (Japanese)

Subscribe to Japanese mobile periodicals that download to handset automatically; use Weather Indicator as needed.
Packet transmission fees apply.

Service Registration & Content Subscription

1. ● ➡ *Entertainment* ➡ ●
   ➡ *S! Information Channel/ Weather* ➡ ●

   > "Tll   15:05▭▭
   > S!Info. Channel
   > What's New
   >
   > Back Issue
   >
   > Registration/C…

   S! Information Channel Menu

2. *Registration/Cancel* ➡ ●
   - Handset connects to the Internet. Follow onscreen instructions.

New Received Information

Information window opens for new S! Information Channel info delivery.

1. **While Information window appears,** *S! Info. Channel* ➡ ●
   - S! Information Channel page opens. Follow onscreen instructions.
   - S! Information Channel page handling is similar to that of Yahoo! Keitai.

2. 🔚 ➡ **Standby returns**

   Opening Unread Latest Issue
   [S! Information Channel Menu] *What's New* ➡ ●
   Opening Back Issues
   [S! Information Channel Menu] *Back Issue* ➡ ● ➡ Select date ➡ ●

Using Weather Indicator

After S! Information Channel registration, local area weather indicator appears in Standby.

Manual Update
[S! Information Channel Menu]
Weather Indicator ➡ ● ➡ *Manual Update* ➡ ● ➡ *Yes* ➡ ●

Widgets & Entertainment

9

Advanced

●Suppressing Information window for new received info ●Changing Display Size ●Changing scroll unit ●Copying text ●Hiding Weather Indicator in Standby ●Canceling Weather Indicator automatic updates ●Suppressing Information window for weather updates (And more on **P.9-18** - **9-19**)

Downloading Content (Japanese)

Download media content via Yahoo! Keitai.

Via S! Contents Store

1   ● ➡ *Entertainment* ➡ ●

> 📶‖‖   15:05 ▭
> Entertainment
> 📡 S! Informati…
> ◔ S! Quick News
> 📷 Free Contents
> 📺 S! Contents …
> 🖥 S! Friend's …
> ◔ S! Circle Ta…
> 📖 Blog Tool
> ◎ BookSurfing

Entertainment Menu

2   *S! Contents Store* ➡ ●
 ● Handset connects to the Internet.
   Follow onscreen instructions.

Via Free Content Providers

Download free Graphic Mail templates,
e-Books, games, etc.
Content downloads are free, however,
they require Internet connection incurring
packet transmission fees.

1   **In Entertainment menu,**
 Free Contents ➡ ●

2   Select provider ➡ ●
 ● Handset connects to the Internet.
   Follow onscreen instructions.

Reading e-Books (Japanese)

Downloading e-Books

1 ● ➡ *Entertainment* ➡ ●

```
Entertainment
📡 S! Informati…
🔊 S! Quick News
📖 Free Contents
```
Entertainment Menu

2 *S! Contents Store* ➡ ●
- Handset connects to the Internet. Follow onscreen instructions.
- Downloaded e-Books are saved to Data Folder (Books).

Note
- Alternatively, go to SH-web Mobile Internet site (*シャープ メーカーサイトSH-web* in Bookmarks; see **P.5-8**) for e-Books.

Downloading Free e-Books
   In 2, *Free Contents* ➡ ● ➡
   Tada-Hon or *Tada-Komi* ➡ ●
   ◼ Follow onscreen instructions.

e-Book Viewer

Read XMDF books and dictionary files. Some files may not be supported.

1 **In Entertainment menu,** *e-Book Viewer* ➡ ●
- e-Book Viewer starts. Refer to the e-Book Viewer help menu for operational instructions.

BookSurfing®

Download Contents Keys and read CCF files. Some files may not be supported.

1 **In Entertainment menu,** *BookSurfing* ➡ ●
- BookSurfing® S! Application starts. Refer to the BookSurfing® help menu for operational instructions.

Moving CCF Files via Memory Card
- When purchasing a new handset, move CCF files and retrieve Contents Keys to open the files. Some files may need to be re-downloaded.

Advanced

9-8

Using S! Friend's Status

Exchange current usage status, mood, etc. with compatible handsets.

- Save and organize members in Groups.
- S! Friend's Status requires a separate contract and basic monthly fee.
- Set IP Service Setting to *On*.
- Set Connection status to *Online*.

First S! Friend's Status Use

Follow these steps to register a number saved in Phone Book; Status, Availability and Comment are sent to the members.

```
 Ti                    15:05
      Yamada Takako
      私の状況
 ⚠ Online
 😊 ごきげん
 👤 Answer Status
 📷 Answer OK
 📧 Reply OK
 👥 Join OK
```

1. ● ➜ *Entertainment* ➜ ●
   ➜ *S! Friend's Status* ➜ ●

2. *Yes* ➜ ●

   ```
   A member is not
     registered.
   Register a member?
   ┌─────────────┐
   │     Yes     │
   ├─────────────┤
   │     No      │
   └─────────────┘
   ```

3. *Yes* ➜ ●

4. *Phone Book* ➜ ●

5. Select entry ➜ ● ➜ Select phone number ➜ ●
   - Omit number selection step if only one number is saved.

6. *Yes* ➜ ●
   - Registration request is sent to the number.

When Request is Accepted
- An acceptance notice arrives; My Status is sent and member's status appears on handset.

Direct Entry
In ④, *Add New Entry* ➜ ● ➜ Enter phone number ➜ ● ➜ ⑥

If IP Service Setting is *Off*
After ①, *On* ➜ ● ➜ Enter Handset Code ➜ ● ➜ *S! Friend's Status* ➜ ● ➜ From ②

Advanced

👆 ●Adding members ●Deleting members ●Moving members ●Renaming Groups ●Rejecting requests ●Updating manually ●Opening notices
●Sending My Details image (And more on **P.9-20** - **9-21**)

Widgets & Entertainment

9

9-10

Opening Member Status

1 ● ➡ *Entertainment* ➡ ●
➡ *S! Friend's Status* ➡ ●
➡ ⊙ Select Group

Group 1
私の状況 — My Status
Ueda Mikio
Kondo Koic... — Member Status

2 Select member ➡ ●
● Member status details appear.

When Cancellation Notice Arrives
● Member is deleted from S! Friend's Status member list.

Changing My Status

Follow these steps to change Status, Availability and Comment; new status is sent to the members.

1 ● ➡ *Entertainment* ➡ ●
➡ *S! Friend's Status* ➡ ●
➡ 私の状況 ➡ ●

Yamada Takako
私の状況
Online — Connection Status
☺ごきげん
Answer Status
Answer OK
Reply OK

My Status Window

2 Select Status, e.g., ごきげん
➡ ●

状況テンプレート
1 2 3 4
☺ごきげん
☺ハッピー
ひまー

Status Template Window

3 Select new Status ➡ ●

4 Select Availability, e.g.,
Answer OK ➡ ● ➡ Select
new Availability ➡ ●

5 *<Add Comment>* ➡ ● ➡
Enter text ➡ ●

6 ☞ ➡ Update starts

Changing Connection Status
[My Status Window] *Online* (or
Offline) ➡ ● ➡ Select status ➡ ●
Changing Status Icon/Label
[Status Template Window] Select
Status ➡ ☞ ➡ *Status Icon* or *Status
Label* ➡ ● ➡ Select Pictogram or
enter text ➡ ● ➡ ☞
Changing Availability Settings at Once
In 4, *Answer Status* ➡ ● ➡ Select
new Answer Status ➡ ● ➡ From 5
Editing My Status Name
[My Status Window] ☞ ➡ *Edit Name*
➡ ● ➡ Edit ➡ ●

Receiving Request from Unsaved Numbers

When a registration request arrives, a confirmation appears.

```
Accept the
registration
request from Ito
    Yes
    No
 ConfirmLater
```

1 *Yes* ➡ ●
   ● Acceptance notice is sent; the number is registered.

Rejecting
   In ①, *No* ➡ ● ➡ *Yes* ➡ ●
   ■ Rejection notice is sent; the number cannot be registered for 24 hours.
   ■ For *ConfirmLater*, Information window opens.

Creating Status Templates

Save custom combinations of Status Icon and Status Label to each template.

```
📶🔋         15:05
状況テンプレート
 1  2  3  4
😊ごきげん
😊ハッピー
🙀ひまー
```

1 In Status Template window, ✉ ➡ *New Entry* ➡ ●

2 Enter name ➡ ●

3 *<未定>* ➡ ●

4 *Status Icon* ➡ ● ➡ Select Pictogram ➡ ●

5 *Status Label* ➡ ● ➡ Enter text ➡ ● ➡ (Y?)

6 Repeat 3 - 5 ➡ (Y?) ➡ Saved

Saving to Data Folder
   [Status Template Window] ✉ Select template ➡ ✉ ➡ *Save to DF* ➡ ●
   ➡ *Save here* ➡ ●
Loading Templates via Data Folder
   [Status Template Window] ✉ ➡ *Add Template* ➡ ● ➡ Select template
   ➡ ●
Renaming Templates
   [Status Template Window] ✉ Select template ➡ ✉ ➡ *Edit Temp. Name*
   ➡ ● ➡ Enter name ➡ ●

Advanced

🔧 ●Resetting templates (**P.9-20**)

Using S! Circle Talk

Use handset like a walkie-talkie to speak to multiple parties simultaneously.

- A subscription to S! Friend's Status is required.
- Packet transmission fees apply during S! Circle Talk.
- Set IP Service Setting to *On*.

Registering Members

Follow these steps to register a number saved in Phone Book:

1. ● ➡ *Entertainment* ➡ ●
   ➡ *S! Circle Talk* ➡ ●
   - When registering a member for the first time, member registration confirmation appears. Choose *Yes* and press ●, then skip ahead to ❸.

2. *<Add New Entry>* ➡ ●

   ```
   ⁵ᵀₐₗ          15:05
     New Entry
   Individual
   Group
   ```

3. *Group* ➡ ● ➡ *Group Name:* ➡ ● ➡ Enter name ➡ ●

   ```
   ⁵ᵀₐₗ          15:05
    New 0 People
   Group Name:
   Friend
   No. 1:
   ```

4. Select number, e.g., *No.1:* ➡ ●

5. *Phone Book* ➡ ●

6. Select entry ➡ ● ➡ Select phone number ➡ ●

   ```
   ⁵ᵀₐₗ          15:05
    New 1 People
   Group Name:
   Friend
   No. 1:
   Ueda Mikio
   No. 2:
   ```

   - Omit number selection step if only one number is saved.
   - Repeat ❹ - ❻ to add members.

7. (Y!) ➡ Saved

Saving as Individuals
   In ❸, *Individual* ➡ ● ➡ ❹ - ❻
Saving from S! Friend's Status Member List
   In ❺, *Members List* ➡ ● ➡ Select member ➡ ● ➡ ❼
   ■ Omit ❼ when *Individual* is selected in ❸.
If IP Service Setting is *Off*
   After ❶, *On* ➡ ● ➡ Enter Handset Code ➡ ● ➡ *S! Circle Talk* ➡ ● ➡ From ❷

Widgets & Entertainment

9

Initiating S! Circle Talk

Follow these steps to send S! Circle Talk requests to members:
(First, set Connection status to *Online* (**P.9-10**).)

1. **● ➜ *Entertainment* ➜ ●
   ➜ *S! Circle Talk* ➜ ●**

   ```
   Til🖾 🖾        15:05📶
   C/T Member List
   ⇨ <Add New E…
   🖾Friend
   🖾Natsuyama …
   ```

2. **Select member or Group
   ➜ ●**

3. **● ➜ Transmission starts**
   ● S! Circle Talk starts when request is accepted by a receiver.
   ● Loudspeaker activates automatically.

Direct Entry
   Enter phone number ➜ ● ➜ *Call Circle Talk* ➜ ● ➜ ●

S! Circle Talk Operations

■ **Speaking**

1. **Press and hold 🖾 when
   Press and Hold 🖾 appears
   ➜ You have the floor**

   ```
   *Til🖾 🖾       📶15:05📶
   S!CircleTalk  2
   Ueda Mikio   🖾
   ```

   ```
   Press and Hold 🖾
   Add     🔏
   ```

   ● 🖾 *:My Turn* appears when you have the floor.

2. **Keep holding 🖾 to speak
   ➜ Release 🖾 ➜ Floor is
   released**
   ● Warning tone sounds before time limit.

Incoming Calls during S! Circle Talk
   ● Incoming calls are rejected. Set handset to exit S! Circle Talk to answer incoming calls as needed.
Canceling Loudspeaker
   During S! Circle Talk, ●
   ■ To reactivate, follow these steps:
      ● ➜ While message appears, ●

■ **Exiting S! Circle Talk**

1. **🖾 ➜ Connection ends**
   ● S! Circle Talk ends automatically when there is only one participant left, including yourself.

Rejoining S! Circle Talk
   ⊙/⊙ ➜ Select most recent S! Circle Talk record ➜ 🖾 ➜ *Rejoin CircleTalk* ➜ ●
   ■ Not available when S! Circle Talk has ended or maximum number of participants are already engaged.

Accepting S! Circle Talk Request

1. **While handset is ringing/
   vibrating, ● ➜ S! Circle
   Talk starts**
   ● Alternatively, press 🖾.
   ● S! Circle Talk Operations: left

Advanced

🔧 ●Disabling Loudspeaker ●Exiting S! Circle Talk for incoming calls (**P.9-21**)

9-13

Blogging

Save blog details to view or update blogs easily on handset.

Saving Blog Details

Setup for Posting via Mail

Follow these steps to save blog name and address for posting:

1. ● ➜ *Entertainment* ➜ ●
   ➜ *Blog Tool* ➜ ●

   ```
    Blog Tool            15:05
    ①Add New Entry
    ②Add New Entry
   ```
   Blog Tool Window

2. *Add New Entry* ➜ ●

   ```
    Blog Setting         15:05
    Blog Title

    Blog by send M…

    Refer/Send by …
   ```
   Blog Setting Menu

3. *Blog Title* ➜ ● ➜ Enter name ➜ ●

4. *Blog by send Mail* ➜ ●

   ```
    Blog Setting         15:05
    Blog's Email A…

    Blog's Title

    Blog's Text
   ```

5. *Blog's Email Address* ➜ ●
   ➜ Enter mail address ➜ ●

6. 戻る ➜ ⓨ

Saving Title/Text for Posts
After ⑤, *Blog's Title* or *Blog's Text*
➜ ● ➜ Enter title or text ➜ ● ➜ ⑥
■ Saved title/text is entered automatically when posting.

Setting Image Size for Posting
After ⑤, *Picture Size* ➜ ● ➜ Select size ➜ ● ➜ ⑥

Setup for Posting via the Internet

Save URL for Yahoo! Keitai or PC sites, or both.

1. In Blog Setting menu, *Blog Title* ➜ ● ➜ Enter name ➜ ●

2. *Refer/Send by Yahoo! Keitai* or *Refer/Send by PCSiteBrowser* ➜ ●

3. *Blog's URL* ➜ ● ➜ Enter URL ➜ ●

4. *Refer Blog's URL* ➜ ● ➜ Enter URL ➜ ●

5. 戻る ➜ ⓨ

Advanced

🔧 ●Editing entries ●Deleting entries (**P.9-21**)

Posting to Blogs

Complete setup for posting via mail/
Internet beforehand.

Posting via Mail

1. **In Blog Tool window, select entry ▶ ⦿**

2. *Blog by send Mail* ▶ ⦿
   ● S! Mail Composition window opens with address entered.
   ● Omit ❷ if no URL is saved for posting.

3. **Complete message ▶ ⓨ**

Posting via the Internet

1. **In Blog Tool window, select entry ▶ ⦿**

2. *Blog by send Browser* ▶ ⦿
   ● Page of URL saved in *Blog's URL* opens.
   ● Omit ❷ if no address is saved for posting.
   ● If PC Site Browser message appears, follow onscreen prompts.

When URLs for Yahoo! Keitai & PC Sites are Saved
After ❷, select browser ▶ ⦿

Opening Blog Page

1. **In Blog Tool window, select entry ▶ ⓨ**
   ● Page of URL saved in *Refer Blog's URL* opens.
   ● If PC Site Browser message appears, follow onscreen prompts.

When URLs for Yahoo! Keitai & PC Sites are Saved
After ❶, select browser ▶ ⦿

Mobile Widget

■ Managing

Opening properties	⦿ ➡ *Widget* ➡ ⦿ ➡ *Widget Contents* ➡ ⦿ ➡ Select widget ➡ ⊙ ➡ *Details* ➡ ⦿ ● Select widget other than *S!速報ニュース/S!ともだち状況*.

■ Settings

Canceling automatic updates	⦿ ➡ *Widget* ➡ ⦿ ➡ *Settings* ➡ ⦿ ➡ *Auto Refresh* ➡ ⦿ ➡ *Off* ➡ ⦿
Receiving updates automatically while outside Japan	⦿ ➡ *Widget* ➡ ⦿ ➡ *Settings* ➡ ⦿ ➡ *AutoConn. Abroad* ➡ ⦿ ➡ *On* ➡ ⦿
Hiding confirmation outside Japan	⦿ ➡ *Widget* ➡ ⦿ ➡ *Settings* ➡ ⦿ ➡ *Set Use Abroad* ➡ ⦿ ➡ *Off* ➡ ⦿
Disabling cookies	⦿ ➡ *Widget* ➡ ⦿ ➡ *Settings* ➡ ⦿ ➡ *Cookies* ➡ ⦿ ➡ *Disabled* ➡ ⦿
Deleting cookies	⦿ ➡ *Widget* ➡ ⦿ ➡ *Settings* ➡ ⦿ ➡ *Delete Cookies* ➡ ⦿ ➡ *Yes* ➡ ⦿

■ Operations in Standby

Selecting widget display option	⟳ ➡ ⊙ ➡ *Settings* ➡ ⦿ ➡ *Show Widget* ➡ ⦿ ➡ Select option ➡ ⦿ ● Choose *Off* to disable widget display even when ⟳ is pressed; re-enable via *Show Widget* in Standby Display menu.
Logging in to Yahoo! JAPAN	⟳ ➡ ⊙ ➡ *Yahoo!JAPAN LogIn* ➡ ⦿ ● Follow onscreen instructions. ● To log out, select *Yahoo!JAPAN LogOut* in the steps above.
Moving widgets	⟳ ➡ ✧ Select widget ➡ ⊙ ➡ *Operation* ➡ ⦿ ➡ *Change Layout* ➡ ⦿ ➡ Specify target location ➡ ⦿
Moving widgets to front/back	⟳ ➡ ✧ Select widget ➡ ⊙ ➡ *Operation* ➡ ⦿ ➡ *To Front* or *To Back* ➡ ⦿
Updating view	⟳ ➡ ✧ Select widget ➡ ⊙ ➡ *Operation* ➡ ⦿ ➡ *Update View* ➡ ⦿
Slowing pointer speed	⟳ ➡ ⊙ ➡ *Settings* ➡ ⦿ ➡ *Cursor Speed* ➡ ⦿ ➡ *Slow* ➡ ⦿

■ **Sheets**

Editing sheet names	Start Here ⑤ ➡ ⊙ ➡ *Settings* ➡ ● ➡ *Sheet Settings* ➡ ● ➡ *ChangeSheetName* ➡ ● ➡ **See below**
	Renaming Select sheet ➡ ● ➡ Enter name ➡ ●
	Resetting All Sheet Names ⊙ ➡ *Yes* ➡ ●
Locking sheets	Start Here ⑤ ➡ ⊙ ➡ *Settings* ➡ ● ➡ *Sheet Settings* ➡ ● ➡ *Set Sheet Lock* ➡ ● ➡ Enter Handset Code ➡ ● ➡ **See below**
	Activating Lock Select sheet ➡ ● ➡ *On* ➡ ●
	Changing Method for Temporary Access *Unlock Method* ➡ ● ➡ *No Password* ➡ ● ● Press ⑤, then select 🔒 and press ● to unlock sheet temporarily.

■ **Removing Widgets**

Removing multiple widgets at once	Start Here ⑤ ➡ ⊙ ➡ *Operate from List* ➡ ● ➡ *Remove* ➡ ● ➡ **See below**
	All Widgets *Remove All* ➡ ● ➡ Select sheet ➡ ⓨ ➡ *Yes* ➡ ●
	Selected Icons *Select & Remove* ➡ ● ➡ Select widget ➡ ● (✓) ➡ Complete selection ➡ ⓨ ➡ *Yes* ➡ ●

■ **S! Quick News & S! Friend's Status Widget (S! Quick News)**

Adding news items	⑤ ➡ Select S! Quick News & S! Friend's Status widget ➡ ⊙ ➡ *Operation* ➡ ● ➡ *Content Menu* ➡ ● ➡ *Add News* ➡ ● ➡ *S! Quick News List* ➡ ● ➡ *登録はこちら* ➡ ● ➡ *Yes* ➡ ● ➡ Select genre ➡ ● ➡ Select item ➡ ● ● Follow onscreen instructions.
Changing news scroll speed	⑤ ➡ Select S! Quick News & S! Friend's Status widget ➡ ⊙ ➡ *Operation* ➡ ● ➡ *Content Menu* ➡ ● ➡ *News Display* ➡ ● ➡ *News Speed* ➡ ● ➡ Select speed ➡ ●
Showing unread news only	⑤ ➡ Select S! Quick News & S! Friend's Status widget ➡ ⊙ ➡ *Operation* ➡ ● ➡ *Content Menu* ➡ ● ➡ *News Display* ➡ ● ➡ *Target News* ➡ ● ➡ *Unread Only* ➡ ●

■ **S! Quick News & S! Friend's Status Widget (S! Friend's Status)**

Assigning members	⑤ ➡ Select S! Quick News & S! Friend's Status widget ➡ ⊙ ➡ *Operation* ➡ ● ➡ *Content Menu* ➡ ● ➡ *Assign Member* ➡ ● ➡ Select category ➡ ● ➡ Select entry/member ➡ ● ➡ *(Empty)* ➡ ●
Managing members	Start Here ⑤ ➡ Select S! Quick News & S! Friend's Status widget ➡ ● ➡ ✧ Select member ➡ ⊙ ➡ *Operation* ➡ ● ➡ *Content Menu* ➡ ● ➡ **See below**
	Deleting Members *Delete* ➡ ● ➡ *Yes* ➡ ●
	Changing Member Order *Move* ➡ ● ➡ ⊙ (Up) or ⓨ (Down) ➡ ●
	Changing Member Icons *Change Icon* ➡ ● ➡ Select Pictogram ➡ ●

Widgets & Entertainment

9

9-17

S! Quick News

■ Opening/Updating Items

Updating S! Quick News List automatically	● ➡ *Entertainment* ➡ ● ➡ *S! Quick News* ➡ ● ➡ *Settings* ➡ ● ➡ *Automatic Update* ➡ ● ➡ Select item ➡ ● ➡ ● ➡ Select interval or choose *On* ➡ ● ● If a message appears after completing the steps above, press ●. ● When selecting an item set to *Off*, a message appears. ● When Special is set to *On*, items are updated every four hours. ● When General is set to *On*, items are updated once a day. ● Updating items may incur high packet transmission fees. ● Only available in Japan.
Checking update schedule	● ➡ *Entertainment* ➡ ● ➡ *S! Quick News* ➡ ● ➡ *Settings* ➡ ● ➡ *Check Schedule* ➡ ●
Deleting S! Quick News items	Start Here ● ➡ *Entertainment* ➡ ● ➡ *S! Quick News* ➡ ● ➡ *S! Quick News List* ➡ ● ➡ Select item ➡ ⊙ ➡ See below
	One Entry 一件 ➡ ● ➡ *Yes* ➡ ●
	All Entries 全件 ➡ ● ➡ Enter Handset Code ➡ ● ➡ *Yes* ➡ ●
Resetting S! Quick News List	● ➡ *Entertainment* ➡ ● ➡ *S! Quick News* ➡ ● ➡ *Settings* ➡ ● ➡ *Delete S! Quick News Lists* ➡ ● ➡ Enter Handset Code ➡ ● ➡ *Yes* ➡ ● ● Not available during automatic updates.

■ Other

Changing background image	● ➡ *Entertainment* ➡ ● ➡ *S! Quick News* ➡ ● ➡ *Settings* ➡ ● ➡ *Change Skin* ➡ ● ➡ Select pattern ➡ ●
Accessing source sites	● ➡ *Entertainment* ➡ ● ➡ *S! Quick News* ➡ ● ➡ *S! Quick News List* ➡ ● ➡ Select item ➡ ● ➡ Select title ➡ ● ➡ Select linked title ➡ ● ➡ *Yes* ➡ ●
Disabling image download	● ➡ *Entertainment* ➡ ● ➡ *S! Quick News* ➡ ● ➡ *Settings* ➡ ● ➡ *Show Image* ➡ ● ➡ *Off* ➡ ●

S! Information Channel

■ Receiving Information

Suppressing Information window for new received info	● ➡ *Entertainment* ➡ ● ➡ *S! Information Channel/Weather* ➡ ● ➡ *Notification* ➡ ● ➡ *Off* ➡ ●
Requesting re-delivery	● ➡ *Entertainment* ➡ ● ➡ *S! Information Channel/Weather* ➡ ● ➡ *Get Latest Contents* ➡ ● ➡ *Yes* ➡ ●

■ Information Pages

Changing Display Size	On a page, ⊙ ➡ *Settings* ➡ ● ➡ *Display Size* ➡ ● ➡ Select size ➡ ●
Changing scroll unit	On a page, ⊙ ➡ *Settings* ➡ ● ➡ *Scroll Unit* ➡ ● ➡ Select unit ➡ ●

Copying text	On a page, ⊙ ➡ *Copy Text* ➡ ⦿ ➡ Select first character ➡ ⦿ ➡ Highlight text range ➡ ⦿
Saving files to Data Folder	On a page, ⊙ ➡ *Save Items* ➡ ⦿ ➡ Select file ➡ ⦿ ➡ *Save* ➡ ⦿ ➡ Enter name ➡ ⦿ ➡ *Save here* ➡ ⦿ ● Some files are saved automatically.
Opening page properties	On a page, ⊙ ➡ *Details* ➡ ⦿

■ Weather Indicators

Checking weather forecast	⦿ ➡ *Entertainment* ➡ ⦿ ➡ *S! Information Channel/Weather* ➡ ⦿ ➡ *Weather Indicator* ➡ ⦿ ➡ *Weather* ➡ ⦿
Changing weather forecast page font size	On a page, ⊙ ➡ *Settings* ➡ ⦿ ➡ *Font Size* ➡ ⦿ ➡ Select size ➡ ⦿
Hiding Weather Indicator in Standby	⦿ ➡ *Entertainment* ➡ ⦿ ➡ *S! Information Channel/Weather* ➡ ⦿ ➡ *Weather Indicator* ➡ ⦿ ➡ *Settings* ➡ ⦿ ➡ *Standby Setting* ➡ ⦿ ➡ *Off* ➡ ⦿
Canceling Weather Indicator automatic updates	⦿ ➡ *Entertainment* ➡ ⦿ ➡ *S! Information Channel/Weather* ➡ ⦿ ➡ *Weather Indicator* ➡ ⦿ ➡ *Settings* ➡ ⦿ ➡ *Icon Update* ➡ ⦿ ➡ *Off* ➡ ⦿
Suppressing Information window for weather updates	⦿ ➡ *Entertainment* ➡ ⦿ ➡ *S! Information Channel/Weather* ➡ ⦿ ➡ *Weather Indicator* ➡ ⦿ ➡ *Settings* ➡ ⦿ ➡ *Weather Notif.* ➡ ⦿ ➡ *Off* ➡ ⦿

e-Books

Copying text	In open page, ⓨ ➡ *文字列をｺﾋﾟｰ* ➡ ⦿ ➡ Select first character ➡ ⦿ ➡ Highlight text range ➡ ⦿
Opening non-841SH s e-Books (Library)	⦿ ➡ *Entertainment* ➡ ⦿ ➡ *e-Book Viewer* ➡ ⊙ ➡ Select file ➡ ⦿ ● Some files may not open.
Using Library	[Start Here] ⦿ ➡ *Entertainment* ➡ ⦿ ➡ *e-Book Viewer* ➡ ⊙ ➡ See below **Adding Folders** ⊙ ➡ *New Folder* ➡ ⦿ ➡ Enter name ➡ ⦿ **Switching Folders** ⊙ ➡ *Switch Folders* ➡ ⦿ ➡ Select folder ➡ ⦿ **Renaming Folders/Files** Select folder/file ➡ ⊙ ➡ *Rename* ➡ ⦿ ➡ Enter name ➡ ⦿ **Moving Files** Select file ➡ ⊙ ➡ *Move* ➡ ⦿ ➡ Select folder ➡ ⦿ ➡ *Move here* ➡ ⦿ **Deleting Folders/Files** Select folder/file ➡ ⊙ ➡ *Delete* ➡ ⦿ ➡ *Yes* ➡ ⦿ **Opening File Properties** Select file ➡ ⊙ ➡ *Details* ➡ ⦿

S! Friend's Status

■ Members & Groups

Adding members	● ➡ *Entertainment* ➡ ● ➡ *S! Friend's Status* ➡ ● ➡ ⊙ Select Group ➡ ⊙ ➡ *Add Member* ➡ ● ➡ Select method ➡ ● ➡ Select entry or enter phone number ➡ ● ➡ *Yes* ➡ ●
Deleting members	● ➡ *Entertainment* ➡ ● ➡ *S! Friend's Status* ➡ ● ➡ ⊙ Select Group ➡ Select member ➡ ⊙ ➡ *Regist. Release* ➡ ● ➡ *Yes* ➡ ● ➡ *Yes* ➡ ● ● Cancellation notice is sent; deleted members cannot be re-registered for 24 hours.
Moving members	● ➡ *Entertainment* ➡ ● ➡ *S! Friend's Status* ➡ ● ➡ ⊙ Select Group ➡ Select member ➡ ⊙ ➡ *Change Group* ➡ ● ➡ Select target Group ➡ ●
Renaming Groups	● ➡ *Entertainment* ➡ ● ➡ *S! Friend's Status* ➡ ● ➡ ⊙ Select Group ➡ ⊙ ➡ *Edit Group Name* ➡ ● ➡ Enter name ➡ ●
Rejecting requests	Start Here ● ➡ *Entertainment* ➡ ● ➡ *S! Friend's Status* ➡ ● ➡ ⊙ ➡ *Settings* ➡ ● ➡ *Request Reply* ➡ ● ➡ See below **Rejecting Requests from Unsaved Numbers** *Confirm if Registered* ➡ ● ● Rejection notice is sent to rejected numbers automatically. **Rejecting All Requests** *Always Ignore* ➡ ● ● Rejection notice is sent to all requesters automatically.

■ Status & Availability

Saving custom Availability combinations	● ➡ *Entertainment* ➡ ● ➡ *S! Friend's Status* ➡ ● ➡ ⊙ *Settings* ➡ ● ➡ *Answer Status* ➡ ● ➡ *User Setting* ➡ ● ➡ Select type ➡ ● ➡ Select Availability ➡ ● ➡ ⓨ
Changing Status Icon Pictogram or Status Label description	● ➡ *Entertainment* ➡ ● ➡ *S! Friend's Status* ➡ ● ➡ ⊙ ➡ *Settings* ➡ ● ➡ *Status Setting* ➡ ● ➡ ⊙ Select template ➡ Select Status ➡ ● ➡ *Status Icon* ➡ ● ➡ Select Pictogram ➡ ● ➡ *Status Label* ➡ ● ➡ Enter text ➡ ● ➡ ⓨ

■ Status Templates

Resetting templates	Start Here ● ➡ *Entertainment* ➡ ● ➡ *S! Friend's Status* ➡ ● ➡ 私の状況 ➡ ● ➡ Select Status ➡ ● ➡ See below **One Template** ⊙ Select template ➡ ⊙ ➡ *Reset* ➡ ● ➡ *Yes* ➡ ● **All Templates** ⊙ ➡ *Reset All* ➡ ● ➡ *Yes* ➡ ●

■ Member Status & Notices

Updating manually	● ➡ *Entertainment* ➡ ● ➡ *S! Friend's Status* ➡ ● ➡ ⊙ ➡ *Settings* ➡ ● ➡ *Status Update* ➡ ●
Opening notices	● ➡ *Entertainment* ➡ ● ➡ *S! Friend's Status* ➡ ● ➡ ⊙ ➡ *StatusNotifList* ➡ ● ➡ Select notice ➡ ●

■ My Details

Sending My Details image	● ➔ *Entertainment* ➔ ● ➔ *S! Friend's Status* ➔ ● ➔ ⊙ Select Group ➔ Select member ➔ ⊙ ➔ *Send Image* ➔ ● ➔ *Yes* ➔ ● ● Available when your handset number is saved in Phone Book on member's handset.

S! Circle Talk

■ Member List

Editing individual members	Start Here ● ➔ *Entertainment* ➔ ● ➔ *S! Circle Talk* ➔ ● ➔ Select member ➔ ⊙ ➔ See below
	Replacing Members *Edit* ➔ ● ➔ ● ➔ Select method ➔ ● ➔ Select entry ➔ ●
	Deleting Members *Delete* ➔ ● ➔ *Yes* ➔ ●
Editing Groups	Start Here ● ➔ *Entertainment* ➔ ● ➔ *S! Circle Talk* ➔ ● ➔ Select Group ➔ ⊙ ➔ See below
	Editing Group Name/Members *Edit* ➔ ● ➔ Select target ➔ ● ➔ Edit/enter ➔ ● ➔ ⓨ
	Deleting Group Members *Edit* ➔ ● ➔ Select member ➔ ⊙ ➔ *Delete* ➔ ● ➔ *Yes* ➔ ● ➔ ⓨ
	Deleting Groups *Delete* ➔ ● ➔ *Yes* ➔ ●

■ Settings

Disabling Loudspeaker	● ➔ *Entertainment* ➔ ● ➔ *S! Circle Talk* ➔ ● ➔ ⊙ ➔ *Loudspeaker* ➔ ● ➔ *Off* ➔ ●
Exiting S! Circle Talk for incoming calls	● ➔ *Entertainment* ➔ ● ➔ *S! Circle Talk* ➔ ● ➔ ⊙ ➔ *Incoming Calls* ➔ ● ➔ *Voice Calls* or *Video Calls* ➔ ● ➔ *Accept Calls* ➔ ●

Blog Tool

Editing entries	● ➔ *Entertainment* ➔ ● ➔ *Blog Tool* ➔ ● ➔ Select entry ➔ ⊙ ➔ *Edit* ➔ ● ➔ Select item ➔ ● ➔ Edit/enter ➔ ● ➔ 戻る ➔ ⓨ ● For *Blog Title*, omit step of pressing 戻る after editing.
Deleting entries	● ➔ *Entertainment* ➔ ● ➔ *Blog Tool* ➔ ● ➔ Select entry ➔ ⊙ ➔ *Delete* ➔ ● ➔ *Yes* ➔ ●

Widgets & Entertainment

9

Widgets & Entertainment

9

S! Quick News

❓ **Cannot receive content updates**

- Update may fail out-of-range or in poor signal conditions.
- Automatic Update does not affect S! Quick News List News Flash update items overnight.
- USIM Card replacement cancels Automatic Update.

S! Friend's Status

❓ **Cannot use S! Friend's Status**

- Set IP Service Setting to *On*.

❓ **Handset rejected a registration request automatically**

- Rejection notice is sent automatically when 30 members are already registered or handset fails to respond within two hours.

❓ **Registration request arrived from a deleted member**

- Registration request arrives when a member fails to receive cancellation notice within 24 hours.

❓ **Registration request was sent to a member automatically**

- Registration request is sent automatically when handset fails to receive rejection/cancellation notice within 24 hours.

❓ **Cannot create Status Templates**

- Three templates may already be added; reset one and retry.

S! Circle Talk

❓ **Cannot use S! Circle Talk**

- Set IP Service Setting to *On*.

❓ **S! Circle Talk starts automatically**

- Check My Status; handset accepts S! Circle Talk requests automatically if S! Circle Talk Availability is set to *Auto Join*.

❓ **Cannot accept S! Circle Talk requests**

- Check My Status; handset rejects S! Circle Talk requests automatically if S! Circle Talk Availability is set to *Join NG.*