Mail

Overview 5-2
Sending Messages 5-3
Sending S! Mail 5-3
Sending SMS Messages 5-5
Receiving & Opening Messages 5-7
Opening New Messages 5-7
Opening Inbox Messages 5-7
Replying to Messages 5-8
Using Mail List 5-8
Handling Messages 5-10
Message Storage Locations 5-10
Opening Sent & Received Messages 5-10
Sorting Messages 5-12
Using Tomomato-Mail 5-12
Prohibiting Access to Messages 5-13
Saving S! Mail Attachments 5-14
Advanced Features 5-16
Sending Messages 5-16
Receiving/Opening Messages 5-20
Managing/Using Messages 5-21

5

Handset supports S! Mail and SMS.



Server

- If recipient's handset is turned off or out of range, sent message is stored on the server up to 30 days until the recipient's handset becomes available.

Available Mail Services

SMS Exchange short text messages with other SoftBank handsets.

S! Mail (Separate contract required) Exchange long text messages with S! Mail compatible SoftBank handsets and other e-mail compatible mobile phones and PCs. Images and melodies can also be attached to S! Mail.

Customize Handset E-mail Address.
Effective for blocking spam.

Graphic Mail
Use HTML mail to change font size/color, background, etc.

Emotion-Expressing Mail
Based on sender's message, handset shows a pictogram matching the sender's mood.

Sending S! Mail

1 Press and hold ✉



Composition Window

2 Select address field ⇨ ■ ⇨ *Enter Address* ⇨ ■ ⇨ Enter address ⇨ ■

■Adding Recipients

⇨ Select address field ⇨ ■ ⇨ Select address field ⇨ ■ ⇨ ***Enter Address*** ⇨ ■ ⇨ Enter address ⇨ ■ ⇨ ✉

3 Select Subject field ⇨ ■ ⇨ Enter subject ⇨ ■

If 1/1 (double-byte mode) appears, switch to single-byte mode (P. 2-31).

Tip

- Add up to 20 recipients total between To, Cc and Bcc fields.

4 Select text field ⇨ ■ ⇨ Enter text ⇨ ■

Text Entry Window

5 ✉

■To Cancel Transmission

⇨ When ***Start Packet Connection*** appears ⇨ ■; or

⇨ During Transmission ⇨ Y!

■If *Resend mail?* Appears

⇨ ***YES*** ⇨ ■

Attaching Files

Attach the following files to S! Mail:

- Images
- Melodies
- Books
- Phone Book entries
- Schedule
- Bookmarks
- Videos
- Music (Songs)
- Widget
- Account Details
- To Do List

● For information about image, video, melody and music files, see P. 12-2.

1 [Composition] window ⇨ ⇧ ⇨ *Attach File* ⇨ ■

2 Select a file type ⇨ ■ (⇨ Enter Security Code ⇨ ■) ⇨ Select a file ⇨ ■

■Images with Large File Size

⇨ ***Attach Mail, QVGA Scale down*** or ***VGA Scale down*** ⇨ ■

■Attach Additional Files

⇨ Repeat steps 1 and 2 above

■Open an Attached File

⇨ Select an attached file ⇨ ■

Note

- Copy protected files cannot be sent as attachments or output to external devices.

Graphic Mail

Create html messages to change font color/size and background color. Add scrolling text, paste images, etc.

<Example> Change font size, background color, insert an image and set flashing text.

1 [Text Entry] window ⇨ ⇨ ⇨ ■ ⇨ Select a font size ⇨ ■ ⇨ Enter text ⇨ ■

2 ⇨ ■ ⇨ to select a background color ⇨ ■

■To Toggle Color Palettes

⇨ In Background color window ⇨ ✉

Toggle between 25-color and 256-color palettes.

3 ⇨ ■ ⇨ Select a folder ⇨ ■ ⇨ Select an image ⇨ ■

■Inserting Images with Large File Size

⇨ ***Insert Mail*** or ***SubQCIF Scale down*** ⇨ ■

4 ⇨ ■ ⇨ Begin ⇨ ■ ⇨ Enter text ⇨ ■ (twice) ⇨ ⇨ ■ ⇨ End ⇨ ■

5 ⇨ ■

Adding Addresses to Blog/Mail Member List

Group addresses into Blog/Mail Member list to upload blog images and send messages by group.

● Set one Blog/Mail Member as a blog upload destination.

1 MENU ⇨ *Own Data* ⇨ ■ ⇨ *Blog/Mail Member* ⇨ ■

Blog/Mail Member List

■To Specify as Blog Upload Destination

⇨ Select Blog/Mail Member ⇨ Y!

Blog/Mail Member "★" specified as upload destination appears.

■To Cancel Blog Upload Destination

⇨ Select Blog/Mail Member with "★" ⇨ Y!

2 Select a Blog/Mail Member list ⇨ ■

Blog/Mail Member Window

3 *<Not Stored>* ⇨ ✉ ⇨ Enter address ⇨ ■

■To Save an Address from Phone Book or Sent/Received Address List ⇨ *<Not Stored>* ⇨ ⊡ ⇨ *Look-up Address* ⇨ ■ ⇨ *Phone Book*, *Sent Address* or *Received Address* ⇨ ■ ⇨ Select an address ⇨ ■ (twice)

Sending SMS Messages

Send short text messages to SoftBank handsets, specifying phone numbers as address.

1 ✉ ⇨ *Compose SMS* ⇨ ■



SMS Composition Window

2 To ⇨ ■ ⇨ *Enter Address* ⇨ ■ ⇨ Enter phone number ⇨ ■

3 ⇨ ■ ⇨ Enter text ⇨ ■

4 ✉

More Features

Advanced

Composing Messages

- Enter Address from Phone Book
- Enter Address from Sent/Received Address List
- Specify Blog/Mail Member List Recipients
- Set To, Cc or Bcc
- Delete an Address
- Insert Header/Signature
- Enter My Pictograms
- Delete Text
- Change SMS Message to S! Mail

(▶P. 5-16)

Sending Messages

- Set Priority (S! Mail)
- Server Storage Period (SMS)
- Check Delivery
- Save a Message to Draft without Transmitting It
- Delete a Message without Transmitting It

(▶P. 5-17)

Attaching Files

- Shoot an Image/Video to Attach to S! Mail
- Delete Files Attached to S! Mail

(▶P. 5-18)

Blog/Mail Member

- Edit an Address
- Delete Addresses from a Blog/Mail Member List
- Edit a Blog/Mail Member List Name
- Reset a Blog/Mail Member List Name

(▶P. 5-18)

Graphic Mail

- Apply Effects to Entered Text
- Change Effects
- Cancel Last Applied Effect
- Preview Graphic Mail
- Cancel All Effects
- Create Graphic Mail Automatically
- Save Graphic Mail as a Template
- Download Templates
- Create Graphic Mail from a Template
- Edit a Template
- Edit Title of a Template
- Delete Templates

(▶P. 5-18)

Customize

S! Mail Settings

- Edit Header/Signature
- Insert Header/Signature Automatically
- Set to Check Delivery

(▶P. 14-21)

SMS Settings

- Set to Check Delivery
- Set Server Storage Period of SMS Messages
- Set SMS Input Language

(▶P. 14-21)

Opening New Messages

Received Result window opens for new messages.
By default, complete S! Mail messages (including attachments) are automatically retrieved. Transmission fees apply, depending on your subscription plan. While traveling abroad, message retrieval may incur high transmission fees.

●Emotion-Expressing Mail

When an S! Mail is received, a pictogram matching the message content appears.
If a message contains a specific keyword, a corresponding indicator appears (P. 14-22).



Received Result Window

● Indicators

	Urgent		Advice
	Love		Try Hard
	Hate		Invitation
	Happy		Feedback
	Angry		Request
	Sad		Announcement
	Fun		OK
	Surprise		Reply
	Question		Information

— appears if message content does not match any of the above moods or information.

1 [Received Result] window ⇨ *Mail* ⇨ ■

2 Select a message ⇨ ■

Tip

- Alternatively open new messages from desktop notification.
- Indicator may not always correspond to message content.

Opening Inbox Messages

1 ✉ ⇨ *Inbox* ⇨ ■

Folder List

2 Select a folder ⇨ ■

Message List

3 Select a message ⇨ ■

Message Window

■To Check Previous/Next Message
⇨ ⊡

Tip
- Use ▲ or ▼ to scroll.
- Some attachments may require content keys to open/play the file.

Replying to Messages

1 [Inbox Message List] window ⇨ Select a message ⇨ ■ ⇨ ✉

■When Original Message Has Multiple Recipients
⇨ *To Sender* or *To All* ⇨ ■

2 Edit subject/text ⇨ ✉

Replying (Quote Message)

1 [Inbox Message List] window ⇨ Select a message ⇨ ■ ⇨ Y!

2 Edit subject/text ⇨ ✉

Tip
- Attachments are automatically deleted from reply messages.
- Quoting text is only available for S! Mail replies.

Using Mail List

Retrieve Mail List and select messages to download or forward.

1 ✉ ⇨ *Server Mail* ⇨ ■ ⇨ *Mail List* ⇨ ■ (⇨ *YES* ⇨ ■)

Mail List

2 Select a message ⇨ ⊡ ⇨ *Message Receive* ⇨ ■ ⇨ *Receive This* ⇨ ■

■To Receive Multiple Messages
⇨ ⊡ ⇨ *Message Receive* ⇨ ■ ⇨ *Receive Selected* ⇨ ■ ⇨
Select messages ⇨ ■ ⇨ ✉

■To Receive All Messages
⇨ [Menu] ⇨ *Message Receive* ⇨ [●]
⇨ *Receive All* ⇨ [●]

Tip

- If download fails while retrieving all messages, download is canceled.
- When there is only one message, message opens upon retrieval.

More Features

Advanced

Receiving Messages

- Manually Retrieve Messages

(▶ P. 5-20)

Checking Messages

- Retrieve Complete S! Mail
- Delete S! Mail from Server
- Read Out Messages
- Check Message Information

(▶ P. 5-20)

Server Message Operations

- Update Mail List
- Switch Mail List Views
- Check Server Message Information
- Forward a Server Message
- Delete Server Messages
- Check Server Memory Status

(▶ P. 5-20)

Customize

Incoming Message Alerts

- Adjust Ringtone Volume
- Set a Ringtone
- Set Ringing Duration of Incoming Message Ringtone
- Set Vibration
- Set Illumination Color
- Open New Mail Window by Opening Handset.

(▶ P. 14-10)

Incoming Message Settings

- Customize E-mail Address
- Do Not Show Emotion Indicators
- Set Priority When Receiving Messages during Operation
- Set Whether to Read Out Received Messages
- Set Voice to Read Out Messages
- Set Manual Retrieval of S! Mail only after Notification

(▶ P. 14-22)

Reply Settings

- Change Quotation Marks

(▶ P. 14-23)

Message Storage Locations

Press [✉] to open Mail Main Menu. Sent, received and draft messages are saved in the locations below.



Message Menu

Opening Sent & Received Messages

<Example> Open a Sent Message

1 [✉] ⇨ ***Outbox*** ⇨ [■]



Folder List

2 Select a folder ⇨ [■]

Message List

3 Select a message ⇨ [■]

Message Window

■To Check Previous/Next Message

⇨ [📷]

Tip

- When Outbox/Inbox becomes full, Trash Box messages and then the oldest messages in Outbox/Inbox are deleted next time a new message is sent/received. Unread and protected messages and Secret Folder messages are not deleted.

Mail Windows

Message types, statuses, and attached file types are shown by indicators.

Inbox Folder List



Outbox Folder List

Message List Windows



Inbox Message List



Outbox Message List

Message Windows



Received Message Window



Sent Message Window

①	Folder Type General Folder Trash Box Folder Secret Folder
②	Message Status Unread Received Message Read Received Message Protected Unread Message Forwarded Message Replied Message Message Sent to a Single Recipient Message Sent to Multiple Recipients
③	Message Type/Attached File Type SMS on Handset SMS on USIM Card S! Mail with Text Unreceived Image Attached/Image Inserted in Text Video Attached Melody Attached Song Attached Copyright-protected File Attached Phone Book Entry, Schedule Event or Bookmark Attached Widget Attached E-comic Attached Forwarded Server Message Other Type of File Attached Multiple Files Attached

The following marks appear on indicators to inform you:

- Folder Contains Unread Messages
- Locked Folder
- Folder with Auto Sort Set
- Protected Message
- Delivery failed to Some Recipients or Some Attachments Deleted
- Delivery Failed/All Attachments Deleted
- Attachment Deleted
- High Priority Message

Tip

- Copyright-protected files cannot be opened/played unless they are saved in Data Folder.
- If Delivery Report was received, Subject appears in field of message.

Sorting Messages

Automatically sort incoming/outgoing messages into folders.

1 **[Folder List] ⇨ Select a folder ⇨ [Fn] ⇨ *Auto-sort* ⇨ [●]**

■**When Auto Sort is Already Set to the Folder**
⇨ Select another criterion ⇨ [Fn]

2 ***Address Sort* ⇨ [●] ⇨ *Look-up Address*, *Look-up Group*, *Look-up Member* or *Enter Address* ⇨ [●]**

■**To Sort by Subject**
⇨ ***Subject Sort*** ⇨ [●] ⇨ Enter subject ⇨ [●]

■**To Sort Messages Failed to be Replied/Sent**
⇨ ***Reply Impossible*** or ***Send Impossible*** ⇨ [●]

■**To Sort Addresses Not Stored in Phone Book**
⇨ ***Unregistered Add.*** ⇨ [●]

Tip

- Only one Inbox folder can be specified for sorting *Reply impossible* messages.
- Only one Outbox folder can be specified for sorting *Send impossible* messages.
- Search addresses from Phone Book, Received Address List, or Sent Address List in Look-up address.

Canceling Auto Sort

1 **[Folder List] ⇨ Select a folder ⇨ [Fn] ⇨ *Auto-sort* ⇨ [●]**

2 **Select a criterion ⇨ [Fn] ⇨ *Release* ⇨ [●]**

3 ***Release This*** **⇨ [●] ⇨ *YES* ⇨ [●]**

■**To Cancel Multiple Criteria**
⇨ ***Release Selected*** ⇨ [●] ⇨ Select criteria ⇨ [●] ⇨ [✉] ⇨ ***YES*** ⇨ [●]

■**To Cancel All Criteria**
⇨ ***Release All*** ⇨ [●] ⇨ ***YES*** ⇨ [●]

Using Tomomato-Mail

Store e-mail addresses in Tomomato-Mail and check messages with stored addresses by selecting Tomomato-Mail BOX.

Checking Tomomato-Mail

1 **[✉] ⇨ *Tomomato-Mail BOX* ⇨ [●]**



Tomomato-Mail Folder List Window

2 **Select a folder**

Storing Tomomato-Mail

1 [Tomomato-Mail Folder List] window → Select a folder ⇨ ✉ ⇨ Enter Address ⇨ ● ***Enter Address*** ⇨ ●

■To Store E-Mail Address From Phone Book or Sent/Received Address List

⇨ Select a folder ⇨ ✉ ⇨ ***Phonebook***, ***Sent Address*** or ***Received Address*** ⇨ ● ⇨ Select a address ⇨ ●

Canceling Tomomato-Mail

1 [Tomomato-Mail Folder List] window ⇨ Select a folder ⇨ ↩ ⇨ ***Unregister*** ⇨ ● ⇨ ***YES*** ⇨ ●

Prohibiting Access to Messages

Setting Mail Box Lock

1 ✉ ⇨ ***Mail Setting*** ⇨ ● ⇨ ***Mail Box Lock*** ⇨ ● ⇨ Enter Security Code ⇨ ●

2 Select a mail box ⇨ ●

Repeat step 2 to specify other boxes.

3 ✉

Setting Folder Lock

1 [Folder List] ⇨ Select a folder ⇨ ↩ ⇨ ***Folder Lock*** ⇨ ● ⇨ Enter Security Code ⇨ ● ⇨ ***YES*** ⇨ ●

Locked folders are indicated by 🔒.

Tip

- Repeat the same procedure to cancel mail box and folder lock.
- Trash Box folder can also be locked.
- Security Code entry is required to view messages in locked mail boxes and folders.

Storing Messages in Secret Folders

Set handset to Secret Mode or Secret Data Only Mode beforehand (P. 4-8).

● Unread Messages cannot be stored in Secret Folders.

1 [Message List] window ⇨ Select a message ⇨ ↩ ⇨ ***Keep in Secret*** ⇨ ●

2 ***Keep This*** ⇨ ●

■To Store Multiple Messages

⇨ ***Keep Selected*** ⇨ ● ⇨ Select a message ⇨ ● ⇨ Repeat the same step to specify other messages ⇨ ✉ ⇨ ***YES*** ⇨ ●

■To Store All Messages in a Folder

⇨ ***Keep All*** ⇨ ● ⇨ ***YES*** ⇨ ●

●Returning Messages in Secret Folders to Ordinary Messages

1 [Folder List] ⇨ ***Secret*** ⇨ ■

2 Select a message ⇨ ▣ ⇨ ***Put Out*** ⇨ ■

3 ***Put Out This*** ⇨ ■ ⇨ Select a folder ⇨ ■

■To Return Multiple Messages
⇨ ***Put Out Selected*** ⇨ ■ ⇨ Select a folder ⇨ ■ ⇨ Select a message ⇨ ■ ⇨ Repeat the same step to specify other messages ⇨ ✉ ⇨ ***YES*** ⇨ ■

■To Return All Messages
⇨ ***Put Out All*** ⇨ ■ ⇨ Select a folder ⇨ ■ ⇨ ***YES*** ⇨ ■

Saving S! Mail Attachments

Saving Image, Video, Melody, Music and Flash® Files

1 [Message] window ⇨ Select a file ⇨ ▣ ⇨ ***Save Data*** ⇨ ■ ⇨ ***YES*** ⇨ ■

2 Select a folder ⇨ ■

■To Set an Image as Wallpaper, etc.
⇨ ***YES*** ⇨ ■ ⇨ Select an item ⇨ ■
Select ***NO*** and press ■ when you do not want to set the image.

■To Set a Melody as Ringtone, etc.
⇨ ***YES*** ⇨ ■ ⇨ Select an item ⇨ ■
Select ***NO*** and press ■ when you do not want to set the melody.

Saving an Image Inserted in Text

1 [Message] window ⇨ ▣ ⇨ ***Save Insert Image*** ⇨ ■

2 Select an image ⇨ ■ ⇨ ***YES*** ⇨ ■ ⇨ Select a folder ⇨ ■

3 ***YES*** ⇨ ■ ⇨ Select an item ⇨ ■

■When You Do Not Want to Set the Image
⇨ ***NO*** ⇨ ■

Saving a Phone Book Entry

1 [Message] window ⇨ Select contact information (a phone number, etc.) ⇨ ■ (twice) ⇨ ***Phone*** or ***USIM*** ⇨ ■ ⇨ ***New*** ⇨ ■

2 Edit each item ⇨ ✉

Saving a Schedule Event

1 [Message] window ⇨ Select Schedule data ⇨ ■ (twice)

Saving a Bookmark

1 [Message] window ⇨ Select a link (URL, etc.) ⇨ ■ (twice) ⇨ Select a destination ⇨ ■ (⇨ Select a folder ⇨ ■)

Note

- Mail-attached bookmarks cannot be saved to ***microSD***.

More Features

Advanced

Managing Messages

- Protect a Message
- Move Messages to a Different Folder
- Drop Messages into Trash Box
- Delete Messages
- Delete All Read Messages
- Delete All Delivery Reports
- Delete Attached Files
- Copy SMS Messages between Handset and USIM Card
- Delete SMS Messages on USIM Card
- Change Message Color
- Add a Folder
- Edit a Folder Name
- Change Order of Folders
- Delete a Folder
- Check Number of Saved Messages
- Check Sent/Received Addresses
- Delete All Messages in Tomomato-Mail Folder

(▶ P. 5-21)

Using Messages

- Edit a Sent Message
- Edit & Send a Draft Message
- Forward a Message
- Save Sender, Recipient's E-mail Address or Phone Number to Phone Book
- Call a Phone Number in Text
- Send an S! Mail to an E-mail Address in Text
- Access the Internet from a URL in Text
- Save Number/Address in Text to Phone Book
- Search for Information by Keyword
- Switch Subject Field Views
- Change Font Size of Text
- Search for Messages in a Folder
- Sort Messages
- Filter Messages
- Reset Message List View to Default
- Switch All Unread Messages to Read Messages
- Open S! Mail Delivery Report

(▶ P. 5-24)

Customize

Message View Settings & Others

- Set Message List View
- Play Attached Melodies Automatically
- Set Number of Text Lines to Scroll
- Set Font Size of Text
- Check Mail Settings
- Reset Mail Settings

(▶ P. 14-23)

Sending Messages

Start Here

【Composition】window ..... P. 5-3
【Text Entry】window ..... P. 5-3
【Blog/Mail Member List】 ..... P. 5-4
【Blog/Mail Member】window .... P. 5-5
【SMS Composition】window..... P. 5-5

Composing Messages

Enter Address from Phone Book

【Composition】window/【SMS Composition】window ⇨ To ⇨ ■ ⇨ ***Phonebook*** ⇨ ■ ⇨ Select search method ⇨ Select an entry ⇨ ■ ⇨ Select an e-mail address or phone number ⇨ ■

Enter Address from Sent/Received Address List

【Composition】window/【SMS Composition】window ⇨ To ⇨ ■ ⇨ ***Sent Address*** or ***Received Address*** ⇨ ■ ⇨ Select an e-mail address/phone number ⇨ ■ (twice)

- Alternatively, select To and press ▭ to open Sent/Received Address List.

Specify Blog/Mail Member List Recipients

【Composition】window ⇨ To ⇨ ■ ⇨ ***Blog/Mail Member*** ⇨ ■ ⇨ Select a Blog/Mail Member list ⇨ ■

- All addresses in the selected Blog/Mail Member list are entered in the address field.
- You must save addresses to a Blog/Mail Member list in advance.

Set To, Cc or Bcc

【Composition】window ⇨ To ⇨ ■ ⇨ Select an address ⇨ ⓕ ⇨ ***Change Rcv. Type*** ⇨ ■ ⇨ ***To***, ***Cc*** or ***Bcc*** ⇨ ■

- Cc (Carbon copy): S! Mail copies are sent to other addresses. Addresses in the Cc field are revealed to the other recipients.
- Bcc (Blind carbon copy): S! Mail copies are sent to other addresses. Addresses in the Bcc field are hidden to the other recipients.
- When there is no address in the To field, the message cannot be sent.

Delete an Address

【Composition】window ⇨ To ⇨ ■ ⇨ Select an address ⇨ ⓕ ⇨ ***Delete Receiver*** ⇨ ■ ⇨ ***YES*** ⇨ ■

Insert Header/Signature

【Composition】window ⇨ [Menu] ⇨ ***Add Header*** or ***Add Signature*** ⇨ [●]

Save header/signature in advance.

Enter My Pictograms

【Text Entry】window ⇨ Press and hold [Y!] ⇨ Select a pictograph ⇨ [●] ⇨ [CLEAR]

Toggle categories by pressing [✉] or [Y!].

My Pictograms are only available for S! Mails.

Delete Text

【Composition】window/【SMS Composition】window ⇨ [Menu] ⇨ ***Erase Message*** ⇨ [●] ⇨ ***YES*** ⇨ [●]

Change SMS Message to S! Mail

【SMS Composition】window ⇨ [Menu] ⇨ ***S! Mail Conversion*** ⇨ [●]

Sending Messages

Set Priority (S! Mail)

【Composition】window ⇨ [Menu] ⇨ ***Priority*** ⇨ [●] ⇨ ***High***, ***Normal*** or ***Low*** ⇨ [●]

Server Storage Period (SMS)

【SMS Composition】window ⇨ [Menu] ⇨ ***SMS Valid. Per.*** ⇨ [●] ⇨ Select a period ⇨ [●]

Specify a period the SMS message is stored in the server in case it fails to reach the recipient because the recipient's handset is out of range, etc.

When ***None*** is set, the SMS message is deleted from the server after it is resent once in a certain period of time.

Check Delivery

【Composition】window/【SMS Composition】window ⇨ [Menu] ⇨ ***Delivery Report*** or ***SMS Report Req.*** ⇨ [●] ⇨ ***ON*** or ***OFF*** ⇨ [●]

When ***ON*** is set, handset receives a delivery report.

Save a Message to Draft without Transmitting It

【Composition】window/【SMS Composition】window ⇨ [Menu] ⇨ ***Save*** ⇨ [●]

The message is saved to Draft. Messages saved in Draft can be edited and sent at a later time.

Delete a Message without Transmitting It

【Composition】window/【SMS Composition】window ⇨ [Menu] ⇨ ***Delete*** ⇨ [●] ⇨ ***YES*** ⇨ [●]

Attaching Files

Shoot an Image/Video to Attach to S! Mail

【Composition】window ⇨ [Menu] ⇨ ***Activate Camera*** ⇨ [●] ⇨ ***Photo Mode*** or ***Movie Mode*** ⇨ [●] ⇨ Shoot image/video ⇨ [●]

Delete Files Attached to S! Mail

【Composition】window ⇨ Select an attached file ⇨ [Menu] ⇨ ***Delete Att. File*** or ***Del All Att.Files*** ⇨ [●] ⇨ ***YES*** ⇨ [●]

Blog/Mail Member

Edit an Address

【Blog/Mail Member】window ⇨ Select an address ⇨ [Menu] ⇨ ***Edit Address*** ⇨ [●] ⇨ Edit address ⇨ [●]

Delete Addresses from a Blog/Mail Member List

【Blog/Mail Member】⇨ Select an address ⇨ [Menu]

- To Select *Delete this* ⇨ *Delete this* ⇨ [●] ⇨ *YES* ⇨ [●]
- To Select *Delete all* ⇨ *Delete all* ⇨ [●] ⇨ Enter Security Code ⇨ [●] ⇨ *YES* ⇨ [●]

Edit a Blog/Mail Member List Name

【Blog/Mail Member List】⇨ Select a Blog/Mail Member list ⇨ [Menu] ⇨ ***Edit Member Name*** ⇨ [●] ⇨ Edit name ⇨ [●]

Reset a Blog/Mail Member List Name

【Blog/Mail Member List】⇨ Select a Blog/Mail Member list ⇨ [Menu] ⇨ ***Reset Member Name*** ⇨ [●] ⇨ ***YES*** ⇨ [●]

Graphic Mail

Apply Effects to Entered Text

【Text Entry】window ⇨ [Clear] ⇨ Edit ⇨ [●] ⇨ Select beginning of characters ⇨ [●] ⇨ Select end of characters ⇨ [●] ⇨ Select effects menu ⇨ [●] ⇨ Apply an effects

Select Edit and press [Y!] to select the entire text.

Change Effects

【Text Entry】window ⇨ [Clear] ⇨ Edit ⇨ [●] ⇨ Select beginning of characters ⇨ [●] ⇨ Select end of characters ⇨ [●] ⇨ Select effects menu ⇨ [●] ⇨ Change effects

Select Edit and press [Y!] to select the entire text.

Cancel Last Applied Effect

【Text Entry】window ⇨ [Clear] ⇨ Undo ⇨ [●]

Preview Graphic Mail

【Text Entry】window ⇨ [✎] ⇨ [🔍] ⇨ ■ ⇨ CLEAR or [Y!] to close preview

Cancel All Effects

【Text Entry】window ⇨ [✎] ⇨ Reset All ⇨ ■ ⇨ ***YES*** ⇨ ■ (⇨ ■)

Create Graphic Mail Automatically

【Text Entry】window ⇨ Enter text ⇨ [✎] ⇨ Auto ⇨ ■ ⇨ [Y!] to toggle effects ⇨ ■

Emotion of the message is detected from the entered text, and a set of effects that matches the emotion is automatically applied.

Save Graphic Mail as a Template

【Text Entry】window ⇨ Enter text ⇨ ■ ⇨ [↑] ⇨ ***Template*** ⇨ ■ ⇨ ***Save Template*** ⇨ ■ ⇨ ***YES*** ⇨ ■

Attached files except images inserted in text are not included in a template. Save up to 45 templates including downloads. Delete saved templates as needed.

Download Templates

[✉] ⇨ ***Template*** ⇨ ■ ⇨ ***Download Templates*** ⇨ ■ (twice) ⇨ Follow onscreen instructions

Create Graphic Mail from a Template

[✉] ⇨ ***Template*** ⇨ ■ ⇨ Select a template ⇨ ■ ⇨ [✉]

Edit a Template

[✉] ⇨ ***Template*** ⇨ ■ ⇨ Select a template ⇨ ■ ⇨ [↑] ⇨ ***Edit*** ⇨ ■ ⇨ Edit text ⇨ ■ (twice) ⇨ ***YES*** ⇨ ■

Edit Title of a Template

[✉] ⇨ ***Template*** ⇨ ■ ⇨ Select a template ⇨ [↑] ⇨ ***Edit Title*** ⇨ ■ ⇨ Edit title ⇨ ■

Delete Templates

[✉] ⇨ ***Template*** ⇨ ■ ⇨ Select a template ⇨ [↑] ⇨ ***Delete*** ⇨ ■

- To Select *Delete This* ⇨ *Delete This* ⇨ ■ ⇨ *YES* ⇨ ■
- To Select *Delete Selected* ⇨ *Delete Selected* ⇨ ■ ⇨ Select templates ⇨ ■ ⇨ [✉] ⇨ *YES* ⇨ ■
- To Select *Delete All* ⇨ *Delete All* ⇨ ■ ⇨ Enter Security Code ⇨ ■ ⇨ *YES* ⇨ ■

Receiving/Opening Messages

Start Here

【Message List】.....P. 5-7
【Message】window.....P. 5-8
【Mail List】.....P. 5-8

Receiving Messages

Manually Retrieve Messages

✉ ⇨ ***Retrieve New*** ⇨ ■ ⇨ Received Result window opens ⇨ ***Mail*** ⇨ ■ ⇨ Select a message ⇨ ■

Press Y! or press and hold CLEAR to cancel message retrieval.

Retrieve messages that were stored on the server while handset was off or out of range.

Checking Messages

Retrieve Complete S! Mail

✉ ⇨ ***Inbox*** ⇨ ■ ⇨ Select a folder ⇨ ■ ⇨ Select an S! Mail notification ⇨ ■ ⇨ ✉

An S! Mail notification is deleted when you retrieve the message text.

Use this procedure when *Message Download* under ***S! Mail Settings*** is set to *Manual*.

Delete S! Mail from Server

✉ ⇨ ***Inbox*** ⇨ ■ ⇨ Select a folder ⇨ ■ ⇨ Select an S! Mail notification ⇨ ■ ⇨ ⊓ ⇨ ***Delete*** ⇨ ■ ⇨ ***Notification***, ***Server Mail*** or ***Notifi./Server*** ⇨ ■ ⇨ ***YES*** ⇨ ■

Read Out Messages

【Message】window ⇨ ⊓ ⇨ ***Read Out Message*** ⇨ ■

Press ■ to stop reading.

Press ✉ to end reading.

Check Message Information

【Message List】 ⇨ ⊓ ⇨ ***Mail Info*** ⇨ ■

This procedure is available only in Inbox Message List window.

Server Message Operations

Update Mail List

【Mail List】 ⇨ ⊓ ⇨ ***Mail List*** ⇨ ■

Switch Mail List Views

【Mail List】 ⇨ ⊓ ⇨ ***List Setting*** ⇨ ■ ⇨ ***Subject***, ***Name*** or ***Address*** ⇨ ■

Check Server Message Information

【Mail List】⇨ Select a message ⇨ [Menu] ⇨ ***Mail Info*** ⇨ [●]

Forward a Server Message

【Mail List】⇨ Select a message ⇨ [Menu] ⇨ ***Forward*** ⇨ [●] ⇨ [To] ⇨ [●] ⇨ Enter address ⇨ [✉]

Delete Server Messages

【Mail List】⇨ Select a message ⇨ [Menu] ⇨ ***Delete*** ⇨ [●]

- To Select *Delete This* ⇨ *Delete This* ⇨ [●] ⇨ *YES* ⇨ [●]
- To Select *Delete Selected* ⇨ *Delete Selected* ⇨ [●] ⇨ Select messages ⇨ [●] ⇨ [✉] ⇨ *YES* ⇨ [●]
- To Select *Delete All* ⇨ *Delete All* ⇨ [●] ⇨ Enter Security Code ⇨ [●] ⇨ *YES* ⇨ [●]

Check Server Memory Status

[✉] ⇨ ***Server Mail*** ⇨ [●] ⇨ ***Server Mail Memory*** ⇨ [●]

Managing/Using Messages

Start Here

【Folder List】..... P. 5-10
【Message List】..... P. 5-10
【Message】window ..... P. 5-10
【Inbox Folder List】..... P. 5-11
【Inbox Message List】..... P. 5-11
【Received Message】window .. P. 5-11
【Sent Message】window..... P. 5-11
【Tomomato-Mail Folder List】window ..... P. 5-12

Managing Messages

Protect a Message

【Message】window ⇨ [Menu] ⇨ ***Protect ON/OFF*** ⇨ [●]

If a message is protected, this procedure cancels protection.

Move Messages to a Different Folder

【Message List】⇨ Select a message ⇨ [Menu] ⇨ ***Move*** ⇨ [●] ⇨ ***Move This***, ***Move Selected*** or ***Move All*** ⇨ [●] ⇨ Select a destination folder ⇨ [●] (⇨ Select messages ⇨ [●] ⇨ [✉]) ⇨ ***YES*** ⇨ [●]

A message can also be moved to a different folder from Message window.

Drop Messages into Trash Box

【Message List】⇨ [Menu] ⇨ ***Move to Trash Box*** ⇨ [●] ⇨ Select a message ⇨ [●] ⇨ [✉] ⇨ ***YES*** ⇨ [●]

Protected messages and delivery reports cannot be moved to Trash Box.

Delete Messages

【Folder List】⇨ [Menu] ⇨ ***Delete All*** ⇨ [●] ⇨ Enter Security Code ⇨ [●] ⇨ ***YES*** ⇨ [●]

【Message List】⇨ Select a message ⇨ [Menu] ⇨ ***Delete*** ⇨ [●]

- To Select *Delete This* ⇨ ***Delete This*** ⇨ [●] ⇨ *YES* ⇨ [●]
- To Select *Delete Selected* ⇨ ***Delete Selected*** ⇨ [●] ⇨ Select messages ⇨ [●] ⇨ [✉] ⇨ *YES* ⇨ [●]
- To Select *Delete All* ⇨ ***Delete All*** ⇨ [●] ⇨ Enter Security Code ⇨ [●] ⇨ YES ⇨ [●]

Protected messages cannot be deleted.

Delete All Read Messages

【Inbox Folder List】⇨ [Menu] ⇨ ***Delete Read*** ⇨ [●] ⇨ ***YES*** ⇨ [●]

【Inbox Message List】window ⇨ [Menu] ⇨ ***Delete*** ⇨ [●] ⇨ ***Delete Read*** ⇨ [●] ⇨ ***YES*** ⇨ [●]

Protected messages cannot be deleted.

Delete All Delivery Reports

【Inbox Message List】⇨ [Menu] ⇨ ***Delete*** ⇨ [●] ⇨ ***Delete All Reports*** ⇨ [●] ⇨ Enter Security Code ⇨ [●] ⇨ ***YES*** ⇨ [●]

Protected delivery reports cannot be deleted.

Delete Attached Files

【Message】window (⇨ Select attached files) ⇨ [Menu] ⇨ ***Delete Att. File*** or ***Del All Att. Files*** ⇨ [●] ⇨ ***YES*** ⇨ [●]

Copy SMS Messages between Handset and USIM Card

[MENU] ⇨ ***Tools*** ⇨ [●] ⇨ ***USIM Operation*** ⇨ [●] ⇨ Enter Security Code ⇨ [●] ⇨ ***Copy*** ⇨ [●] ⇨ ***Phone→USIM*** or ***USIM→Phone*** ⇨ [●] ⇨ ***SMS*** ⇨ [●] ⇨ ***Inbox*** or ***Outbox*** ⇨ [●] ⇨ Select a folder ⇨ [●] ⇨ Select an SMS message ⇨ [●] ⇨ [✉] ⇨ ***YES*** ⇨ [●]

Delete SMS Messages on USIM Card

[MENU] ⇨ ***Tools*** ⇨ [●] ⇨ ***USIM Operation*** ⇨ [●] ⇨ Enter Security Code ⇨ [●] ⇨ ***Delete*** ⇨ [●] ⇨ ***USIM*** ⇨ [●] ⇨ ***SMS*** ⇨ [●] ⇨ ***Inbox*** or ***Outbox*** ⇨ [●] ⇨ Select a folder ⇨ [●] ⇨ Select an SMS message ⇨ [●] ⇨ [✉] ⇨ ***YES*** ⇨ [●]

Change Message Color

【Message List】⇨ Select a message ⇨ Press and hold [✱]

Each time you press and hold [✱], the message color toggles as follows: Red → Blue → Black

Add a Folder

【Folder List】⇨ [Menu] ⇨ ***Add Folder*** ⇨ [●] ⇨ Enter folder name ⇨ [●] ⇨ ***YES*** ⇨ [●] ⇨ ***Address Sort***, ***Subject Sort***, ***Reply Impossible***, ***Send Impossible*** or ***Unregistered Add.*** ⇨ [●] ⇨ Make auto Sort settings ⇨ [✉] ⇨ ***YES*** or ***NO*** ⇨ [●]

Select ***NO*** and press [●] when you do not want to make Auto Sort settings to the folder.

Edit a Folder Name

【Folder List】⇨ Select a folder ⇨ [Menu] ⇨ ***Edit Folder Name*** ⇨ [●] ⇨ Edit folder name ⇨ [●]

Preinstalled folders cannot be renamed.

Change Order of Folders

【Folder List】⇨ Select a folder ⇨ [Menu] ⇨ ***Sort Folder*** ⇨ [●] ⇨ Select a position ⇨ [●]

The order of preinstalled folders cannot be changed.

Delete a Folder

【Folder List】⇨ Select a folder ⇨ [Menu] ⇨ ***Delete Folder*** ⇨ [●] ⇨ Enter Security Code ⇨ [●] ⇨ ***YES*** ⇨ [●]

Folders containing protected messages and preinstalled folders cannot be deleted.

This procedure also deletes messages stored in the folder.

Auto Sort settings are also canceled when you delete a folder with Auto Sort settings.

Check Number of Saved Messages

【Folder List】/【Message List】⇨ [Menu] ⇨ ***No. of Messages*** ⇨ [●]

The total number of messages, and the number of unread and protected messages in a folder can be checked from Folder List.
The number of messages in a folder can be checked from Message List window.

Check Sent/Received Addresses

Press and hold [Mail] or press and hold [Mail] ⇨ Select an entry ⇨ [●]

Delete All Messages in Tomomato-Mail Folder

【Tomomato-Mail Folder List】window ⇨ Select folder ⇨ [Menu] ⇨ ***Del All in Folder*** ⇨ Enter Security Code ⇨ [●] ⇨ ***YES*** ⇨ [●]

Using Messages

Edit a Sent Message

✉ ⇨ ***Outbox*** ⇨ ■ ⇨ Select a folder ⇨ ■ ⇨ Select a sent message ⇨ ✉ ⇨ Edit address, subject and text ⇨ ✉

Edit & Send a Draft Message

✉ ⇨ ***Draft*** ⇨ ■ ⇨ Select a message ⇨ ■ ⇨ Edit address, subject and text ⇨ ✉

Forward a Message

【Received Message】window ⇨ ⊡ ⇨ ***Reply/Forward*** ⇨ ■ ⇨ ***Forward*** ⇨ ■ (twice) ⇨ Enter address ⇨ ✉

- The subject and text can also be edited.
- Files attached to/inserted in S! Mails are also forwarded.

Save Sender, Recipient's E-mail Address or Phone Number to Phone Book

【Message】window ⇨ ⊡ ⇨ ***Address List*** ⇨ Select an e-mail address/phone number ⇨ ⊡ ⇨ ***Save Address*** ⇨ ■ ⇨ ***YES*** ⇨ ■ ⇨ ***Phone*** or ***USIM*** ⇨ ■ ⇨ Select saving option ⇨ ■ (⇨ Search Phone Book ⇨ Select an entry ⇨ ■) ⇨ Edit each item ⇨ ✉

- Select an address to save to Phone Book when the message has multiple recipients.

Call a Phone Number in Text

【Message】window ⇨ Select a phone number ⇨ ■ ⇨ ***Voice Phone*** or ***Video Call*** ⇨ ■ ⇨ ***Dial*** ⇨ ■

Send an S! Mail to an E-mail Address in Text

【Message】window ⇨ Select an e-mail address ⇨ ■ ⇨ Compose S! Mail ⇨ ✉

Access the Internet from a URL in Text

【Message】window ⇨ Select a URL ⇨ ■ ⇨ ***Yahoo! Keitai*** or ***PC Site Browser*** ⇨ ■

Save Number/Address in Text to Phone Book

【Message】window ⇨ Select an e-mail address/phone number ⇨ [Menu] ⇨ ***Save Address*** ⇨ [●] ⇨ ***Phonebook*** ⇨ [●]

- Save to Handset ⇨ ***Phone*** ⇨ [●] ⇨ Select store method ⇨ [●] (⇨ Search Phone Book ⇨ Select Phone Book ⇨ [●]) ⇨ Edit items ⇨ [✉] (⇨ ***YES*** or ***NO*** ⇨ [●]) (⇨ Enter entry number ⇨ [●])
- To Save to USIM Card ⇨ ***USIM*** ⇨ [●] ⇨ Select store method ⇨ [●] (⇨ Search Phone Book ⇨ Select Phone Book ⇨ [●]) ⇨ Edit items ⇨ [✉] (⇨ ***Overwrite*** or ***Add*** ⇨ [●]) (⇨ ***YES*** or ***NO*** ⇨ [●])

Search for Information by Keyword

【Message】window ⇨ [Menu] ⇨ Quick Search ⇨ [●] ⇨ Enter keyword ⇨ [●] ⇨ Enter keyword ⇨ [●] ⇨ Y! or Browser ⇨ [●] ⇨ Select an item from search results ⇨ [●]

To select a keyword from previous entries, select ***History***, press [●], select a keyword, and then press [●].

Switch Subject Field Views

【Message List】⇨ Press and hold [#]

When Mail List Disp. is set to ***2 Lines***, view toggles in the order Name → Address.

When ***Mail List Disp***. is set to ***1 Line***, or to ***1 Line+Body***, the view cycles as follows: Subject → Name → Address

Change Font Size of Text

【Message】window ⇨ Press and hold [Camera]

Search for Messages in a Folder

【Message List】⇨ [Menu] ⇨ ***Search Mail*** ⇨ [●] ⇨ ***Search Sender***, ***Search Receiver*** or ***Search Subject*** ⇨ [●] (⇨ Select a search criterion ⇨ [●]) ⇨ Select an address, enter address or subject ⇨ [●]

Narrow down search results by repeating the search operation.

Sort Messages

【Message List】⇨ [Menu] ⇨ ***Sort*** ⇨ [●] ⇨ Select a criterion ⇨ [●]

This procedure can be combined with the ***Filter*** operation below.

Filter Messages

【Message List】⇨ [Menu] ⇨ ***Filter*** ⇨ [●] ⇨ Select a criterion ⇨ [●]

This procedure can be combined with the ***Sort*** operation above.

Reset Message List View to Default

【Message List】 ⇨ [Menu] ⇨ ***Display All*** ⇨ [●]

This procedure returns the message list view that has been changed by search, sort or filter operation to its original view.

Switch All Unread Messages to Read Messages

【Inbox Message List】 ⇨ [Menu] ⇨ ***Read All*** ⇨ [●] ⇨ ***YES*** ⇨ [●]

Open S! Mail Delivery Report

【Outbox Message】 window ⇨ [Menu] ⇨ ***Disp. Report*** ⇨ [●]

Only available in Message window of a sent message with a requested delivery report.