

Making/Answering Voice Calls 2-2

Making Voice Calls	2-2
Outgoing Call Functions	2-3
Emergency Calls (110, 119, 118)	2-4
Answering Voice Calls.....	2-5
Incoming Call Functions.....	2-5
Making Voice Clear (Shikkari Talk).....	2-5

Making/Answering Video Calls..... 2-6

Note	2-6
Video Call Window.....	2-6
Making Video Calls.....	2-7
Answering Video Calls	2-8

International Calls..... 2-9

Calling Abroad from Japan.....	2-9
Calling while Abroad	2-9
Global Roaming Settings	2-10

Engaged Call Functions 2-11

Operations Available during a Voice Call	2-11
Operations Available during a Video Call	2-12

Call Log..... 2-13

Viewing Call Logs.....	2-13
Calling from Call Log.....	2-14
Call Log Operations.....	2-14

Answer Phone..... 2-15

Using Answer Phone.....	2-15
Recording Calls/Playing Recordings.....	2-16
Additional Settings	2-16


Optional Services 2-17

Overview	2-17
Call Forwarding	2-17
Voice Mail	2-18
Call Waiting.....	2-20
Call Barring.....	2-20
Caller ID.....	2-21

Making/Answering Voice Calls

Making Voice Calls

Before Calling

- Confirm signal strength (☞P.1-8)
- If any of these indicators appear:

 → Calls cannot be made (☞P.1-8, P.1-9, P.18-11)

1 Enter a phone number

- Include area code for all numbers.

090XXXXXXXXX



2 Confirm the number, then

- To adjust volume:  or 

3 to end call

Call Time appears.

Correcting Misentries

Use  to place cursor at digit to delete, then .

Press and hold  to delete the digit and all digits to the right of cursor.

Note

- Do not cover antenna area (☞P.1-5) with hand or sticker; may weaken signal strength and cause calls/transmissions to be unavailable.

Tip

- Operations Available during a Voice Call (☞P.2-11)
 - Calling from Call Log (☞P.2-14)
 - Saving Entered Numbers to Phone Book (☞P.4-5)
 - Making Calls from Phone Book (☞P.4-6)
- Settings**
- Call Time & Call Cost (☞P.17-8)
 - Set Handset Response when Closed during Call (☞P.17-9)

Outgoing Call Functions

Showing/Hiding Caller ID

- > Enter a number → [Menu] → **Notify caller ID** → **OFF** or **ON**
- To cancel setting: [Menu] → **Notify caller ID** → **Cancel prefix**
- Setting Caller ID on/off (Caller ID: P.2-21)

Adding Prefix to Phone Number

■ Save Prefix

- > **Main Menu** ► **Settings** ► **Call Settings** ► **Prefix**
 - Highlight **<Not Recorded>** ► [Edit] ► Enter a name
 - Enter a prefix number
- Up to seven entries can be saved.
- To check entries: Select a saved prefix.
- To delete entries: Highlight a prefix → [Menu] → **Delete this** or **Delete all** (→ For **Delete all**, enter Phone Password) → **YES**

■ Make Calls Using Prefix

- > Enter a number → [Menu] → **Prefix numbers** → Select an entry
→ Voice Calls: /Video Calls: [V. Call]
 - Alternatively, in detail window of Phone Book, Redial, Outgoing Call Logs or Incoming Call Logs, [Menu] → **Prefix numbers** → Select an entry → Voice Calls: /Video Calls: [V. Call]
- Example: Save "186" and "184" as prefixes, and add them to phone numbers to show/hide your caller ID when making calls.

Sending Touch-tone Signals

Send touch-tone signals for services such as reserving tickets, checking bank balance, etc. Save number strings to be sent as a touch-tone signal. Use P (pause) to separate numbers when saving.

■ Save Pause Dial

- > **Main Menu** ► **Settings** ► **Phone Settings** ► **Pause Dial**
 - [Edit] ► Enter a number string
- To enter a pause (p): Press and hold
- To delete: In Pause Dial window, [Menu] → **Delete** → **YES**

■ Send Pause Dial

- > **Main Menu** ► **Settings** ► **Phone Settings** ► **Pause Dial**
 - [Send] ► Enter a phone number ► ► Once line is connected, [Send]
- Number string is sent each time [Send] is pressed.
- To send all number strings at one time: Once line is connected, press and hold → **Send at one time**

Emergency Calls (110, 119, 118)

Call 110 (Police), 119 (Fire & Ambulance) or 118 (Coast Guard) even when some handset restrictions are active.

Calls Cannot be Made in Following Cases:

- When **Set Max Cost Limit** is **ON** and charge limit is reached
- In PIN/PIN2, PUK/PUK2 entry window

Emergency Positioning Request


When an emergency call is made from a mobile phone, location is reported to first response agencies such as the police.

- Location information may be inaccurate due to location or signal conditions. Describe location or nearby landmarks.
- Base Station Positioning System is accurate within 100 meters to 10 kilometers. Location information from distant base stations may be inaccurate.
- Function available where first response agencies have completed system installation.
- Dialing 184 before 110, 118 or 119, cancels location report. However, first responders may obtain location information for immediate and serious threats to life.
- Not available for international roaming.
- Requires no separate subscription or transmission fees.

Answering Voice Calls

When a Call Arrives...

Handset rings; Notification Light flashes.



If Caller ID is sent, number appears in Display; if saved in Phone Book, caller's name appears.

When an International call arrives,  appears at upper left of caller's phone number.

1 to talk

- To adjust volume:  or 

2 to end call

Call Time appears.

Adjust Ringer Volume

> While handset is ringing, 

- Volume adjustment is disabled in following cases:
 - When Manner Mode is active ([P.1-15](#))
 - While **Ringer Volume** is set to **Escalating Tone** ([P.17-2](#))

Note






- When Caller ID is not sent, **Withheld** appears.

Tip

- Operations Available during a Voice Call ([P.2-11](#))
- Rejecting Unknown Callers ● Rejecting Calls without Caller ID ([P.12-13](#))
- Settings** ● Change Answer Setting ● Answer Calls by Opening Handset ([P.17-7](#))

Incoming Call Functions

Following operations are available for incoming calls.

Place Calls on Hold	> 
Answer Phone	>  or 
Call Rejection	>  [Menu] → Call Rejection <ul style="list-style-type: none"> ● Rejecting Unknown Callers/Rejecting Calls without Caller ID (P.12-13)
Call Forwarding	>  [Menu] → Call Forwarding <ul style="list-style-type: none"> ● Activate Call Forwarding (P.2-17) beforehand to forward incoming calls to a preset number. If Call Forwarding is not active, calls are rejected.

Making Voice Clear (Shikkari Talk)

<Default> ON

Shikkari Talk adjusts earpiece sound according to surrounding noise.

Main Menu ► Settings ► Call Settings ► Shikkari Talk

1 **ON** or **OFF**

Making/Answering Video Calls

Exchange video/sound with video call-compatible mobiles.


- Send Alternative Image (still image) or Video Image via Camera. By default, Outgoing Image is set to Alternative Image.

Note

- Only available within 3G network coverage.
- Handset is 3G-324M compliant; calls connected via different systems may be disconnected (charges apply).
- Increasing Speaker volume may cause interference. Decrease volume or use Earphone Microphone.
- Handset may become warm during Video Call. This is not malfunction.
- When incoming/outgoing sound or image fails, try calling again.

Video Call Window

Example: Outgoing Video Call by Default



Indicators

- | | |
|------------------------------------|------------------------|
| : Incoming/Outgoing Sound OK | : Video ON |
| (Gray): Incoming/Outgoing Sound NG | : Alternative Image ON |
| : Incoming/Outgoing Image OK | : Speaker ON |
| (Gray): Incoming/Outgoing Image NG | : Close-up |
| | : Landscape |
| | : Night mode |

- Image display changes depending on settings.

Making Video Calls

Before Calling

- Confirm signal strength (☞P.1-8)
- If any of these indicators appear:



→ Video Calls cannot be made (☞P.1-8, P.1-9, P.18-11)

1 Enter a phone number

090XXXXXXXXX

2 Confirm the number, then [V. Call]

When answered, outgoing and incoming images appear; other party's voice sounds via Speaker.

- To adjust volume: [Speaker Icon] or [Volume Icon]

3 [End Call Icon] to end call

Note

- Other party's voice sounds via Earpiece in Manner Mode; activate Speaker (☞P.2-12).

Tip


- Outgoing Call Functions (☞P.2-3)
 - Operations Available during a Video Call (☞P.2-12)
 - Calling from Call Log (☞P.2-14)
 - Saving Entered Numbers to Phone Book (☞P.4-5)
 - Making Calls from Phone Book (☞P.4-6)
- Settings**
- Change Outgoing Image
 - Switch to Voice Call when Video Call Fails (☞P.17-12)


Answering Video Calls

When a Video Call Arrives...

Handset rings; Notification Light flashes.

If Caller ID is sent, number appears in Display;
if saved in Phone Book, caller's name appears.

When an International call arrives,  appears at upper left of caller's phone number.




1



Alternative Image is sent.

- To send Video Image:




2



to end call

Note

- Other party's voice sounds via Earpiece in Manner Mode; activate Speaker ( P.2-12).


Tip

- Adjust Ringer Volume ● Incoming Call Functions ( P.2-5)
- Operations Available during a Video Call ( P.2-12)

International Calls

Calling Abroad from Japan

- Application not required. For details, go to:
http://mb.softbank.jp/en/global_services/call/

- 1 Enter a phone number
- 2  [Menu] → *Int'l dial assist*
Country/region code list appears.

- 3 Select a country/region





4 Voice Calls



Video Calls



■ Enter Country/Region Code Directly

- >  → Press and hold  to display + (IDD Prefix) → Enter a country/region code → Enter a number (omit first 0)
→ Voice Calls: /Video Calls:  [V. Call]
- Do not omit leading 0 to call Italy (country code: 39).


Calling while Abroad

- May require application to Global Roaming Service. For details, go to:
http://mb.softbank.jp/en/global_services/global_roaming/

Example: Calling Japan from Another Country/Region

- **Auto Assist** ( P.2-10) is set to **ON** and **Japan (+81)** by default.
- Enter the complete number, starting with 0.

1 Voice Calls

Enter a phone number → 

Video Calls

Enter a phone number →  [V. Call]

2 Dial


First 0 is replaced by +81.

- To dial a number as saved in Phone Book: **Dial with orig.No.**

Calling Other Countries/Regions Using Country/Region Code

Follow the same steps as calling abroad from Japan ( Left).

Calling within the Same Country/Region

Follow the same steps as making a Voice Call/Video Call within Japan ( P.2-2, P.2-7).

Global Roaming Settings

From ► Main Menu ► Settings ► International Call

International Call Settings

> **Int'l Dial Assist** → Select an item (See below)

Item	Operation/Description
Auto Assist	Automatically inserts prefixes (IDD Prefix and country code). > ON or OFF (→ For ON , select a country/region)
Country/ Area Code	Save up to 27 country/region codes > Highlight <Not Recorded> → [Edit] → Enter a country/region name → Enter a country/region code ● To view an entry: Select a saved country/region ● To delete: Highlight a country/region → [Menu] → Delete this or Delete all (→ For Delete all , enter Phone Password) → YES
IDD Prefix	Edit IDD Prefix. IDD Prefix is set to 0046010 by default > [Menu] → Edit → Edit IDD Prefix

Network Mode

<Default> Automatically

> **Select Network** → Select an item (See below)

Item	Operation/Description
Automatically	Handset automatically selects 3G network in Japan, and available network (3G or GSM) when abroad.
Manually	> Select an item <ul style="list-style-type: none"> · 3G/GSM: 3G/GSM service area in Japan or abroad. Handset selects an available network automatically. · 3G: 3G service area in Japan or abroad · GSM: GSM service area abroad. Unavailable in Japan

● **Automatically** is recommended.

Select Operator

<Default> Auto

> **Select Operator** → Select an item (See below)

Item	Operation/Description
Auto	Select an operator automatically
Manual	Select an operator manually > Select an operator <ul style="list-style-type: none"> ● Operators with X are not available. ● To update operator list: [Update]
Network Re-search	Search available networks <ul style="list-style-type: none"> ● When Auto is set, handset selects an available operator automatically. When Manual is set, operator list appears.

■ Operator Priority for Automatic Search

> **PLMN Setting** → Highlight a position → [Menu] → Select an item (See below)

Item	Operation/Description
Add your network	Save currently connected operator > [Finish] → YES
Add from list	> Select an operator → [Set] → Select a network type → [Finish] → YES ● To search operators by country/region: [Search] → Select a country/region (To search again in country/region list: [Search] → Enter a country/region name)
Direct input	Save unlisted operators by entering country/region code and operator code > Enter country/region code (3 digits) and operator code (2 to 3 digits) → Select a network type → [Finish] → YES
Change priority	> Select a priority → [Finish] → YES
Delete this/ Delete all	> YES → [Finish] → YES

■ View Operator Name in Standby

<Default> OFF

> **Operator Name** → **ON** or **OFF**

- When **ON** is set, Clock Position is set to **Pattern 1** (☞ P.17-5).

Engaged Call Functions

Operations Available during a Voice Call

Adjust Volume	> or ● Adjust volume within two seconds. ● Adjusted volume is retained even after calls end or handset is turned off.
Place Call on Hold	> [Hold] ● To resume call:
Speaker ON/OFF	Toggle Speaker and Earpiece >
Record Conversation	Record one call only for about three minutes > Press and hold or [Rec] ● To end recording: [Stop], or press and hold ● To play recorded data: P.2-16
Toggle Manner Mode	> Press and hold [#]

Operations Available during a Video Call

Adjust Volume	<p>> or </p> <ul style="list-style-type: none"> ● Adjust volume within two seconds. ● Adjusted volume is retained even after calls end or handset is turned off.
Place Call on Hold	<p>> [Hold]</p> <ul style="list-style-type: none"> ● To resume call:
Speaker ON/OFF	<p>Toggle Speaker and Earpiece</p> <p>> </p>
Record Conversation	<p>Record up to five calls for about 20 seconds each</p> <p>> Press and hold </p> <ul style="list-style-type: none"> ● To end recording: [Stop] or press and hold ● To play recorded data: P.2-16
Video/ Alternative Image	<p>Toggle Video Image and Alternative Image</p> <p>> [image]/[Subst.]</p>
Toggle Image Sizes	<p>> [Change]</p>
Zoom	<p>Adjust zoom level for Video Image to be sent</p> <p>> (zoom in) or (zoom out)</p>
Toggle Manner Mode	<p>> Press and hold [#]</p>
Back Light Setting	<p>> [Menu] → <i>Back light</i> → <i>Constant light</i> or <i>15 seconds light</i></p>
Video Call Setting	<p>> [Menu] → <i>V. Call settings</i> → Follow the steps for selected item (P.17-12)</p>
LCD AI	<p>Activate/deactivate auto image compensation</p> <p>> [Menu] → <i>LCD AI</i> → <i>ON</i> or <i>OFF</i></p>

Account Details	> [Menu] → <i>Account details</i>
Key Guide	> [Menu] → <i>Key guide</i>

Call Log

Incoming and outgoing call records appear here. Use these records to call back.

Redial	Up to 30 outgoing call records (Voice and Video) are saved. Older records of same number are deleted.
Outgoing Call Logs	Up to 30 outgoing call records (Voice and Video) and up to 30 outgoing transmission records (64K data and packet transmission) are saved. Older records of same number are also retained.
Incoming Call Logs	Up to 30 incoming call records (Voice and Video) and up to 30 incoming transmission records (64K data transmission) are saved. Older records of same number are also retained.

Indicators for Redial/Outgoing Call Logs/Incoming Call Logs

	Dialed/received Voice Calls		Dialed calls of 64K data transmission
	* Missed Voice Calls		Received calls of 64K data transmission
	Dialed/received Video Calls		* Missed calls of 64K data transmission
	* Missed Video Calls		Dialed calls of packet transmission
	New messages recorded on Answer Phone		Received calls of 64K data/packet transmission when no external device is connected
	Dialed/received international Voice Calls		
	* Missed international Voice Calls		
	Dialed/received international Video Calls		
	* Missed international Video Calls		
	* Calls received while handset is off, out-of-range, engaged, etc. (P.2-19)		

* Unchecked calls are highlighted.

Viewing Call Logs

1 Redial



Outgoing Call Logs



→ **Phone** → **Call Log**
→ **Outgoing Call Logs**

Incoming Call Logs



Records appear.

- To show Received/Sent address logs:

[Change]



Redial

■ View Missed Calls

> **Main Menu** ► **Phone** ► **Call Log** ► **Incoming Call Logs**

► **Missed Calls**

- **Unknown Calls** appears in Incoming Call Logs for unchecked calls.

Note

- Newest record appears at top of list. Names appear if saved in Phone Book.
- Call Log records remain even if handset is turned off.
- When the maximum number of records is saved, oldest is deleted first.
- Alternatively, view Incoming Call Logs: **Main Menu** ► **Phone** ► **Call Log** ► **Incoming Call Logs** ► **All Calls**

Calling from Call Log

1 Open Call Logs (☞ P.2-13)

2 Voice Calls

Highlight a phone number or name →

Video Calls

Highlight a phone number or name → [V. Call]

International Calls

Select a phone number or name → [Menu] →

Int'l dial assist → Select a country/region →

Voice Calls: /Video Calls: [V. Call]

Call Log Operations

Highlight a call record and press [Menu].

- Available functions vary by selected log/record.

Item	Operation/Description
Notify caller ID	Notify or withhold your Caller ID (☞ P.2-3)
Prefix numbers	Add a prefix to phone number before dialing > Select an entry →
Int'l dial assist	Add international dialing prefix > Select a country/region →
Character size	Toggle font sizes
Add to Phone Book	Save number to Phone Book (☞ P.4-5)
Ring time¹	Show ring time (missed calls)
Add shortcut icon	Create shortcut (☞ P.1-20)
Compose S! Mail	Create S! Mail (☞ From Step 4 on P.14-4)
Compose SMS²	Create SMS (☞ From Step 4 on P.14-8)
Received address/Sent address	Show Received/Sent address log
Delete this/ Delete selected/ Delete all	> Delete record(s) in selected list

¹ Available only for Incoming Call Logs

² Message can be sent to SoftBank handsets only

Answer Phone

Using Answer Phone


Record up to five voice messages or up to two video messages (up to 20 seconds per message) on handset.

- When Answer Phone is active, – (Voice Call) or – (Video Call) appears in Standby.
- Unavailable when: handset is off or in Offline Mode; appears. Use Voice Mail (➡P.2-18).

Activating Answer Phone

- 1 Press and hold
 - To cancel Answer Phone, repeat operation.

<Default> OFF



Redirect a Call to Answer Phone

> [Ans. Ph] or

Note

- To set outgoing message and ring time: **Main Menu ▶ Tools ▶ Sound Recorders ▶ Answer Phone Setting ▶ ON** (➡P.2-16)
- When full, new messages cannot be recorded even if Answer Phone is activated. Delete unnecessary messages (➡Below, P.2-16).
- While Manner Mode (set for User Mode) is active, Answer Phone setting for User Mode (➡P.17-6) is prioritized.

Playing Messages from Event Indicator

When a new message is recorded, Event Indicator (➡P.1-19) appears in Standby.



- 1 Select indicator
- 2 Select a message
Playback starts.
After playback ends, indicator disappears.


Note

- Alternatively, press in Standby (for Voice Call messages) or **Main Menu ▶ Tools ▶ Sound Recorders ▶ Voice Call Data or Video Call Data ▶ Select a recording**
- While playing a message, [Erase] → YES to delete the message

Recording Calls/Playing Recordings

- Record one Voice Call (up to three minutes).
- Record up to five Video Calls (up to 20 seconds per message).

Recording Calls

- 1 During a call, press and hold 
Recording starts.
- 2 To end recording,  **[Stop]** or press and hold 

Note

- Alternatively, record a Voice Call:  **[Rec]** to start and  to end

Playing Recordings (Call Data)

Main Menu ► Tools ► Sound Recorders

- 1 **Voice Calls**
Voice Call Data → **Call Data**

Video Calls

Video Call Data → Select a recording
Playback starts.

Additional Settings

From ► Main Menu ► Tools ► Sound Recorders


Select Outgoing Message/Set Ring Time

> **Answer Phone Setting** → **ON** → Select an outgoing message →

Enter ring time

- When Answer Phone and an Optional Service (Voice Mail or Call Forwarding) are both active, function with shorter ring time takes priority. For example, if Answer Phone ring time is 18 seconds and Optional Service is 20 seconds, Answer Phone responds first (Priority may change due to signal conditions).
- Regardless of priority setting, Call Forwarding or Voice Mail takes priority when Answer Phone has reached maximum number of messages.

Delete Messages/Recordings

> **Voice Call Data** or **Video Call Data** → (Highlight a recording →)
 **[Menu]** → **Erase this**, **Erase rec. msg.**, **Erase Call Data*** or
Erase all → **YES**

* **Video Call Data** only

Optional Services

Overview

- For details, visit SOFTBANK MOBILE Corp. Website (<http://www.softbank.jp>).

Call Forwarding (☞ Right)	Forward unanswerable calls to a preset number when handset is off, out-of-range, etc.
Voice Mail (☞ P.2-18)	Unanswered calls are forwarded to Voice Mail Center as set or when handset is off, out-of-range, engaged, etc. ● Missed Call Notification (☞ P.2-19)
Call Waiting* (☞ P.2-20)	Place the current call on hold and answer a second, or alternate between calls.
Call Barring (☞ P.2-20)	Restrict incoming/outgoing Voice Calls/Video Calls and SMS messages.
Caller ID (☞ P.2-21)	Show or hide your number when calling.


* Separate subscription required.

Call Forwarding

- Call Forwarding and Voice Mail cannot be set simultaneously.
- When forwarding Video Calls, set a destination phone that supports 3G-324M standard video calls. If not, Video Calls are not forwarded.

Activating Call Forwarding

Main Menu ▶ Settings ▶ Call Settings
▶ Voice Mail/Call Fwding ▶ Call Forwarding ON

- Select a type
- Enter a destination phone number
 - Press  to select number from Phone Book.
- Select an item (See below)

Item	Operation/Description
Ringer ON	Forward missed calls > Select a ring time → YES
Ringer OFF	Forward all calls without ringing/vibrating > YES



■ Check Call Forwarding Status

> **Main Menu ▶ Settings ▶ Call Settings ▶ Voice Mail/Call Fwding**
▶ Get Status

■ Cancel Call Forwarding

> **Main Menu ▶ Settings ▶ Call Settings ▶ Voice Mail/Call Fwding**
▶ Deactivate All ▶ YES

Note

- Toll free numbers and international call numbers cannot be saved as a destination number.
- When using Call Forwarding together with Answer Phone, the function with shorter ring time takes priority (Priority may change due to signal conditions).
- When **Ringer ON** is set, following operations are available while handset is ringing (within ring time):
 - To answer call: 
 - To forward call:  [Menu] → *Call Forwarding*

Voice Mail

- Calls are forwarded to Voice Mail Center via Call Forwarding function; Call Forwarding and Voice Mail cannot be set simultaneously.
- Voice Mail is not available for Video Calls.

Activating Voice Mail

Main Menu ► **Settings** ► **Call Settings**
 ► **Voice Mail/Call Fwding** ► **Voice Mail ON**

1 Select an item (See below)

Item	Operation/Description
Ringer ON	Forward missed calls > Select a ring time → YES
Ringer OFF	Forward all calls without ringing/vibrating > YES



■ Check Voice Mail Status

> **Main Menu** ► **Settings** ► **Call Settings** ► **Voice Mail/Call Fwding**
 ► **Get Status**



■ Cancel Voice Mail

> **Main Menu** ► **Settings** ► **Call Settings** ► **Voice Mail/Call Fwding**
 ► **Deactivate All** ► **YES**

Note


- When using Voice Mail together with Answer Phone, the function with shorter ring time takes priority (Priority may change due to signal conditions).
- When **Ringer ON** is set, following operations are available while handset is ringing (within ring time):
 - To answer call: 
 - To forward call:  [Menu] → **Call Forwarding**

Checking Voice Mail Messages

Event Indicator ( P.1-19) and  appear in Standby when new messages are recorded.

1 → Select indicator → **YES**

Follow voice guidance.

Indicator and  disappear after messages are checked.



■ View Details

View callers' phone numbers and date/time Voice Mail messages were left before playing messages.

- Activate Missed Call Notification beforehand ( Right).

>  → **Voice Mail Notif.** →  [ 1416]

■ Delete Indicator

> **Main Menu** ► **Settings** ► **Call Settings** ► **Voice Mail/Call Fwding**
 ► **Delete Voice Mail Icon** ► **YES**

Note

- Alternatively, check Voice Mail: **Main Menu** ► **Settings**
 ► **Call Settings** ► **Voice Mail/Call Fwding**
 ► **Listen to Voice Mail** ► **YES**

Missed Call Notification

When Missed Call Notification function is active, **Event Indicator** appears for calls missed while handset was off, out-of-range, engaged, etc.

- Available only when Voice Mail is active.

Main Menu ► **Settings** ► **Call Settings** ► **Missed Call Notifi.**


1 **YES**

Handset connects to the Network.

Follow voice guidance.

When Calls are Received while Missed Call Notification is Active...

Event Indicator appears for missed calls when handset is turned on or comes into range. Select indicator to view Missed Calls.

- **Voice mail** Event Indicator appears when Voice Mail messages are recorded ( Left).



Call Waiting

Activating/Canceling Call Waiting

Main Menu ► Settings ► Call Settings ► Call Waiting

1 **Activate** or **Deactivate** → YES




Current status appears.

■ Check Call Waiting Status

> Main Menu ► Settings ► Call Settings ► Call Waiting
► Get Status

Answering Second Call

1 When tone sounds,

- Press  to alternate between calls.
- Press  to disconnect active call.
- When the party hangs up, active call ends.
- Press  to re-engage the party on hold.
- When a second call comes in while first call is on hold, hold status is canceled and first call resumes.

■ Reject Second Call

> When tone sounds,  [Menu] → **Call Rejection**

Note

- When Voice Mail or Call Forwarding is set to **Ringer ON** while Call Waiting is active, unanswered calls are transferred to Voice Mail Center or the forwarding number.
- When Voice Mail or Call Forwarding is set to **Ringer OFF**, Call Waiting is disabled.

Call Barring

- **Bar All Outgoing** and **Bar All Incoming** are not available when Call Forwarding or Voice Mail is active (Call Forwarding or Voice Mail takes priority).
- Security Code is required (☎P.1-26).

Activating/Deactivating Call Barring

Main Menu ► Settings ► Call Settings ► Call Barring

1 Select an item (See below)

Item	Operation/Description
Bar All Outgoing	Restrict all non-emergency calls
Bar All Int'l	Allow only domestic calls
Bar Int'l	Restrict all international calls except to Japan
Bar All Incoming	Reject all calls
Bar All Roaming	Reject calls when outside Japan

2 **Activate** or **Deactivate** → **YES**

3 Enter Security Code

■ **Check Call Barring Status**

> After Step 1, **Get Status**

■ **Cancel All Call Barring**

> In Step 1, **Cancel All Barring** → Enter Security Code

■ **Change Security Code**

> In Step 1, **Set Security Code** → Enter current Security Code → Enter new Security Code → Reenter Security Code

Note

- Emergency numbers (110, 119, 118) are dialable even while Call Barring for outgoing calls is active.
- If call is attempted when Call Barring is active, warning message appears. It may take longer to appear in some areas. Check Call Barring settings if the message does not appear.

Caller ID

<Default> Network Set

Main Menu ► Settings ► Call Settings

► Show My Number ► Activate

1 **ON, OFF** or **Network Set**

- **Network Set** Caller ID setting varies by subscription.

■ **Check Caller ID Status**

> Main Menu ► Settings ► Call Settings ► Show My Number
► Check Setting

Note

- Alternatively, enter these numbers/symbols before the phone number to show or hide Caller ID:

Show: (1) (8) (6) or (*) (3) (1) (#)

Hide: (1) (8) (4) or (#) (3) (1) (#)

