

Mail



5


Overview	5-2
Sending Messages	5-3
Sending S! Mail	5-3
Graphic Mail	5-3
Attaching Files	5-5
Saving Addresses to Mail Member	5-6
Using Itsumono-Mail	5-6
Sending SMS Messages	5-7
Receiving & Opening Messages	5-9
Opening New Messages	5-9
Opening Inbox Messages	5-9
Replying to Messages	5-10
Using Mail List	5-10
Handling Messages	5-12
Message Folders	5-12
Opening Sent & Received Messages	5-12
Sorting Messages	5-14
Prohibiting Access to Messages	5-14
Saving S! Mail Attachments	5-15
Advanced Features	5-17
Sending Messages	5-17
Receiving/Opening Messages	5-20
Managing/Using Messages	5-21



Overview

Handset supports SMS and S! Mail.

5
Mail



Server

- If recipient's handset is turned off or out of range, sent message is stored on the server up to 30 days until the recipient's handset becomes available.

Available Mail Services

SMS

Exchange short text messages with other SoftBank handsets.

S! Mail (Separate contract required)

Exchange long text messages with S! Mail compatible SoftBank handsets and other e-mail compatible mobile phones and PCs. Images and melodies can also be attached to S! Mail.

Customize Handset E-mail Address.

Effective for blocking spam.

Graphic Mail

Use HTML mail to change font size/color, background, etc.

Special Template

Graphic Mail templates are awarded based on the number of sent or received Graphic Mail.

Itsumono-Mail

Save custom-created message templates.



Sending S! Mail

1 Press and hold



S! Mail Composition Window


2 → ● → **Enter Address** → ●

● → **Enter address** → ●

To add more recipients, Select , press ● and repeat the same step.

3 → ● → **Enter subject** → ●

4 → ● → **Enter text** → ●



S! Mail Text Entry Window

5

■ To Cancel Transmission

→ When **Start Packet Connection** appears → ●

Alternatively, press during transmission.

■ If **Resend mail?** Appears

→ **YES** → ●

Tip

- Add up to 20 recipients total between To, Cc and Bcc fields.

Graphic Mail

Create html messages to change font color/size and background color. Add scrolling text, paste images, etc.

<Example> Change font size, background color, insert an image and set flashing text.

1 [S! Mail Text Entry Window] →

→ → ● → Select a font size → ● → Enter text → ●

2 → ● → → Select a

background color → ●

Press to toggle between 25-color and 256-color palettes.

3 → ● → Select a folder → ●

→ Select an image → ●

■ Inserting Images with Large File Size

→ **Insert Mail** or **SubQCIF Scale Down** → ● (→ Check an image → ●)

4 → ● → → ● → Enter text → ●

→ → ● → → ●


5 → ●



Entering My Pictograms

1 [S! Mail Text Entry Window] ⇨

2 or to select **MyPict** tab



My Pictograms Entry Window

3 to select a pictogram ⇨

4 CLEAR

Handset returns to S! Mail Text Entry window.

Using Predictions

Use predictions to quickly enter My Pictograms.

<Example> Entering “はなび” (fireworks)

- The following example is in Japanese text entry mode.

1 [S! Mail Text Entry Window] ⇨

Enter “はなび” ⇨

2 to select a pictogram ⇨

Use or to toggle prediction candidates for My Pictograms and Mail Art.

Note

- Downloaded My Pictograms do not appear in predictions.

Tip

- Enter a My Pictograms category name and press to open a list of matching My Pictograms.

Categories

My Pictograms are categorized for quick entry of target items.


<Example> Entering “ハート” (heart)

- The following example is in Japanese text entry mode.

1 [My Pictograms Entry Window] ⇨



A category appears in a list.



2 ⇨ はーと ⇨

Use or to toggle page or category.

■ To Enter From History

⇨ ⇨ History ⇨

3 Select a pictogram ⇨



Special Template

Access to a Special Template (original Graphic Mail template) is awarded, based on the number of sent/received Graphic Mail (see chart below).

Sent Message Count	3, 30, 60, 90, 120, 150, 200, 250, 300, 350
Received Message Count	1, 25, 75, 100, 150, 250, 400, 500

A notification appears when a Special Template is awarded.

<Example> When three Graphic Mail messages are sent

- 1 **Select notification**

An animation appears.

- 2 **or**



Template List

Special Template files are saved in **Templates**. appears for Special Template.

Note

- Special Template files not yet available also appear in **Templates**. Once the required sent/received count is achieved these templates become accessible.
- Initializing handset resets sent/received message count and Special Template access becomes unavailable again.

Tip

- To access Graphic Mail templates:
 Templates

Attaching Files

Attach the following files to S! Mail:

- Images
- Melodies
- Phone Book entries
- Schedule (To Do List)
- Videos
- Music (Songs)
- Account Details
- Bookmarks

- For information about image, video, melody and music files, see P. 12-2.

1 [S! Mail Composition Window]



2 Select a file type (Enter Security Code) Select a file



■ Images with Large File Size

Attach Mail or QVGA Scale Down

(Check an image)

Note

- Copy protected files cannot be sent as attachments or output to external devices.

Tip

- To open or play an attached file:
Select the file



Mail

Mail

- Mail



Mail

- Mail



Mail

- Mail

- Mail

- Mail

Mail

Mail

Mail

- Mail



Mail

- Mail

- Mail

- Mail

Mail

Mail

Mail

- Mail

Mail

- Mail

Mail

Mail

- Mail

- Mail

Mail

Mail


- Mail



Sending Itsumono-Mail

1

Default template is selected. To send a different template, manually select the template.



2

Sending SMS Messages

Send short text messages to SoftBank handsets, using recipient's phone number.

1 **Compose SMS**



SMS Composition Window

2 **Enter Address**
Enter phone number

3 **Enter text**

4

More Features

Advanced

Composing Messages

- Enter Address from Phone Book
- Enter Address from Sent/Received Address List
- Enter Address from Mail Member List
- Set To, Cc or Bcc
- Delete an Address
- Insert Header/Signature
- Set Default Input Language for SMS
- Delete Text
- Change SMS Message to S! Mail

P. 5-17

Sending Messages

- Set Priority (S! Mail)
- Server Storage Period (SMS)
- Request Delivery Report
- Save Messages to Draft
- Quit Composing and Delete Message

P. 5-18

Attaching Files

- Capture and Attach Still Image/Video
- Delete S! Mail Attachments

P. 5-18



Sending Messages

Mail Member

- Edit an Address
- Delete Addresses from a Mail Member List
- Edit a Mail Member List Name
- Reset a Mail Member List Name

(▶ P. 5-18)

SMS Settings

- Request Delivery Report
- Set Server Storage Period of SMS Messages
- Set SMS Input Language

(▶ P. 14-16)

Graphic Mail

- Add/Edit Text Decoration
- Undo
- Preview Graphic Mail
- Cancel All Decoration
- Instantly Convert S! Mail to Graphic Mail
- Save Graphic Mail as a Template
- Download Templates
- Create Graphic Mail from a Template
- Edit a Template
- Edit Title of a Template
- Delete Templates

(▶ P. 5-19)



Customize

Display Settings

- Set an Outgoing Message Image

(▶ P. 14-4)

S! Mail Settings

- Edit Header/Signature
- Insert Header/Signature Automatically
- Request Delivery Report

(▶ P. 14-16)




Opening New Messages

Received Result window opens for new messages.

Emotion-Expressing Mail

When a message is received, a pictogram matching the message content appears in Received Result Window and Message List. Set the Keyword setting on, to show Keyword indicators when messages include user-set keywords (P. 14-16).



Indicator/
Pictogram

Received Result Window

● Pictograms

	Hurry		Advice
	Like		Cheer
	Dislike		Join
	Happy		Impression
	Angry		Request
	Sad		Notice
	Fun		OK
	Surprise		Reply
	Question		Other

1 [Received Result Window] → Mail
→ ●

2 Select a message → ●

Note


- By default, complete S! Mail messages (including attachments) are automatically retrieved. Transmission fees apply, depending on your subscription plan. While traveling abroad, message retrieval may incur high transmission fees.

Tip

- Alternatively open new messages from desktop notification.
- When **Mail** under **Sub-display Setting** is set to **ON**, press **977** with handset closed to check the subject of new messages.
- Indicator may not always correspond to message content.
- appears if message content does not match any of the above moods or information.

Opening Inbox Messages

1 → **Inbox** → ●



Folder List



Receiving & Opening Messages

2 Select a folder ⇨ ●



Message List

3 Select a message ⇨ ●



Message Window

To check previous/next message, press
⌂.

Tip

- Some attachments may require content keys to open/play the file.

Replying to Messages

1 [Inbox Message List] ⇨ Select a message ⇨ ● ⇨ ✉

■ When Original Message Has Multiple Recipients

⇨ To Sender or To All ⇨ ●

2 Edit subject/text ⇨ ✉

Replying (Quote Message)

1 [Inbox Message List] ⇨ Select a message ⇨ ● ⇨ ✉

■ When Original Message Has Multiple Recipients

⇨ To Sender or To All ⇨ ●

2 Edit subject/text ⇨ ✉

Note

- If *To All* is selected, your address is also included in the reply. Save your address to Account Details (P. 1-21) to exclude your address as a destination.


Tip

- Attachments are automatically deleted from reply messages.
- Quoting text is available only for S! Mail replies.

Using Mail List

Retrieve Mail List and select messages to download or forward.

1 ✉ ⇨ **Server Mail** ⇨ ● ⇨ **Mail List** ⇨ ● (⇨ YES ⇨ ●)



Mail List

2 Select a message ⇨ ● ⇨ **Message Receive** ⇨ ●

▶ To Receive a Message
Receive This ⇨ ●

▶ To Receive Multiple Messages
Receive Selected ⇨ ● ⇨ Select messages ⇨ ● ⇨ ✉

▶ To Receive All Messages
Receive All ⇨ ●



Tip

- If download fails while retrieving all messages, download is canceled.
- When there is only one message, message opens upon retrieval.

More Features

Advanced

Receiving Messages

- Manually Retrieve Messages (S! Mail)

(▶ P. 5-20)

Checking Messages

- Retrieve Complete S! Mail Manually
- Delete S! Mail from Server
- Read Out Messages
- Check Message Information

(▶ P. 5-20)

Server Message Operations

- Update Mail List
- Switch Mail List Views
- Check Server Message Information (S! Mail)
- Forward a Server Message (S! Mail)
- Delete Server Messages (S! Mail)
- Check Server Memory Status

(▶ P. 5-20)

Customize

Display Settings

- Set Image or Video for Incoming Message
- Set Image for New Message/Received Result Window
- Show New Message Info While Viewing TV

(▶ P. 14-4)

Incoming Message Alerts

- Adjust Ringtone Volume
- Set a Ringtone
- Set Random Playback of Melodies as Ringtones
- Set Ringtone Duration for Incoming Message
- Set Vibration
- Set Illumination Color
- Set Illumination Pattern
- Set Illumination to Flash for New Messages
- Set Handset Action When Handset Opened
- Set an Incoming Message Image

(▶ P. 14-8)

Incoming Message Settings

- Customize E-mail Address
- Do Not Show Emotion Indicators
- Show Keyword Indicators
- Delete Keywords
- Set Priority When Receiving Messages during Operation
- Read Out Received Mail (Text to Speech) Setting
- Set Voice to Read Out Messages
- Manually Retrieve Complete Messages

(▶ P. 14-16)

Reply Settings

- Quote Message Marks


(▶ P. 14-17)



Message Folders

Press to open Mail Menu.

Sent, received and draft messages are saved in the locations below.




Mail Menu

- Received messages
- Sent messages
- Draft messages

Opening Sent & Received Messages

<Example> Open a Sent Message

1 **Outbox**




Folder List

2 Select a folder



Message List

3 Select a message



Message Window

To check previous/next message, press .

Tip


- When Outbox/Inbox is full, old messages are deleted in order of Trash Box then Outbox/Inbox when a new message is sent or received. Unread and protected messages and Secret Folder messages are not deleted.




Windows & Indicators

Check message status, attachment type, etc. by indicators.


Folder Lists



Message Lists



Message Windows



①	Folder Type General Folder Trash Box Secret Folder
②	Message Status Unread Read Protected (Unread) Protected (Read) Forwarded Replied Sent to a Single Recipient Sent to Multiple Recipients
③	Message Type SMS on Handset SMS on USIM Card S! Mail Notification Attachment Type Image Video Melody (Tones/Ringtones) Music Copy-protected File Phone Book Entry, Account Details, Schedule Event or Bookmark Forwarded Server Mail Others Multiple Files

The following marks appear on indicators to inform you:

- Folder Contains Unread Messages
- Locked Folder
- Folder with Auto Sort Set
- Protected Message
- Delivery failed to Some Recipients or Some Attachments Deleted
- Delivery Failed/All Attachments Deleted
- Attachment Deleted
- High Priority S! Mail

Tip

- To open/play copy-protected files, save files to Data Folder.
- appears in **Subject** field when Delivery Report is received.



Sorting Messages

Automatically sort incoming/outgoing messages into folders.

- 1 [Folder List] → Select a folder → → **Auto-sort** →

▶ To Sort by Address

Address Sort → → **Look-up Address, Look-up Group, Look-up Member or Enter Address** →

▶ To Sort by Subject

Subject Sort → → Enter subject →

▶ To Sort by Reply Failed, Send Failed or Unregistered Address
Reply Impossible, Send Impossible or Unregistered Add. →

Tip

- Only one Inbox folder can be specified for sorting *Reply Impossible* messages.
- Only one Outbox folder can be specified for sorting *Send Impossible* messages.
- Only one Inbox/Outbox folder can be specified for sorting *Unregistered Add.* messages.
- Search addresses from Phone Book, Received/Sent Address List in *Look-up address*.

Canceling Auto Sort

- 1 [Folder List] → Select a folder → → **Auto-sort** →

- 2 Select a criterion → → **Release** →

▶ To Cancel a Criterion

Release This → → **YES** →

▶ To Cancel Multiple Criteria

Release Selected → → Select criteria → → **YES** →

▶ To Cancel All Criteria

Release All → → **YES** →

Prohibiting Access to Messages

Setting Mail Box Lock

- 1 → **Mail Setting** →

- 2 **Mail Box Lock** → → Enter Security Code →

- 3 Select a mail box →
Repeat Step 3 to specify other boxes.

- 4

Setting Folder Lock

- 1 [Folder List] → Select a folder → → **Folder Lock** → → Enter Security Code → → **YES** →
 appears for locked folders.

Tip

- Repeat the same procedure to cancel mail box and folder lock.
- Lock Trash Box to require password for access.
- Security Code entry is required to view messages in locked mail boxes and folders.



Storing Messages in Secret Folders

- Set handset to Secret Mode or Secret Data Only Mode beforehand (P. 4-6).
- Unread Messages, S! Mail with Text Unreceived or delivery reports cannot be stored in Secret Folders.

- 1 [Message List] → Select a message → [icon] → **Keep in Secret** → [icon]**
 - ▶ **To Store a Message**
Keep This → [icon]
 - ▶ **To Store Multiple Messages**
Keep Selected → [icon] → Select a message → [icon] (repeat to select another message) → [icon] → **YES** → [icon]
 - ▶ **To Store All Messages in a Folder**
Keep All → [icon] → **YES** → [icon]

Returning Messages in Secret Folders to Ordinary Messages

- 1 [Folder List] → **Secret** → [icon]**
- 2 Select a message → [icon] → **Put Out** → [icon]**
 - ▶ **To Return a Message**
Put Out This → [icon] → Select a folder → [icon]

- ▶ **To Return Multiple Messages**
Put Out Selected → [icon] → Select a folder → [icon] → Select a message → [icon] (repeat to select another message) → [icon] → **YES** → [icon]
- ▶ **To Return All Messages**
Put Out All → [icon] → Select a folder → [icon] → **YES** → [icon]

Saving S! Mail Attachments

Saving Image, Video, Melody, Music and Flash® Files

<Example> Save an image

- 1 [Message Window] → Select a file → [icon] → **Save Data** → [icon] → **YES** → [icon]**
- 2 Select a folder → [icon]**
- 3 **YES** or **NO** → [icon] (→ Select an item → [icon] (→ Select a view → [icon] → Check an image → [icon]))**

Saving an Image Inserted in Text

- 1 [Message Window] → [icon] → **Save Insert Image** → [icon]**
- 2 Select an image → [icon] → **YES** → [icon] → Select a folder → [icon]**
- 3 **YES** or **NO** → [icon] (→ Select an item → [icon] (→ Select a view → [icon] → Check an image → [icon]))**

Saving a Phone Book Entry

- 1 [Message Window] → Select contact information (a phone number, etc.) → [icon] (twice) → **Phone** or **USIM** → [icon] → **New** → [icon]**
- 2 Edit each item → [icon]**

Saving a Schedule Event

- 1 [Message Window] → Select Schedule events → [icon] (twice)**



Saving a Bookmark

- 1 [Message Window] ⇒ Select a link (URL, etc.) ⇒ ● (twice) ⇒ Select a destination ⇒ ● ⇒ Select a folder ⇒ ●

Note

- Mail-attached phone book entries, schedule events or bookmarks cannot be saved to *microSD*.

More Features

Advanced

Managing Messages

- Protect a Message
- Move Messages to a Different Folder
- Move Messages to Trash Box
- Delete Messages
- Delete All Read Messages
- Delete All Delivery Reports
- Report as Spam
- Delete Attached Files
- Copy SMS Messages between Handset and USIM Card
- Delete SMS Messages on USIM Card
- Change Message Color
- Add a Folder
- Edit a Folder Name
- Change Order of Folders
- Delete a Folder
- Check Number of Saved Messages
- Check Sent/Received Addresses

▶ P. 5-21

Using Messages

- Edit a Sent Message
- Edit & Send a Draft Message
- Forward a Message
- Save Sender, Recipient's E-mail Address or Phone Number to Phone Book
- Call a Phone Number in Text
- Send an S! Mail to an E-mail Address in Text
- Access the Internet from a URL in Text

- Save Number/Address in Text to Phone Book
- Search Information by Keyword
- Switch Subject Field Views
- Change Message Font Size
- Search for Messages in a Folder
- Sort Messages
- Filter Messages
- Return Message List View to Default
- Switch All Unread Messages to Read Messages
- Open S! Mail Delivery Report
- Check Attachment Properties (Image File)

▶ P. 5-23

Customize

Message Window/Messaging Settings

- Set Message List View
- Set Auto-Play for Melody Attachments
- Set Scroll Unit
- Set Font Size
- Change Address for Reporting Spam
- Check Mail Settings
- Restore to Default Settings

▶ P. 14-17

SMS Server Settings

- Change SMS Center Address
- Reset to SoftBank SMS Center Address

▶ P. 14-18



Sending Messages

Start Here

[S! Mail Composition Window].....	P. 5-3
[S! Mail Text Entry Window].....	P. 5-3
[Mail Member List]	P. 5-6
[Mail Member Window]	P. 5-6
[SMS Composition Window]	P. 5-7

Composing Messages

Enter Address from Phone Book

[S! Mail Composition Window]/[SMS Composition Window] ⇨ **To** ⇨ ● ⇨ **Phonebook** ⇨ ● ⇨ Search Phone Book ⇨ Select Phone Book ⇨ ● ⇨ Select an e-mail address or phone number ⇨ ●

Enter Address from Sent/Received Address List

[S! Mail Composition Window]/[SMS Composition Window] ⇨ **To** ⇨ ● ⇨ **Sent Address or Received Address** ⇨ ● ⇨ Select an e-mail address/phone number ⇨ ● (twice)
 Alternatively, select **To** and press ⌘ to open Sent/Received Address List.

Enter Address from Mail Member List

[S! Mail Composition Window] ⇨ **To** ⇨ ● ⇨ **Mail Member** ⇨ ● ⇨ Select a Mail Member list ⇨ ●
 All addresses in the selected Mail Member list are entered in the Address field.
 You must save addresses to a Mail Member list in advance.

Set To, Cc or Bcc

[S! Mail Composition Window] ⇨ **To** ⇨ ● ⇨ Select an address ⇨ ● ⇨ **Change Rcv. Type** ⇨ ● ⇨ **To, Cc or Bcc** ⇨ ●
 Cc (Carbon copy): S! Mail copies are sent to other addresses. Addresses in the Cc field are revealed to the other recipients.
 Bcc (Blind carbon copy): S! Mail copies are sent to other addresses. Addresses in the Bcc field are hidden to the other recipients.
 When there is no address in the To field, the message cannot be sent.

Delete an Address

[S! Mail Composition Window] ⇨ **To** ⇨ ● ⇨ Select an address ⇨ ● ⇨ **Delete Receiver** ⇨ ● ⇨ **YES** ⇨ ●

Insert Header/Signature

[S! Mail Composition Window] ⇨ ● ⇨ **Add Header or Add Signature** ⇨ ●
 Save header/signature in advance.

Set Default Input Language for SMS

[SMS Composition Window] ⇨ ● ⇨ **SMS Input Char.** ⇨ ● ⇨ **Japanese or English** ⇨ ●

Delete Text

[S! Mail Composition Window]/[SMS Composition Window] ⇨ ● ⇨ **Erase Message** ⇨ ● ⇨ **YES** ⇨ ●

Change SMS Message to S! Mail

[SMS Composition Window] ⇨ ● ⇨ **S! Mail Conversion** ⇨ ●



Advanced Features

Sending Messages

Set Priority (S! Mail)

[S! Mail Composition Window] → [Priority] → [High, Normal or Low]

Server Storage Period (SMS)

[SMS Composition Window] → [Valid. Per.] → [Select a period]

Specify a period the SMS message is stored in the server in case it fails to reach the recipient because the recipient's handset is out of range, etc.

When **None** is set, the SMS message is deleted from the server after it is resent once in a certain period of time.

Request Delivery Report

[S! Mail Composition Window]/[SMS Composition Window] → [Delivery Report or SMS Report Req.] → [ON or OFF]

When **ON** is set, handset receives a delivery report.

Save Messages to Draft

[S! Mail Composition Window]/[SMS Composition Window] → [Save] → [The message is saved to **Draft**. Messages saved in **Draft** can be edited and sent at a later time.]

Quit Composing and Delete Message

[S! Mail Composition Window]/[SMS Composition Window] → [Delete] → [YES]

Attaching Files

Capture and Attach Still Image/Video

[S! Mail Composition Window] → [Activate Camera] → [Photo Mode or Movie Mode] → [Shoot image/video]

Delete S! Mail Attachments

[S! Mail Composition Window] → [Delete Att. File or Del All Att.Files] → [YES]

Mail Member

Edit an Address

[Mail Member Window] → [Select an address] → [Edit address]

Delete Addresses from a Mail Member List

[Mail Member Window] → [Select an address]

- To Delete the Selected Address → [Delete This] → [YES]
- To Delete All → [Delete All] → [Enter Security Code] → [YES]

Edit a Mail Member List Name

[Mail Member List] → [Select a Mail Member list] → [Edit Member Name] → [Edit name]

Reset a Mail Member List Name

[Mail Member List] → [Select a Mail Member list] → [Reset Member Name] → [YES]



Graphic Mail

Add/Edit Text Decoration

[S! Mail Text Entry Window] → → → ● → Select beginning of characters → ● → Select end of characters → ● → Select effects menu → ● → Apply or Change effects
 Select , press , select **YES** and then press ● to select the entire text.

Undo

[S! Mail Text Entry Window] → → → ●

Preview Graphic Mail

[S! Mail Text Entry Window] → → → ● → or to close preview

Cancel All Decoration

[S! Mail Text Entry Window] → → → ● → **YES** → ● (→ ●)

Instantly Convert S! Mail to Graphic Mail

[S! Mail Text Entry Window] → Enter text → Press and hold → to toggle selections → ●

Pictographs, graphic items, and effects are automatically selected, based on content of entered text (available in Japanese entry mode).

Alternatively, press , select and then press ● to convert to Graphic Mail.

In Preview window, press to toggle pictographs and emoticons on/off.

Save Graphic Mail as a Template

[S! Mail Text Entry Window] → Enter text → ● → → **Template** → ● → **Save Template** → ● → **YES** → ●

Attached files except images inserted in text are not included in a template.

Save up to 1,000 templates including downloads. Delete saved templates as needed.

Download Templates

→ **Templates** → ● → **Download Templates** → ● → **YES** → ● → Follow onscreen instructions

Create Graphic Mail from a Template

→ **Templates** → ● → Select a template → ● →

Edit a Template

→ **Templates** → ● → Select a template → ● → → **Edit** → ● → Edit text → ● (twice) → **YES** or **NO** → ●

Edit Title of a Template

→ **Templates** → ● → Select a template → → **Edit Title** → ● → Edit title → ●

Delete Templates

→ **Templates** → ● → Select a template → → **Delete** → ●

● To Delete the Selected Template

→ **Delete This** → ● → **YES** → ●

● To Delete Multiple Templates

→ **Delete Selected** → ● → Select templates → ● → → **YES** → ●

● To Delete All

→ **Delete All** → ● → Enter Security Code

→ ● → **YES** → ●



Advanced Features

Receiving/Opening Messages

Start Here

[Message List] P. 5-10
 [Message Window] P. 5-10
 [Mail List] P. 5-10

Receiving Messages

Manually Retrieve Messages (S! Mail)

☺ ➔ **Retrieve New** ➔ ● ➔ Received
 Result window opens ➔ **Mail** ➔ ● ➔
 Select a message ➔ ●
 ☞ Press (Y) or press and hold (CLEAR) to cancel message retrieval.
 ☞ Retrieve messages that were stored on the server while handset was off or out of range.

Checking Messages

Retrieve Complete S! Mail Manually

[Message List] ➔ Select an S! Mail notification ➔ ● ➔ ☺
 ☞ S! Mail notification is deleted when you retrieve the complete message.
 ☞ Manually retrieve complete messages when **Message Download** is set to **Manual** (S! Mail Settings, P. 14-17).

Delete S! Mail from Server

[Message List] ➔ Select an S! Mail notification ➔ ● ➔ ☺ ➔ **Delete** ➔ ● ➔
 ➔ **Notification, Server Mail or Notifi./Server** ➔ ● ➔ YES ➔ ●

Read Out Messages

[Message Window] ➔ ☺ ➔ **Read Out Message** ➔ ●
 ☞ Press ● to stop reading.
 ☞ Press ☺ to end reading.

Check Message Information

[Message List] ➔ Select a message ➔ ☺ ➔
Mail Info ➔ ●

Server Message Operations

Update Mail List

[Mail List] ➔ ☺ ➔ **Mail List** ➔ ●

Switch Mail List Views

[Mail List] ➔ ☺ ➔ **List Setting** ➔ ● ➔
Subject, Name or Address ➔ ●

Check Server Message Information (S! Mail)

[Mail List] ➔ Select a message ➔ ☺ ➔
Mail Info ➔ ●

Forward a Server Message (S! Mail)

[Mail List] ➔ Select a message ➔ ☺ ➔
Forward ➔ ● ➔ To ➔ ● ➔ Enter address ➔ ☺

Delete Server Messages (S! Mail)

[Mail List] ➔ Select a message ➔ ☺ ➔
Delete ➔ ●
 ● To Delete the Selected Message
 ➔ **Delete This** ➔ ● ➔ YES ➔ ●
 ● To Delete Multiple Messages
 ➔ **Delete Selected** ➔ ● ➔ Select messages ➔ ● ➔ ☺ ➔ YES ➔ ●
 ● To Delete All
 ➔ **Delete All** ➔ ● ➔ Enter Security Code ➔ ● ➔ YES ➔ ●

Check Server Memory Status

☺ ➔ **Server Mail** ➔ ● ➔ **Server Mail Memory** ➔ ●



Managing/Using Messages

Start Here

[Folder List]	P. 5-12
[Message List]	P. 5-12
[Message Window]	P. 5-12
[Inbox Folder List]	P. 5-13
[Inbox Message List]	P. 5-13
[Received Message Window]	P. 5-13
[Sent Message Window]	P. 5-13

Managing Messages

Protect a Message

[Message Window] → [Protect ON/OFF] → [Protect ON/OFF]

ⓘ If a message is protected, this procedure cancels protection.

Move Messages to a Different Folder

[Message List] → Select a message → [Move]

Move → [Move]

- To Move the Selected Message
→ **Move This** → [Select a destination folder] → **YES** → [OK]
- To Move Multiple Messages
→ **Move Selected** → [Select a destination folder] → [Select messages] → **YES** → [OK]
- To Move All
→ **Move All** → [Select a destination folder] → **YES** → [OK]

ⓘ A message can also be moved to a different folder from Message window.

Move Messages to Trash Box

[Message List] → [Move to Trash Box] → [Select messages] → **YES** → [OK]

ⓘ Protected messages and delivery reports cannot be moved to Trash Box.

Delete Messages

[Folder List] → [Delete All] → [Enter Security Code] → **YES** → [OK]
[Message List] → Select a message → [Delete] → [Delete]

- To Delete the Selected Message
→ **Delete This** → [Enter Security Code] → **YES** → [OK]
- To Delete Multiple Messages
→ **Delete Selected** → [Select messages] → **YES** → [OK]
- To Delete All
→ **Delete All** → [Enter Security Code] → **YES** → [OK]

ⓘ Protected messages cannot be deleted.

Delete All Read Messages

[Inbox Folder List] → [Delete Read] → **YES** → [OK]

[Inbox Message List] → [Delete] → **Delete Read** → **YES** → [OK]

ⓘ Protected messages cannot be deleted.

Delete All Delivery Reports

[Inbox Message List] → [Delete] → **Delete All Reports** → [Enter Security Code] → **YES** → [OK]

ⓘ Protected delivery reports cannot be deleted.



Advanced Features

Report as Spam

[Message List]/[Received Message Window]

⇒ Select a message) ⇒ ⇒ **Report**

Spam ⇒ ⇒

Header/signature is not inserted, regardless of *Insert Setting*.

Delete Attached Files

[Message Window] ⇒ Select attached files

⇒ ⇒ **Delete Att. File** or **Del All Att. Files**

⇒ ⇒ **YES** ⇒

Copy SMS Messages between Handset and USIM Card

⇒ **Tools** ⇒ ⇒ **USIM Operation** ⇒

⇒ Enter Security Code ⇒ ⇒ **Copy**

⇒ ⇒ **Phone→USIM** or **USIM→Phone** ⇒

⇒ **SMS** ⇒ ⇒ **Inbox** or **Outbox** ⇒

⇒ Select a folder ⇒ ⇒ Select an SMS

message ⇒ ⇒ **YES** ⇒

Delete SMS Messages on USIM Card

⇒ **Tools** ⇒ ⇒ **USIM Operation** ⇒

⇒ Enter Security Code ⇒ ⇒ **Delete**

⇒ ⇒ **USIM** ⇒ ⇒ **SMS** ⇒

Inbox or **Outbox** ⇒ ⇒ Select a folder

⇒ ⇒ Select an SMS message ⇒

⇒ **YES** ⇒

Change Message Color

[Message List] ⇒ Select a message ⇒ Press and hold

Each time you press and hold , the message color toggles as follows: Red → Blue → Default (Black)

Add a Folder

[Folder List] ⇒ ⇒ **Add Folder** ⇒

Enter folder name ⇒ ⇒ **YES** or **NO** ⇒

(⇒ **Address Sort, Subject Sort, Reply**

Impossible, Send Impossible or

Unregistered Add. ⇒ ⇒ Make auto

Sort settings ⇒ ⇒ **YES** or **NO** ⇒

Edit a Folder Name

[Folder List] ⇒ Select a folder ⇒ ⇒ **Edit**

Folder Name ⇒ ⇒ Edit folder name ⇒

Preinstalled folders cannot be renamed.

Change Order of Folders

[Folder List] ⇒ Select a folder ⇒ ⇒ **Sort**

Folder ⇒ ⇒ Select a position ⇒

The order of preinstalled folders cannot be changed.

Delete a Folder

[Folder List] ⇒ Select a folder ⇒ ⇒

Delete Folder ⇒ ⇒ Enter Security Code

⇒ ⇒ **YES** ⇒

Folders containing protected messages and preinstalled folders cannot be deleted.

This procedure also deletes messages stored in the folder.

Auto Sort settings are also canceled when you delete a folder with Auto Sort settings.

Check Number of Saved Messages

[Folder List]/[Message List] ⇒ ⇒ **No. of Messages** ⇒

Check number of total, unread, protected and USIM Card SMS Messages.

Folder List: The total of all folders.

Message List: The total of the selected folder.

Check Sent/Received Addresses

Press and hold or press and hold ⇒

Select an entry ⇒



Using Messages

Edit a Sent Message

[Sent Message Window] → → Edit address, subject and text →

Edit & Send a Draft Message

→ **Draft** → → Select a message → → Edit address, subject and text →

Forward a Message

[Received Message Window] → → **Forward** → (twice) → Enter address →
 Edit subject and text as needed.
 Attached files are forwarded.

Save Sender, Recipient's E-mail Address or Phone Number to Phone Book

[Message Window] → → **Address List** → → Select an e-mail address/phone number → → **Save Address** → → **YES** →

- To Save to Handset
 → **Phone** → → Select store method → (→ Search Phone Book → Select Phone Book → (twice)) → Edit items → (→ **YES** or **NO** → (→ Enter entry number →
- To Save to USIM Card
 → **USIM** → → Select store method → (→ Search Phone Book → Select Phone Book → (twice)) → Edit items → (→ **Overwrite** or **Add** → (→ **YES** or **NO** →

Call a Phone Number in Text

[Message Window] → Select a phone number → → **Voice Phone** or **Video Call** → → **Dial** →

Send an S! Mail to an E-mail Address in Text

[Message Window] → Select an e-mail address → → Compose S! Mail →

Access the Internet from a URL in Text

[Message Window] → Select a URL → → **YES** →

Save Number/Address in Text to Phone Book

[Message Window] → Select an e-mail address/phone number → → **Add to Phonebook** → → **YES** →

- To Save to Handset
 → **Phone** → → Select store method → (→ Search Phone Book → Select Phone Book → (twice)) → Edit items → (→ **YES** or **NO** → (→ Enter entry number →
- To Save to USIM Card
 → **USIM** → → Select store method → (→ Search Phone Book → Select Phone Book → (twice)) → Edit items → (→ **Overwrite** or **Add** → (→ **YES** or **NO** →

Search Information by Keyword

[Message Window] → → **Quick Search** → → **Enter Keyword** → → Enter keyword → → Search → → Select an item from search results →



Advanced Features

5

Mail

Switch Subject Field Views

[Message List] → Press and hold [F5]

When *Mail List Disp.* is set to *2 Lines*, view toggles in the order Name → Address.

When *Mail List Disp.* is set to *1 Line*, or to *1 Line+Body*, the view cycles as follows:
Subject → Name → Address

Change Message Font Size

[Message Window] → Press and hold [F12]

Search for Messages in a Folder

[Message List] → [F3] → *Search Mail* → [F3] → *Search Sender, Search Receiver* or *Search Subject* → [F3] (→ Select a search criterion → [F3] → Select an address, enter address or subject → [F3])

Narrow down search results by repeating the search operation.

This procedure can be combined with *Sort* or *Filter*.

Sort Messages

[Message List] → [F4] → *Sort* → [F4] → [F5]

Select a criterion → [F5]

This procedure can be combined with the *Search Mail* or *Filter*.

Filter Messages

[Message List] → [F6] → *Filter* → [F6] → [F5]

Select a criterion → [F5]

This procedure can be combined with *Search Mail* or *Sort*.

Return Message List View to Default

[Message List] → [F7] → *Display All* → [F7]

Switch All Unread Messages to Read Messages

[Inbox Message List] → [F8] → *Read All* → [F8] → *YES* → [F8]

Open S! Mail Delivery Report

[Sent Message Window] → [F9] → *Disp. Report* → [F9]

Only available in Message window of a sent message with a requested delivery report.

Check Attachment Properties (Image File)

[Message Window] → [F10] → *Property* → [F10] → Select image → [F10]