Calendar & Tasks	. 11-
Calendar	. 11-
Tasks	. 11-
Alarms	. 11-
Using Alarms	
Wakeup TV	11-1
Using Wakeup TV	11-1
Relaxation Time	11-1:
Playing Animation with Music &	
Illumination	11-1:
Household Accounts	11-1:
Managing Household Expenses	11-1
Calculator	11-1
Using Calculator	
Expenses Memo	11-18
Adding Expenses	
Osaifu-Keitai®	11-19
Osaifu-Keitai® (Japanese)	11-1
Locking IC Card	11-2
Simulated Call	11-2
Faking Incoming Calls	11-2
Stopwatch	11-2
Using Stopwatch	
Countdown Timer	11-2
Using Countdown Timer	11-2
World Clock	11-2
Opening World Clock	11-2
Hour Minder	11-2
Using Hour Minder	11-2

Pedometer	11-28
Using Pedometer	11-28
Compass	11-30
Using Compass	11-30
S! GPS Navi	11-31
Using S! GPS Navi	11-31
Document Viewer	11-34
Opening PC Documents	11-34
Notepad	11-35
Saving Text	
ASCII Art	11-36
Using ASCII Art	11-36
Voice Recorder	11-37
Recording/Playing Voice	11-37
Scan Barcode	11-38
Scanning Barcodes	11-38
Create QR Code	11-39
Creating QR Codes	11-39
Scan Card	11-40
Scanning Business Cards	11-40
Scan Text	11-41
Scanning Text	11-41
Kanji Grabber	11-42
Using Kanji Grabber	11-42
Additional Functions	11-43
Troubleshooting	11-56



Handy Extras



Calendar

Opening Calendar

● **→** Tools **→** • In PIM/ Life menu, *Calendar* → ●



Calendar Window

Press (x) to toggle Calendar view.

Key Assignments

■ All Views

Open Previous Page	★ ***
Open Next Page	(i, t)
Open Help	() to

■ 1Month/3Month View

Select Date	⊹
Go to Current Date	5 5

6Month View

Go to Current Month	5 %
Select Month	•

Week View

Select Date	⊙
Select Time Block	②

Spinguru Log Calendar (Spinguru Log)

Long Press () in Calendar window to switch to Spinguru Log Calendar (Spinguru Log); circle finger around Vector Pad for operation. Select a date and press (2) to save/check schedules, view operation history (mail records, call log, etc.), and more.



Timeline Window


Opening Help

[Spinguru Log Menu]/[Timeline

■ To return, press .

Returning to Calendar Window [Spinguru Log Menu] (v) (Long) Accessing Operation History, Etc. [Timeline Window] (Ty) (Long)





Saving Schedules

Follow these steps to save subject, Category, start/end date/time, Alarm and schedule details:

(Enter Subject or Description to save entry.)

In Calendar window, select date **→** (•)









- Preset → Select Category **→** (•)
- Enter start date/time **→** (●)




End:

● Enter end date/time

◆ (●)











In ③, Alarm Time: ▶ ● Other ▶ ● **Enter date/time ●** ● **P**

From (3)

At Alarm Time

Alarm activates; sounds/vibrates by related settings.



Stopping Alarm to Return to Standby

While Alarm sounds/vibrates, press ,
 or
 or

Stopping Alarm to Open Schedule

 While Alarm sounds/vibrates, press a key other than , or well.

When Another Function is Active

 Alarm may not activate until handset returns to Standby.

Incoming Calls


 Active Alarm stops for incoming calls.
 Information window opens after handset returns to Standby.

Opening Schedules/Tasks

In Calendar window, select date ▶ ●



Schedule List



😭 🙃 🕈 Standby returns

Opening Task List
In ⊘, select task ▶ ⊚ ▶ Go to
Tasks ▶ ⑥

Accessing Secret Entries

[Calendar Window] ② → Unlock
Temporarily → ③ → Enter Handset
Code → ⑥

Opening Related Message

Open schedule-related messages saved from Messaging message list.

- In schedule list, select schedule ▶ ●
- ⇒ Related Mail ⇒

 • Related message opens.
 - To return to schedule window, press (MARCO).

Deleting Message from Schedule
After ①, ⑥ ♦ Related Mail: ♦ ⑥ ♦
Yes ♦ ⑥ ♦ ♡

Advanced



Searching entries Checking memory status Deleting all entries Deleting entries by specifying week (Week View) Deleting entries by specifying month (1Month/3Month View) Deleting entries in six months (6Month View) (P.11-45)

Information Link

Set to show or hide the following information in Calendar.

Reservation List	TV Timer and TV Recording Timer entries
Birthday	Birthdays entered in Phone Book
What is today? (Japanese)	Preset anniversaries, commemorative days, etc.

- Calendar Settings → ●
- Data to Show ▶
 - Select item → (□/☑)
- **5** (2)

Spinguru Log Information Link

 In Spinguru Log, operation history of various functions are also displayable.

Editing TV Timer/TV Recording Timer

- In schedule list, select entry

 → □
- Edit → ●
- Edit → 🕏

Deleting Entries

In ②, Delete → ● Yes → ●

- Timer is canceled.
- Making Birthday Calls
- In schedule list, select entry

 → □
- Call

 Select phone number

 Output

 Select phone
 - Omit number selection step if only one number is saved.

Sending Birthday Messages

In ②, Mail → ⑥ → Select number/
address → ⑥ → Complete message
→ ⑤


- Omit number/address selection step if only one number or address is saved.
- For phone numbers, select S! Mail or SMS and press .

Deleting Schedules

- One Entry
- In schedule list, select schedule ▶ ☒
- Delete → → This
 Appointment → → Yes
 → ●
- All Entries of the Day
- In Calendar window, select date ▶
- Delete → → All This Day
 → Yes → ●

Saving Tasks

Follow these steps to save subject, due date/time, Alarm and task details: (Enter Subject or Description to save entry.)





∠Add New Entry>

●





Za Enter due date/time → ●



- 🔜 Alarm: 🖈 💿

- Saved





At Alarm Time

Alarm activates; sounds/vibrates by related settings.



Stopping Alarm to Return to Standby

 While Alarm sounds/vibrates, press ①, or (GLEAR SE).

Stopping Alarm to Open Task

 While Alarm sounds/vibrates, press a key other than . or was or


When Another Function is Active

 Alarm may not activate until handset returns to Standby.

Incoming Calls

· Active Alarm stops for incoming calls. Information window opens after handset returns to Standby.

Opening Tasks





Task List

- Use to open Completed or Incomplete task list.
- Select task **→** (•)



⇒ Standby returns

Accessing Secret Entries

After (1), (□) → Unlock Temporarily **→** • Enter Handset Code **→** •

Marking Tasks as Completed

After ①, select task ▶ 🖘

Deleting Tasks


- One Entry
 - In task list, select task ▶ 🖾
- Delete **→** •
- This Task → Yes → •
- **All Completed Tasks**
- In task list,
- Delete **→** (•)
- All Comp. Tasks ▶ () ▶ Yes **▶**



Using Alarms

Setting Alarm

Follow these steps to set Alarm to sound at a specific time on a specific day of the week: (Set Snooze--Alarm repeats at set interval--Alarm Volume and Duration.)





Alarm List









- Selected Days → ●
- Snooze: → ●
- Select interval → ●
 For custom intervals, select Other.
- 🔁 Alarm Volume: 🕈 💿
- Adjust level → ●
- 间 Duration: Þ 💿

- Nelect time →

 Output

 Description:
 - For custom Duration, select Other.
- (v) → Saved
 For more settings, repeat ② ②.
- 👔 💿 **➡** Standby returns

Activating Alarm Once or Daily In ②, Once or Every Day (All) ▶ ● From ⑤ Selecting/Canceling All Days

- lecting/Canceling All Days
 In ⑤, ⑥ **→** Check All or Uncheck All **→** ●
- Excluding Holidays
 In \bigcirc , select day \Rightarrow \bigcirc (\bigcirc / \checkmark) \Rightarrow Complete selection \Rightarrow Except
 Holidays \Rightarrow \bigcirc (\checkmark) \Rightarrow \bigcirc \Rightarrow From \bigcirc



At Alarm Time

Alarm activates; sounds/vibrates by related settings.



Stopping Alarm

 Press a key (except with handset closed).

When Another Function is Active

 Alarm may not activate until handset returns to Standby.

Incoming Calls

 Active Alarm stops for incoming calls. Information window opens after handset returns to Standby.

When Snooze is Set

Alarm repeats at the set interval. Other Alarms do not activate while handset is Snoozing.


Canceling Snooze

While Snoozing, ● Yes → ●

■ Snooze is automatically canceled after a period of time.

Canceling Alarm






 Reactivate entry to use the same settings.

Reactivating Entry

In ②, Switch On → ●

Deleting Alarm

One Entry







All Entries

In Alarm list, select entry




Using Wakeup TV

Setting Wakeup TV

Follow these steps to activate TV at a specific time on a specific day of the week:

- Complete TV Area setup beforehand.
- TV may not activate in poor signal conditions.





Wakeup TV List

--:-- **♦** (**•**) **♦** Enter hour minutes **→ ●**



Wakeup TV Menu

- Repeat:

 ◆
- Selected Days **→** (•)
- Select day **→ (** (/ / √) **→** Complete selection **→** (12)
- Channel: **→** •
- Select channel **→** (•)
- Saved • For more settings, repeat @ - 3.
- Standby returns

Activating TV Once or Daily In ②, Once or Every Day (All) → • From 🕞

Selecting/Canceling All Days In ⑤, Ø → Check All or Uncheck All **▶ (**

In ⑤, select day ♦ ⑥ (/ / V) ♦ Complete selection **→** Except Holidays \Rightarrow \bullet $(\lor) \Rightarrow \bigcirc \Rightarrow$ From \bigcirc

Canceling Alarm Alarm activates at Wakeup TV time. To cancel Alarm, follow these steps:

[Wakeup TV Menu] Alarm On/Off: ▶

Adjusting Alarm Volume

Excluding Holidays

[Wakeup TV Menu] Alarm Volume: >

Adjust level
 From
 From



At Wakeup TV Time

TV activates after Alarm.



Stopping Alarm Instantly

• While Alarm sounds/vibrates, press a key (except with handset closed).

When Another Function is Active

• TV may not activate depending on the function.

After TV is On for a Period of Time

• A confirmation appears. Choose Yes and press
to exit TV.

Canceling Wakeup TV





• Reactivate entry to use the same settings.

Reactivating Entry

In ②, Wakeup TV On → •

Deleting Wakeup TV

- One Entry
- In Wakeup TV list, select entry **▶** 🖾
- Reset Alarm **→** ●
- Yes **▶** •
- All Entries
- In Wakeup TV list, select entry **▶** 🖾

Playing Animation with Music & Illumination

Play preset animations or downloaded Flash® files with music and illumination. Set playback time, volume, etc. as needed.

- ① → Tools → ⊙ → In PIM/ Life menu, Relaxation Time → ⊙
- Select type →
 - Animation appears.
 For *Flash*®, select a file and press .
 - Message appears when Playback Time is set to *Continuous Play* (except when charging battery); press to proceed.

- Setting Relaxation Time
- → Tools → In PIM/ Life menu, Relaxation Time → ●
- Settings → ●



- 📵 Playback Time 🕈 💿
- Select time →
 - For custom playback time, select Other.
- **S** Volume **→**
- 🕞 Adjust level 🕈 💿
- Set Key Illumi **→** ●

- S Key Pattern → ●
- Select pattern → 🍑 → 🔊
- 🔟 🕝 ➡ Standby returns

Disabling Key Illumination
In ⊕, Switch On/Off → ● → Off →
● → ⊕




Managing Household Expenses

Scan receipts with mobile camera to manage expenses on handset.

Setup

Specify closing day, closing month and budget for the month.

● **Tools →** In PIM/ Life menu, Household Accounts **→** ●



Household Accounts Window








Account Setup Menu





- Press () to change default closing date (end of the month): use • to move between date and month fields
- Enter date/month **→** •
- Yes **→** (•)





Restricting Access to Household **Accounts by Handset Code** [Account Setup Menu] Locks → • **→** On **→ (•)**

Resetting Household Accounts [Account Setup Menu] Master Reset

- **→ →** Enter Handset Code **→**
 - Yes → ●





Saving Entries

Scanning Receipts

Scan receipts with mobile camera to enter date, expense items, fees/prices and total amount automatically.

Scan may fail if receipt is too long, folded, faded, etc.; some formats are not supported.

In Household Accounts window, select scan receipt panel

● ●





Scan Window

 Frame date, expense items and total amount. Align text parallel to reference lines.





• To cancel, press 🐨.







 To add, delete or edit expense items, see P.11-15 "Entering Manually."





• Entry is saved.

Opening Operation Guide

[Scan Window] 🐨

■ Press to return to scan window.

Key Assignments in Scan Window

Toggle Focus Mode	3 😁
Focus Lock	\$-J
Mobile Light On/Off	#:
Adjust Brightness	•
Open Help	() to ()



Entering Manually



Expense Input Window

- Select date panel

 Select date panel

 Enter date

 ●
- Shop → Select shop/ facility → ●
- Paid

 Select payment method

 Output

 Description:





- [| Item → | ► Enter name → | |
- Category → Select
 Category → ●
- Value → ► Enter amount
- Saved

Adding Expense Items

After ③, select item field → ◎ →
Add Items → ● → From ⑤

Deleting Expense Items

After ③, select item ▶ ▶ Delete

→ ● Yes → ● ● ● ●

Changing Categories of All Items at Once [Expense Input Window] Category

→ ● Select Category → ● ● ⑤

Opening Expense Records

- **Opening Entries**
- In Household Accounts window, select totals panel
- Select date **→** •



Daily Expense Log

- Select entry **→** Details appear.
- **Deleting an Entry**

[Daily Expense Log] Select entry ▶ 🖾

Delete Receipt → ● Yes → ●

Deleting All Entries

[Daily Expense Log]

→ Delete Day Receipt Data or Delete Month Receipt Data → ● Yes → ●

Viewing Expense Trends

Follow these steps to view monthly expenses, budgets and balances:

- In Household Accounts window, select charts panel **▶** (●)
- Results by Month **→**



- Press

 to toggle budget and balance.
- Use to open previous or next year.

Viewing Other Expense Trends In ②, select item ▶ ●

Using Calculator

● **Tools →** In PIM/ Life menu, Calculator → ●



Calculator Window

- Use Keypad to enter digits Calculate
- Standby returns

Key Assignments + (Add) <u></u> - (Subtract) (ੈ) × (Multiply) **②** ÷ (Divide) • = (Sum) C·CE (Clear) CM (Clear Memory) (**<u>)</u> RM (Recall Memory) (Y) M+ (Add to Memory) X (Decimal)

Memory Calculation

% (Percentage)

+/- (Positive/Negative Value)

- Clear Memory before starting new Memory calculations.
- Numbers saved in Memory remain until handset is powered off.

(#,;

Incoming Calls

· Calculations are not affected. End the call to return to Calculator

Using % Function

Use (R) to find definite percentage of a known value

Example: Calculate 30% of 800,000

Enter 800,000 → x → 30 → %

240,000 appears.

Adding Expenses

Entering Expenses

● → Tools → ● In PIM/ Life menu, Expenses Memo • ●



Expenses Memo Menu













[Expenses Memo Menu]

→ Reset

Checking Entries

In Expenses Memo menu, select list **→** ●

Title **♦ (•) ∀** Yes **♦ (•)**



Expenses Memo List



Saving Entries to Notepad

[Expenses Memo List] Select entry

⇒

→ Save to Notepad

→

●

Deleting Entries

One Entry

- In Expenses Memo list, select entry ▶ ◎
- Delete Item → ●
- Yes → ●
- All Entries
- In Expenses Memo list, select entry ▶ ⊠
- 🕖 Delete All 🕈 💿
- R Yes ▶
 - All entries on the list are deleted.



Osaifu-Keitai® (Japanese)

Osaifu-Keitai® describes IC Card-equipped handsets that support e-money or credit functions/services. Osaifu-Keitai® encompasses a range of IC Card-based services on FeliCa-compatible SoftBank handsets. 944SH supports Osaifu-Keitai®. To use e-money, e-ticketing and reward points, etc., hold handset over a compatible reader/writer at shops, restaurants, and other retail outlets, etc.

Basics

Before using Osaifu-Keitai®, activate Lifestyle-Appli, complete registration, customize settings and charge accounts.

Starting Lifestyle-Appli


- Tools → In PIM/Life menu,
 Osaifu-Keitai → → Lifestyle-Appli
 → Select application → ●
- Important Lifestyle-Appli Usage Notes
- Contact Osaifu-Keitai[®] service providers for Lifestyle-Appli registration and usage details.
- Keep service passwords/customer service contact information, etc. in a separate place.

Using Osaifu-Keitai®

Follow these steps to conduct a transaction: Example: Making an electronic payment

- Lifestyle-Appli activation is not necessary.
- Transactions are possible even while handset is off (if battery is adequately charged).
- Calls/Internet transmissions do not affect transactions.





Place this part over reader/writer

Align handset parallel to reader/writer.


Important Osaifu-Keitai® Usage Note

 SoftBank Mobile is not liable for damages resulting from accidental loss/alteration of IC Card data/settings.

When Placed Over Sensor

- If recognition is slow, move handset around slightly.
- Handset may respond automatically for some services.







IC Card Lock → ● → On

Yes **▶** •

Canceling IC Card Lock In \bigcirc , IC Card Lock \Rightarrow \bigcirc \Rightarrow Off \Rightarrow \bigcirc ▶ Enter Handset Code
 ◆ ●



Handy Extras

IC Card Settings

◆

●



IC Card Settings Menu

Advanced




🖄 Customizing handset response to reader/writer commands Opening IC Card properties Changing IC Card Lock notice recipient Changing required Missed Call count for Call Remote Lock Restoring default Osaifu-Keitai® settings (P.11-48)


Remote Lock

Disable Osaifu-Keitai® remotely by mail or phone.


Lock	Send mail to activate Remote Lock
Call Remote	Call from a specified phone to activate Remote Lock
Lock	to activate Remote Lock



Preparation on Handset












Mail Remote Lock Menu

- Remote Lock PW **→** ●
- Enter password **▶**
- - On **♦ (**27)

Canceling Mail Remote Lock In ⑤, Switch On/Off → ⑥ → Off → (27)

Activating Remote Lock via Mail If handset cannot receive mail, IC Card Lock remains unset.



• After handset receives message, IC Card Lock is set and notice is sent as a reply.

- Call Remote Lock
- Preparation on Handset
- 🔁 IC Card Settings 🕈 💿
- Remote Lock

 ● Enter
 Handset Code

 ●
- Call Remote Lock → ●



Call Remote Lock Menu

Phone No. to Lck 1 or
Phone No. to Lck 2 ▶ ●



- Phone Book → Select entry → → Select phone number →
 - Select Phone Number to enter directly.
- Switch On/Off → ●
- 🛜 On **→** 💿 **→** 🐨

Enabling Activation via Public Phone
In ⑤, Set Public Phone ▶ ⑥ ▶ On
▶ ⑥ ▶ From ②
Canceling Call Remote Lock

■ Activating Remote Lock via Phone
If handset cannot receive calls, IC Card
Lock remains unset

- Using one of the specified phones, call handset
 - Send Caller ID.
 - Handset receives call
 End the call
 - The call is recorded as a Missed Call.
- Within three minutes, repeat

 O 2 twice
 - After the third Missed Call, IC Card Lock is set; a message announces Remote Lock activation. Confirm the message and end the call.

If Series is Interrupted by Another Call

 Missed Call count is reset. Start over from the beginning.

Faking Incoming Calls

Handset rings to emulate an incoming call.


- Save name and phone number to show as Caller ID.
- Ringer may be muted by handset settings.
 To override Silent setting, see P.11-49.

Setting Simulated Call






Simulated Call Menu









- Assign Tone → Select tone/file → ●
- 🥏 🕏 ▶ PIM/Life menu returns

When Name and Phone Number are Unset

Handset rings with Caller ID "Withheld."

Canceling Simulated Call

[Simulated Call Menu] Switch On/Off

→ (a) → Off → (b) → (b)

Setting Wait Time

[Simulated Call Menu] Receive Timing

 → ● Select time → ● → ∞

Using Simulated Call




- Available regardless of handset position.
- Handset rings and incoming Voice Call window opens.
- Ringtone stops after a period of time.
- In incoming Voice Call window, press
 - Voice Call window opens. (Softkeys are dummies.)
- Standby returns

When Receive Timing is Not Immediately

- Press or during wait time to cancel Simulated Call activation.
- Simulated Call activation is canceled by incoming calls, Alarms, etc. during wait time.

Using Stopwatch

Stopwatch stops if battery runs low.







Stopwatch Window





• Press • to resume.



· Records are deleted when Stopwatch ends.





Using Countdown Timer

 \bullet \rightarrow Tools \rightarrow \bullet Clock/Gauge

→ Countdown Timer **→** •



Timer Entry Window

Enter minutes **→** Enter seconds







Countdown Timer Window

- Countdown starts Press to stop/resume countdown.
- Set time elapses **→** Tone sounds
- ③ **→** Yes **→ → Countdown Timer ends**

Using Timer Records

After ①, ☑ → Select record → ⊙ → ● From ②

Resetting Countdown Timer Stop countdown and (22) **Incoming Calls**

 Countdown is not affected by incoming calls. End the call to return.

When Set Time Elapses

Tone sounds.



Stopping Tone Instantly

 Press or . (Tone stops automatically after a period of time.)

When Timer Time Elapsed during a Call

Tone sounds after the call



Opening World Clock

① ◆ Tools ◆ ⊙ ◆ ⊙
Clock/Gauge ◆ World Clock



Select area → ●

Advancing One Hour (Daylight Saving)
[Set Time Zone Window] 😕

■ To cancel, press 🔊.

Adding Custom Time Zone

[Set Time Zone Window]

Figure Part

Figure Par

Enter time difference ▶ ●

Opening World Clock in Standby

● Settings → ● In Sound/Display menu, Display → ●

Standby Display → ●

👸 Clock/Calendar 🕈 🧿

Morld Clock (L), etc. ⇒ ●

🕞 💿 **♦** Standby returns

20



Set Time Zone Window



Using Hour Minder

Setting Hour Minder

Follow these steps to activate the hourly time signal at selected hours:






Hour Minder Menu













Adjusting Hour Minder Volume
In ②, Advanced ▶ ● ➤ Volume: ▶
● ➤ Adjust level ▶ ● ➤ →
From ⑤
Changing Hour Minder Duration

In ②, Advanced → ● → Duration:

→ ● → Select time → ● → 🏵 →

From 🖯

■ For custom Duration, select *Other*.

Selecting/Canceling All Hours

In ②, → Check All or Uncheck All

At Hour Minder Time

Hour Minder activates; sounds/vibrates by related settings.



Stopping Tone Instantly

Press a key.

When Another Function is Active

- Hour Minder does not activate.
- Incoming Calls
- · Active Hour Minder stops for incoming calls.

Canceling Hour Minder

In Hour Minder menu, Switch On/Off → ● → Off → ● → ∞



Handy

Using Pedometer

Getting Started

- Count based on a pace of approximately 100 steps per minute over even terrain.
- · Accuracy may be affected by course, terrain, walking style, etc.
- Avoid holding the handset; use a body worn case or a strap, or place handset inside a pocket or bag.
 - Avoid sudden/erratic movements.
- Steps are not counted in the following cases:
 - While handset is off
 - For the first few steps
 - While handset vibrates
- Handset use may affect accuracy.
- Weight and pace entry required to view full Pedometer data.
- Use Pedometer only as a rough guide.

Adjusting Counter Sensitivity

- → Pedometer → (a) → (b) →
- Select option ⇒ ●
- Select *Low* when steps seem overcounted; select High when they seem undercounted

Saving Body Information





Pedometer Window

- If Pedometer is disabled, a confirmation appears. Choose **Yes** or **No** and press .
- Settings → Body Info. **→ ●**



Body Info Menu

- Height → ► Enter height
- Weight → Enter weight **→** •
- $Pace \Rightarrow \bigcirc \Rightarrow Yes \text{ or } No \Rightarrow \bigcirc$ • Choose Yes to enter pace
- automatically based on height.
- Enter pace

 ◆ (Yr)

Editing Body Information ★ Enter value ◆ ◆ ▽

■ For *Pace*, automatic calculation confirmation appears (when height is entered).

Enabling Pedometer

In Pedometer window, (☑) ▶ Pedometer On

◆

●

Disabling Pedometer [Pedometer Window] (Page 1) Pedometer Off

◆

●



Viewing Step Count Records

In Pedometer window,



Steps Window

- Press (x) to toggle Daily/Hourly view.
- Press #,5 or ★ to scroll down or up by one page.
- Select time/date

 ◆
 - Hourly/daily step counts appear.
- ▶ Pedometer window returns

Pedometer Window Tabs

• Press • to open Exercise and then Calories

Resetting Today's Step Count

[Pedometer Window]

→ Reset Dav's Data → ● Yes → ●


Resetting Log

Reset **♦ ●** Yes **♦ ●**

■ Todav's data is also reset.

Setting Targets

Information window opens, etc. when target is achieved for these items:



- In Pedometer window, ☑ ▶ Settings → • Target → •
- Target Settings **→** ●



 Other target settings may consequently change.

Editing Targets

→ • **→** Target **→** • **→** Target Settings → • Select item → •

→ Enter value/time → ●

When Target is Achieved


 A tone sounds and Information window opens. (Select Goal Achievement and press

to open Pedometer Calendar.) Follow these steps to mute achievement tone:

→ • → Target → • → Goal Announce **→ (•) →** Off **→ (•)**

About Exercise (Ex)

 Ex and MET indicate amount and intensity of physical activity, respectively. Ex for walking is calculated by multiplying 3 METs by walking duration (hour).



Using Compass

Opening Compass





Compass Window

· Compass opens; use as a rough guide.

Adjusting Compass

- In Compass window, ▶
 - Follow onscreen instructions.

Compass Indicator

- When map is open, compass indicator appears; follow these steps to hide it:
 - **Tools ● ● Olock/Gauge** ⇒ S! GPS Navi ⇒ ● NAVI
 - Settings → Compass Indicator **→** • **→** Off **→** •



Using S! GPS Navi

Use this GPS navigation service to pinpoint current location, find routes to destinations, and more.

Provide current location to administrator upon request.

Precautions

- Location Information accuracy may be affected when GPS satellite/radio station signal reception is poor. Use S! GPS Navi under the open sky.
- SoftBank Mobile is not liable for any damages resulting from the provided Location Information.

Positioning

 Pinpoints current location using signals transmitted from GPS satellites.

Location Information Accuracy

- Probable distance from the actual position is classified into three accuracy levels, from level 1 (low) to 3 (high), indicated by the number of %s.
- A confirmation appears when accuracy level is 1 or 2; follow these steps:
 Yes or No → ●

Starting Navi-Appli





S! GPS Navi Menu



Navi Appli **→** •



Opening Navi Appli List

[S! GPS Navi Menu] Navi Appli List

→ ●

■ To activate Navi Appli, select one and press .

Selecting a Navi-Appli for S! GPS Navi
[S! GPS Navi Menu] NAVI Settings ▶

(S) ⇒ Select Navi Appli ⇒ (S) ⇒

Select application **→ ●**





• To disable confirmation, press 🖾

• Map of your current location appears.

Using My Location

Saving Location Information

Follow these steps to save current location as a new entry:

In S! GPS Navi menu, *My*Location List

●



My LocationList Menu

New Entry → ●

Name → ● ► Enter name

A Location Info → ●

From Current Loc.

◆ ●

Positioning complete

30

When accuracy level is 1 or 2, choose
 No and press to proceed to .

Saving as Home

In ②, 自宅 ◆ ⑥ ◆ From ②
Saving from Location Log
In ⑤, From Location Logs ◆ ⑥ ◆
Select record ◆ ⑥ ◆ 廖

Opening Entries

In My LocationList menu, select entry ▶ ●

Location Info

• Details window opens.

Details window closes

Deleting Entries

In My LocationList menu, select entry


② ⇒ Delete ⇒ ⊙ ⇒ Yes ⇒ ⊙

Sending current location via mail Changing map source URL Disabling positioning Selecting Location Information transmission option Using My Location & Location Log Saving Location Log records to My Location Deleting Location Log records (P.11-50)

Using Ichi Navi (Japanese)

Locate other S! GPS Navi-compatible handset users or lost handset.

- Ichi Navi requires a separate contract and initial settings.
- If Double Number is active, service uses Line A regardless of usage mode setting.
- For more about Ichi Navi, see SoftBank Mobile Website (P.17-24).



 Handset connects to the Internet. Follow onscreen instructions.

Providing Location Information

Provide current location to administrator upon request.

- Location may be provided automatically upon administrator's request without confirmation.
- May be unavailable depending on subscription. For details, contact the nearest SoftBank Shop or SoftBank Mobile Customer Center, General Information (P.17-43).
- Location Information request arrives



 A confirmation appears. (Message shown above is for reference only.)



Information

Information window opens after your location is provided manually (by pressing (a) upon Location Information request or automatically upon administrator's request. Select the item and press
to open log.








Opening PC Documents

Supported File Formats:

Supported the Formats.		
PDF (.pdf)		
Microsoft® Excel® (.xls)		
Microsoft® Word (.doc)		
Microsoft® PowerPoint® (.ppt)		
Some files may not appear correctly.		

- Downloaded files are also supported. • When transferring files from PCs, save to
- corresponding Memory Card folder (P.17-25).






Zooming In/Out with Loupe (Magnifier) In open file, [®] (Long) → Specify portion → 🖾 → Zoom Out or Zoom In **▶** ●

Key Assignments		
View Whole Page	•	
Scroll	:	
View Upper Left	1 8	
Toggle Full Screen View On/Off	2 ÷)/(• •	
View Upper Right	3 de	
Zoom Out	4 to	
Continuous Zoom Out	4 € (Long)	
View Center	5 .5.	
Zoom In	6 mmo	
Continuous Zoom In	(Long) (Long)	
View Lower Left	7 # ross	
Jump to Page	8 m	
View Lower Right	9 5 wxyz	
Open Help	() **	
Next Page	#.š	
Previous Page	X ***	
Fit Width	*.J	
Rotate 90 Degrees	\(\frac{\partial}{2}\)	

Saving Text

New Notepad Entry





Notepad List



💽 Enter text 🕈 💿

Select Category

◆ ●

Saved

Sorting Entries Temporarily

[Notepad List] 🏵

Press to toggle sort options (Modified, Created, Category and Accessed).

Inserting Notepad Text during Text Entry

[Text Entry Window]

→ Notepad

→ → Call Notepad → →

Select entry → →

Opening Notepad

Text appears.



Deleting Entries

One Entry

In Notepad list, select entry

⇒ ⊠

Delete Item → ● Yes → ●

Selected Entries

In Notepad list, select entry →

Setting/Manage →

O

Multiple Selection
Select entry

(□/√)
Complete selection

□

👔 Delete 🕈 💿 🕈 Yes 🕈 💿

Unchecking All In ⊚, Uncheck All → ●


All Entries

In Notepad list, select entry →

Setting/Manage →

O

Delete All → ● Yes → ●



Using ASCII Art

Inserting ASCII Art

- In message text entry window, (□) **→** Call ASCII Art **→** (•)
- Select entry **→**



Previewing ASCII Art In ②, select entry ▶ ■ Press to insert ASCII Art.

Editing Entries





ASCII Art List

Select entry **→ ● →** Edit

Opening Entries In ②, select entry ⇒ ③ ⇒ View ⇒ ⑥ **Adding New Entries** In ②, <Empty> → ● Create ASCII Art ◆ ●

Deleting Entries

- In ASCII Art list, select entry **→** □ **→** Delete **→** •
- Yes **▶** •

Recording/Playing Voice

Recording

- Recording stops if battery runs low while recording.
- Record conversations during calls via Record Caller Voice.





Recording Window







 For Extended Voice, recording is saved automatically.



Playback







Playback Operations

Volume Control	③
Pause/Resume	•
Stop	THE AREA

Advanced

Scanning Barcodes

Scan UPC/JAN (1D barcodes) or QR Codes (2D barcodes).

- Membership file or password may be required when scanning barcodes.
- Some barcodes may not be scanned.







Frame barcode in center of **Display**



Scan Window

- Use Focus Adjustment Bar as a guide (better focus in darker blue).

Scan starts

- If recognition takes time, slowly adjust the distance between handset and barcode.
- To cancel, press ().


Tone sounds ◆ Scan results appear



Split Data

- After scanning, a confirmation appears. Follow onscreen prompt(s).
- Scan results do not appear until all split data is scanned.

Starting Over



Key Assignments in Scan Window

Toggle Focus Mode	3 👬
Switch to Photo Camera	7.3
Focus Lock	2+~
Mobile Light On/Off	#.j
Adjust Brightness	••
Open Help	() to #

Advanced



💯 Scanning during text entry Scanning continuously Reading saved barcode images Saving scan results Saving to Notepad Saving linked info to Phone Book Opening saved scan results Using linked info Using images as Wallpaper Saving images & melodies Ocopying text (And more on P.11-52 - 11-53)

Creating QR Codes

Create QR Codes from these items on handset:

Phone Book

My Details

Text Input

Ring Songs-Tones

Pictures Notepad

Large items are divided into multiple QR Codes.

Procedure

Follow these steps to create QR Codes from Data Folder files:



- Create QR Code → ●
- 🚺 Data Folder 🕈 💿
- Select folder

 Select file or entry

 Select
 - QR Code is created.



 QR Code is saved to Data Folder (Pictures). From Phone Book Entries

In ©, Phone Book \Rightarrow © \Rightarrow Select entry \Rightarrow © \Rightarrow \bigcirc

From My Details

In s, My Details \Rightarrow a \Rightarrow a

From Entered Text

In ⑤, Text Input → ⑥ → Enter text → ⑥ → ⑤

Switching Storage Media

In \bigcirc , \bigcirc \Rightarrow Save to \Rightarrow \bigcirc \Rightarrow Phone or Memory Card \Rightarrow \bigcirc \Rightarrow \bigcirc

Attaching to S! Mail

In ⑤, ⑥ → Send As Message → ⑥

Incoming Calls

• QR Code creation is not affected by incoming calls. End the call to return.


Scanning Business Cards


Scan business cards and save names, addresses, etc. to Phone Book.

- English business cards may not be scanned correctly.
- Some cards may not be scanned.
- ① → Tools → ② → ②
 Doc./Rec. → Barcode/Scan
 → ③
- Scan Card → ●
- Frame card on Display



Scan Window









New Phone Book entry is saved.

If Text Exceeds Phone Book Entry Item Character Limit

 A confirmation appears. Follow these steps to delete overage:

Yes **▶** •

Switching Storage Media

After \bigcirc , \bigcirc \Rightarrow Save to \Rightarrow \bigcirc \Rightarrow Select storage media \Rightarrow \bigcirc \Rightarrow \bigcirc

Saving Scanned Image as Phone Book Picture

Picture

After ⊕, ⊕ → Add Image → ● →

On → ● ⊕ ⊕

Starting Over

After ⊕, ⊕ → Yes → ● → From ⊕

Key Assignments in Scan Window

Toggle Focus Mode	3 🚓
Switch to Photo Camera	7.3
Focus Lock	\$+~)
Mobile Light On/Off	#.;
Adjust Brightness	••
Open Help	0 **



Advanced

Scanning Text

Scan text and save it to Notepad, etc. Available Modes:

	Capture text in full screen and scan a selected line
Line	Capture a few lines of text and scan a selected line


- To toggle mode, press 💬 in scan window.
- Some text may not be scanned.





• To change mode, press (**) in scan window.

Frame text in center of Display



Scan Window

- Scan starts
 To cancel, press (*).







Correcting Text Type

After ③, ⑤ → Change Mode → ⑥
→ Select type → ⑥ → From ⑤

Editing Scanned Text


After ⑤, ◎ ♦ Select/Edit ♦ ⑥ ♦
Select character ♦ Select alternative
from list or edit directly ♦ From ⑥

Starting Over In ⑤, ఄ → Yes → ⑥ → From ⑥

Key Assignments in Scan Window

Toggle Focus Mode	3 🛎
Switch to Photo Camera	7:
Focus Lock	*.J
Mobile Light On/Off	(i, t)
Adjust Brightness	⊙
Open Help	() to #


Advanced



Using Kanji Grabber

Scan a word of up to ten kanji and look it up in dictionaries.

Some kanji may not be scanned.





Frame kanji in Loupe





• Scan results (kanji) appear.







Starting Over	
In ⑤, 🖅 🖈	From ©

Key Assignments in Scan Window

Toggle Focus Mode	3 🖆
Switch to Photo Camera	7:
Focus Lock	*.J
Mobile Light On/Off	#10
Zoom In/Out	③
Adjust Brightness	••
Open Help	() to the



Calendar View Settings Changing default → () → () → Calendar Settings → () → view Jumpina to • > Tools • • In PIM/Life menu. Calendar → • • Enter date → • specified date Start Here Tools In PIM/Life menu. By Days of the Week By Week Select day Select day Select color ⇒ ● Changing date **Bv Date** color Not available in 6Month View. Resetting "By Date" Colors Reset Color → ● Select option → ● → Yes → ● Tools In PIM/Life menu, Calendar Output Description: Selecting task view → (a) → (b) → Calendar Settings → (b) → (c) option Tasks View → • Select option → • Adding stamps ● → Tools → ● In PIM/Life menu, Calendar (1Month/3Month Select date → 2 ♣ Select stamp → ● View) ● → Tools → ● In PIM/Life menu, Calendar Hiding schedules ⇒ Select date ⇒ ● Select entry ⇒ ●

	Start Here ● → Tools → ● → In PIM/Life menu, Calendar → ● → □ → Calendar Settings → ● Set Holiday → ● → Private → See below
Saving additional holidays	Adding Holidays <empty> ▶ ● ⇒ Enter name ⇒ ● ⇒ Enter date ⇒ ● ⇒ Select frequency ⇒ ● ⇒ ⊙</empty>
	Editing Added Holidays Select holiday
Hiding/showing holidays	● Tools ● In PIM/Life menu, Calendar ● ● ⑤ Calendar Settings ● Set Holiday ● ● ⊙ Private or Public ■ Select holiday ● (

■ Saving/Editing Schedules

_ ourmg/_uning t	
Setting Location	● Tools ● In PIM/Life menu, Calendar ● Select date ● Select entry ● ● Location: ● Enter location ● ● ⑨
Creating Categories	Start Here ● → Tools → ● → In PIM/Life menu, Calendar → ● → □ → Calendar Settings → ● → Set Category → ● → See below
	Renaming Categories Select Category → ● → Edit Category Name → ● → Enter name → ●
	Changing Icons Select Category → ● → Change Icon → ● → Select Pictogram → ●
	Resetting
Saving repetitive schedules	 Tools In PIM/Life menu, Calendar Select date Select entry Repeat: Select frequency Enter repeat time
Saving S! Friend's Status information	Start Here
	Availability Answer Status: → ● ⇒ Edit → ♡ ⇒ ♡ • Set Category first.
	Comment Comment:

Editing entries	● Tools ● In PIM/Life menu, Calendar ● Select date ● Select entry ● ● Select item ● Edit in the same manner as saving schedules ● Output The same manner as saving schedules ● Output The same manner
	Start Here
Changing Alarm tone/video & duration	Alarm Tone/Video Assign Tone/Video: Select folder Select tone/file Select start point if required.
	Duration Duration: Select time Duration: Durat
Changing Alarm volume	● * Tools * ● * In PIM/Life menu, Calendar * ● * ② * Alarm Settings * ● * Alarm Volume: * ● * Adjust level * ●
Selecting Vibration option	● * Tools * ● * In PIM/Life menu, Calendar * ● * ② * Alarm Settings * ● * Vibration: * ● * Select option * ●
Sounding Alarm tone even in Manner mode	● Tools ● In PIM/Life menu, Calendar ● ● ② Alarm Settings ● ● For Manner Mode: ● ● Ring ● ● Yes ● ●

■ Managing Schedules

Start Here ● → Tools → ● In PIM/Life menu, Calendar → ● → See below
By Part of Subject ⑤ ♣ ▶ Enter text ▶ ●
By Category Select Category ●
● → Tools → ● In PIM/Life menu, Calendar → ● → Select date → ② → Memory Status → ●
● Tools • ● In PIM/Life menu, Calendar • ● • ⑤ Delete • ● All Appointments • ● Yes • ●
Start Here
Within One Week Select date ⇒ ② ⇒ Delete ⇒ ● ⇒ All This Week ⇒ ● ⇒ Yes ⇒ ●
Up to the End of Previous Week Select date ⇒ ② ⇒ Delete ⇒ ● ⇒ Up to Last Week ⇒ ● ⇒ Yes ⇒ ●
Start Here ● → Tools → ● In PIM/Life menu, Calendar → ● → See below
Within One Month Select date ⇒ ② ⇒ Delete ⇒ ● ⇒ All This Month ⇒ ● ⇒ Yes ⇒ ●
Up to the End of Previous Month Select date ⇒ ② ⇒ Delete ⇒ ● ⇒ Up to Last Month ⇒ ● → Yes ⇒ ●

Deleting entries in six months (6Month View)	● Tools ● ● In PIM/Life menu, Calendar ● ● ⑤ Delete ● All This 6Months ● ● Yes ●	
Tasks	Tasks	
■ Task List		
Hiding tasks	 Tools In PIM/Life menu, Tasks Select task Edit Secret: On Ye 	
Saving/Editing Tasks		
Editing tasks	● Tools ● ■ In PIM/Life menu, Tasks ■ ● Select task ● ◎ ▶ Edit ● ● Select item ● ● Edit in the same manner as saving tasks ● ⑨	
Setting priority	 Tools In PIM/Life menu, Tasks Select task Edit Priority: Select priority 	
	Start Here ● → Tools → ● → In PIM/Life menu, Tasks → ● → Select task → ② → Edit → ● → Alarm: → ● → See below	
Changing Alarm tone/video & duration	Alarm Tone/Video Assign Tone/Video: Select folder Select tone/file Select start point if required.	
	Duration Duration: ◆ ● Select time ◆ ● ◆ ② ◆ ②	
Changing Alarm volume	Tools Alarm Settings Alarm Volume: Alarm Adjust level Alarm	

Selecting Vibration option	 Tools In PIM/Life menu, Tasks In PIM/Life men
Sounding Alarm	● → Tools → ● In PIM/Life menu, Tasks →
tone even in	● ⇒ 🖾 ⇒ Alarm Settings ⇒ ● ⇒ For
Manner mode	Manner Mode: ▶ ● ▶ Ring ▶ ● ≯ Yes ▶ ●

■ Managing Tasks

Searching tasks	Start Here ● → Tools → ● → In PIM/Life menu, Tasks → ● → ② → Find → ● → See below
	By Part of Subject By Subject ● Enter text ●
	By Due Date By Due Date ● ● Enter date ●
Sorting tasks by priority	 Tools In PIM/Life menu, Tasks Sort Priority
Checking memory status	● → Tools → ● → In PIM/Life menu, Tasks → ● → ◎ → Memory Status → ●
Deleting all tasks	● * Tools * ● * In PIM/Life menu, Tasks * ● * ② * Delete * ● * All Tasks * ● * Yes * ●

Alarms	
Editing entries	Tools
Saving entry name	● * Tools * ● In PIM/Life menu, Alarms • • Select entry • • * Subject: • • * Enter name • • • ♡
	Start Here ● → Tools → ● → In PIM/Life menu, Alarms → ● → Select entry → ● → Assign Tone/Video: → ● → See below
Changing Alarm tone/video	Using Preset Tone or Data Folder File Select folder
	Using Customized Screen Tone/Video Customized Screen
Setting handset to vibrate at Alarm Time	● * Tools * ● In PIM/Life menu, Alarms • ● * Select entry * ● * Vibration: * ● • On or Link to Sound * ● * ♡ • Select Link to Sound to allow compatible SMAF files to control vibration.
Sounding Alarm tone even in Manner mode	Tools In PIM/Life menu, Alarms Settings For Manner Mode Ring Yes Yes
Activating Alarm based on World Clock time	Tools In PIM/Life menu, Alarms Settings Link to World Clk On On On On On On On On On O

Wakeup TV ● → Tools → ● In PIM/Life menu, Wakeup TV → • Select entry → • Select item → **Editing entries** District the same manner as saving entries 🗼 💬 Start Here ● → Tools → ● In PIM/Life menu, Wakeup TV ⇒ ● Select entry ⇒ ● ⇒ Assign Tone/Video: ◆ ● See below **Changing Alarm Using Preset Tone or Data Folder File** tone/video Select folder → • Select tone/file → • ✓ • Select start point if required. Using Customized Screen Tone/Video Customized Screen ⇒ ● > > Sounding Alarm ● → Tools → ● → In PIM/Life menu, Wakeup TV ⇒ • For Manner Mode ⇒ • Ring ⇒ tone even in Manner mode ♦ Yes♦

Household Accounts

Renaming icon labels	Start Here
	Shops Shop → ● → Select icon → □ → Enter name → ●
	Payment Methods Paid ♦ ● Select icon ♦ ◎ ♦ Enter name ♦ ●
	Categories Category → ● → Select icon → □ → Enter name → ●

	● → Tools → ● In PIM/Life menu,
	Household Accounts ⇒ ● ⇒ 🖾 ⇒ Export All
Household Accounts data	⇒ • Yes ⇒ •
	Data is exported as a CSV file and saved to handset
Accounts data	Data Folder (Other Documents).
	Files are saved to Memory Card, if inserted.

Calculator

Copying calculation results	While result appears, ⁽²⁾ → <i>Copy</i> → (
Changing exchange rate for currency conversion	Tools In PIM/Life menu, Calculator S Money Converter Exchange Rate Domestic or Foreign Enter rate
Converting currencies	● Tools ● In PIM/Life menu, Calculator ● Enter amount of money ● ■ Money Converter ● ● To Domestic or To Foreign ● ● • Set Exchange Rate first.

Expenses Memo

Changing Category of saved entry	● * Tools * ● In PIM/Life menu, Expenses Memo * ● * Select list * ● * Select entry * ● * Select Category * ●
Changing amount	● * Tools * ● In PIM/Life menu, Expenses Memo * ● * Select list * ● * Select entry * ② * Change Amount * ● * Edit * ●
Renaming Categories	● * Tools * ● * In PIM/Life menu, Expenses Memo * ● * Edit Category * ● * Select Category * ● * Enter name * ●



Osaifu-Keitai[®]

Enabling to view e-money balances	● Tools ● In PIM/Life menu, Osaifu-Keitai ● IC Card Settings ● Balance Info ● <= Empty> ● ■ Lifestyle-Appli or S! Appli ● Select application ● For use with compatible Lifestyle-Applications. ■ Start Lifestyle-Appli once before adding it to Balance Info list.
Moving applications up/down Balance Info list	● Tools ● In PIM/Life menu, Osaifu-Keitai ● IC Card Settings ● Balance Info ● Select application ● Move ● Select target location ●
Removing applications from Balance Info list	● * Tools * ● In PIM/Life menu, Osaifu-Keitai * ● * IC Card Settings * ● * Balance Info * ● * Select application * Delete * ●
Customizing handset response to reader/writer commands	● Tools ● ● In PIM/Life menu, Osaifu-Keitai ● IC Card Settings ● ■ Interface Settings ● ● Select item ● ● ■ Off ● ●
Opening IC Card properties	● ▼ Tools ▼ ● ► In PIM/Life menu, Osaifu-Keitai ▼ ● ▼ IC Card Settings ▼ ● ▼ IC Card Status ▼ ●

Changing IC Card Lock notice recipient	Start Here
	Changing Recipient To Set Recipient Select method Select/enter number/address To Set Recipient Select/enter number/address To Selectienter number/address To Selectienter number or mail address appears if a specific recipient has already been set; edit or delete as needed.
	Disabling Notice Off → ● ⇒ → ∞
Changing required Missed Call count for Call Remote Lock	 Tools In PIM/Life menu, Osaifu-Keitai IC Card Settings Remote Lock Enter Handset Code Call Remote Lock Count for Lock Enter Missed Call count ♥
Restoring default Osaifu-Keitai® settings	● * Tools * ● * In PIM/Life menu, Osaifu-Keitai * ● * IC Card Settings * ● * Set to Default * ● * Enter Handset Code * ● * Yes * ●

Simulated Call

_		
	Starting via Simulated Call menu	● Tools ● In PIM/Life menu, Simulated Call ● Receive Simulated Call ● Yes ● ● Simulated Call starts immediately regardless of Receive Timing setting. ● Settings remain even after starting Simulated Call during setup.

Clearing caller information	● * Tools * ● * In PIM/Life menu, Simulated Call * ● * Set Caller * ● * ◎ * Yes * ● * ② * ②
Overriding Silent volume setting	○ Tools ○ In PIM/Life menu, Simulated Call ○ For Silent Mode ○ Ring ○ Yes ○ ○ ♡

Hour Minder

2.7	
Changing Hour Minder tone/video	● Tools ● ● ○ Clock/Gauge Hour Minder ● Advanced ● Assign Tone/Video: ● Select folder ● Select tone/file ● ○ ♡ ♡ • Select start point if required.
Setting handset to vibrate at Hour Minder Time	● Tools ● ● ○ Clock/Gauge Hour Minder ● ● Advanced ● Vibration: ● ● On or Link to Sound ● ● ② ● ② ● Select Link to Sound to allow compatible SMAF files to control vibration.
Sounding Hour Minder tone even in Manner mode	Minder → O → Ring → O → Yes → O → O
Activating Hour Minder based on World Clock time	● Tools • ● • ⊙ Clock/Gauge Hour Minder • ● Advanced • Link to World Clk: • ● On • ● ♡ • ⊙

Pedometer	
Using Pedometer Calendar	● * Tools * ● * ❖ Clock/Gauge * Pedometer * ● * ❖ * Select date * ● • Degree of achievement appears. • Press ※ or ※ to view previous or next month.
Checking accumulated data	● Tools ● ● ⇔ Clock/Gauge ⇒ Pedometer ● ● ⇔ Accumulated Data ⇒ ● Change in body information is reflected in the data.
Resetting accumulated data	● Tools ● ● ○ Clock/Gauge Pedometer ● ● ○ Accumulated Data ● ○ Peset Walk Data ● ○ Yes ● ● Averages are also reset.
Setting daily step count reset time	● * Tools * ● * • Clock/Gauge * Pedometer * ● * ◎ * Settings * ● * Count Reset Time * ● * Enter time * ● * Yes * ●

S! GPS Navi

Customizing achievement notice	
	Changing Tone Goal Sound → ● Select pattern → ●
	Changing Tone Volume Goal Volume
	Selecting Vibration Option Vibration
	Changing Duration Duration Select time For custom Duration, select Other and press .

Sending current location via mail	● Tools ● ● ○ Clock/Gauge ● S! GPS Navi ● Location Mail ● Positioning complete ● Complete message ♡ ● When accuracy level is 1 or 2, choose No and press ● after positioning, then complete message.
Changing map source URL	Start Here ● → Tools → ● → Clock/Gauge → S! GPS Navi → ● → NAVI Settings → ● → Map URL Settings → ● → See below
	Adding URLs <not set=""> → ● Description → Enter URL → ●</not>
	Setting Destination URL Select URL
	Viewing/Editing/Deleting URLs Select URL

Disabling positioning	● Tools ● ● ○ Clock/Gauge ● S! GPS Navi ● NAVI Settings ● ● Positioning Lock ● ● On ● Handset Code is required to re-select Off.
Selecting Location Information transmission option	● Tools ● ● ⊖ Clock/Gauge ● S! GPS Navi ● ● NAVI Settings ● ● Send Location Info ● ● Select option ● ●
	Start Here
	Opening Map
Using My Location & Location Log	Showing Routes via Navi Appli (a) → Go to → (b) → Yes → (c) • Follow onscreen instructions.
	Inserting into Message Text (a) As Msg. Text (b) Complete message (c) (c) Complete message
	Saving to Phone Book
Saving Location Log records to My Location	Name • • • Clock/Gauge • SI GPS Navi • • Location Logs • • Select record • • Set as My Location • • • • • • • • • • • • • • • • • • •
Deleting Location Log records	● * Tools * ● * ⓒ Clock/Gauge * \$I GPS Navi * ● * Location Logs * ● * Select record * ◎ * Delete or Delete All * ● * Yes * ● Omit record selection step when deleting all records.

Suppressing Information window after sending Location Information automatically	Tools OH
---	---

Notepad

Editing Notepad	Start Here
	Editing Text Edit Text → ● → Edit → ●
	Changing Category Change Category Select Category
Searching text within all entries	● * Tools * ● * ❖ Doc./Rec. * Notepad • • Select entry * ② * Search * • • Enter text * ●
Inserting Notepad text into message text	● Tools ● ⊖ Doc./Rec. Notepad ● Select entry ● Send ● As Message Text ● S! Mail or SMS ● Complete message ♡ ● SI Mail Composition window opens automatically depending on character count.
Sending entries via S! Mail	● * Tools * ● * ❖ Doc./Rec. * Notepad • • Select entry * ② * Send * ● * Via Message * • Complete message * ♡
Creating text files	 Tools Select entry Select Text File Save here Tools Setting/Manage Enter name

Importing text files	Tools Doc./Rec. Notepad Select entry Select entry Select file Manage Import Text File Select file Select file Notepad Notepad
Checking memory status	● * Tools * • • • Doc./Rec. * Notepad • • Select entry * ② * Setting/Manage • • Memory Status * •
Opening properties	● → Tools → ● → ⊕ Doc./Rec. → Notepad → ● Select entry → ⊕ → Details → ●
Voice Recorder	

Saving longer recordings	● Tools ● ◆ Doc./Rec. Voice Recorder ◆ ● ◆ ● ★ Record Time ◆ ● ★ Extended Voice ★ ● ★ Recording starts ◆ ● Recording ends • Insert Memory Card to record in Extended Voice mode. (Recording is saved automatically.)
Sending Voice files via S! Mail	● * Tools * • • • Doc./Rec. * Voice Recorder * • • • Recording starts * • * Recording ends * Save and Send * • Complete message * • Available in For Message mode.
Switching storage media	● Tools ● ● Doc./Rec. Voice Recorder ● ● ● Save Recording to ● ● Select option ● ● • Available in For Message mode. • Set to Ask Each Time to select media after every recording.



Scan Barcode	
	Start Here In a text entry window, (a) ⇒ Scan ⇒ (a) ⇒ Scan Code ⇒ (b) ⇒ Frame barcode in center of Display ⇒ (c) ⇒ See below
Scanning during text entry	Pasting All Scan Results
	Pasting a Part of Scan Results a → Select first character → ● → Highlight text range → ●
Scanning continuously	● Tools ● ⊙ Doc./Rec. Barcode/ Scan ● Scan Barcode ● © © Continuous Scan ● On ● Frame barcode in center of Display ● • Choose Yes to continue scanning or No and press ● to view scan results.
Reading saved barcode images	● * Tools * ● * • Doc./Rec. * Barcode/ Scan * ● * Open Barcode * ● * Select file * ●
Saving scan results	● * Tools * ● * • Doc./Rec. * Barcode/ Scan * ● * Scan Barcode * ● * Frame barcode in center of Display * ● * ⑤ Save * ●
Saving to Notepad	● * Tools * ● * • Doc./Rec. * Barcode/ Scan * ● * Scan Barcode * ● * Frame barcode in center of Display * ● * ⑤ Notepad * ●

Saving linked info to Phone Book	■ Tools ■ Doc./Rec. ■ Barcode/ Scan ■ Scan Barcode ■ Frame barcode in center of Display ■ Select number or mail address ■ Save to Ph.Book ■ As New Entry ■ ■ Complete other fields ■ © ■ To add to an existing entry, select As New Detail. ■ When MEMORY: appears in scan results, press ■ to enter the items underlined with a dotted line automatically in Phone Book entry window.
Opening saved scan results	● Tools ● ● Onc./Rec. Barcode/ Scan ● Scanned Results ● ● Select file ● ● • Select a file and press ® to rename files, open properties or delete files. • Some files may not open.
Using linked info	Start Here
	Sending Messages Select mail address → ● Complete message → ⊕ • When MAILTO: appears in scan results along with SUBJECT: or BODY:, press ● to enter the items underlined with a dotted line automatically in Mail Composition window.
	Accessing Internet Sites Select URL

Using images as Wallpaper	Tools Scan Barcode Scan S
Saving images & melodies	● Tools ● → ⊙ Doc./Rec. Barcode/ Scan ● ● Scan Barcode ● ● Frame barcode in center of Display ● ● Select file ● ② ● To Data Folder ● ●
Opening or playing files	● ** Tools ** ● ** ⊙ Doc./Rec. ** Barcode/ Scan ** ● ** Scan Barcode ** ● ** Frame barcode in center of Display ** ● ** Select file • ●
Using images for System Graphics	● Tools ● ⊖ Doc./Rec. Barcode/ Scan ● Scan Barcode ● Frame barcode in center of Display ● Select image ● As System ● Select item ● Specify image area ● ● Some images may be usable without specifying image area.

Pasting to message text	Start Here ● → Tools → ● → Ooc./Rec. → Barcode/Scan → ● → Scan Barcode → ● → Frame barcode in center of Display → ● ⇒ Send Message → ● → See below
	All Text
	Selected Text ② ➤ Select first character ➤ ● ➤ Highlight text range ➤ ● ➤ S! Mail or SMS ➤ ● ➤ Complete message ➤ ○ • S! Mail Composition window opens automatically depending on character count.
Copying text	Start Here ● → Tools → ● → ⊙ Doc./Rec. → Barcode/Scan → ● → Scan Barcode → ● → Frame barcode in center of Display → ● → See below
	Text ② → Copy → ● → Select first character → ● → Highlight text range → ●
	Number, Address or URL Select number, mail address or URL © Copy Telephone, Copy Address or Copy URL © ©

Scan Card

Saving to Notepad	● Tools ● ● Doc./Rec. ■ Barcode/ Scan ● Scan Card ● ■ Frame card in center of Display ● ● ● ③ ■ Notepad ●
Pasting to message text	Start Here ● → Tools → ● → Doc./Rec. → Barcode/Scan → ● → Scan Card → ● → Frame card in center of Display → ● → ● → ⑤ → Send Message → ● → See below
	All Text
	Selected Text ③ Select first character → ● → Highlight text range → ● → S! Mail or SMS → ◆ Complete message → ○ SI Mail Composition window opens automatically depending on character count.
Copying text	● Tools ● Doc./Rec. Barcode/ Scan ● Scan Card ● Frame card in center of Display ● ● © Copy ● Select first character ● ● Highlight text range ● ●

Scan Text

Scanning and	In a text entry window, (a) → Scan → (b) →
pasting during text	Scan Text → ● → Frame text in center of
entry	Display ⇒ ● Select line ⇒ ● ●
Scanning more text	Tools Doc./Rec. Barcode/
	Scan → ● Scan Text → ● Frame text in
	center of Display → ● Select line → ●
	● ⇒ © → Continue Part or Scan More → ●
	Select Continue Part to enter additional text or
	Scan More to enter text after a line break.
	→ Tools →
Saving scan results	Scan → ● → Scan Text → ● → Frame text in
	center of Display
	● → □ Save → ●
	9 9
	Tools O Doc./Rec. Barcode/
	Scan → ● → Scan Text → ● → Frame text in
Saving linked info	center of Display → ● Select line → ●
to Phone Book	Select number or mail address
	Save to Ph.Book → ● → As New Entry → ●
	Complete other fields ⇒ (y)
	To add to an existing entry, select As New Detail.
	Tools O Doc./Rec. Barcode/
	Scan → ● Scanned Results → ● → Select
Opening saved	file D
scan results	Select a file and press to rename files, open
	properties or delete files.
	Some files may not open.

Using linked info	Start Here ● → Tools → ● → Doc./Rec. → Barcode/Scan → ● → Scan Text → ● → Frame text in center of Display → ● → Select line → ● → ● → See below Dialing Numbers Select phone number → ● → ♣
	Sending Messages Select mail address
	Accessing Internet Sites Select URL
Pasting to message text	Start Here
	All Text
	Selected Text ③ → Select first character → ● → Highlight text range → ● → SI Mail or SMS → ● → Complete message → ○ • S! Mail Composition window opens automatically depending on character count.

Copying text	Start Here ● → Tools → ● → Doc./Rec. → Barcode/Scan → ● → Scan Text → ● → Frame text in center of Display → ● → Select line → ● → ● → See below
	Text (a) ⇒ Copy ⇒ ● ⇒ Select first character ⇒ ● ⇒ Highlight text range ⇒ ●
	Number, Address or URL Select number, mail address or URL © Copy Telephone, Copy Address or Copy URL © ©
Kanji Grabber	

Scanning and pasting during text

entry

In a text entry window, ⊚ → Scan → ● →

Kanji Grabber → ● → Frame kanji in Loupe →

● Scan results appear → ●



Osaifu-Keitai®



Cannot use Osaifu-Keitai® (S! FeliCa)

• Battery may be low. Charge battery or install a charged battery.



Recognition via reader/writer takes time

• Check logo area. Foreign articles can block/hamper recognition.



Call Remote Lock does not activate even after specified number of Missed Calls

- . Missed Call count is reset by calls from other numbers. If series is interrupted, start over from the beginning.
- When Call Forwarding is active, Missed Calls may not be recorded.

Wakeup TV



TV does not activate with specified channel

• If Wakeup TV Time arrives while TV is active, channel does not switch to the specified one.

Voice Recorder



Cannot record properly

• If incompatible microphone is connected, recording may fail.



Noise/skipping occurs

 Avoid shocks to handset while recording; may cause noise or skipping.



Recording takes time to start

• Recording window may take longer to open as more Voice files are saved on Memory Card.

Scanning Barcode/Card/Text



Cannot read barcodes properly

- · Scan may fail if barcode is dirty or unclear.
- · Scan may fail if barcode is scanned under inadequate light.
- · Scan may fail if multiple barcodes are captured at one time.



Cannot read barcodes during text entry

· Scanning is not available during calls or when mobile camera is active.



Cannot read split QR Codes in **Data Folder automatically**

· When scan fails, follow onscreen instructions and select next barcode image manually.



Cannot scan business cards properly

- · Scan fails if business card is printed in light-colored text on a dark background. handwritten or printed in casual/ decorative fonts, decorated with a background pattern, or designed with both vertical and horizontal text.
- · Scan may fail if business card is printed in light-colored text on a light background, printed in italics or extremely small fonts, decorated with a logo or logo-like text, printed on a glossy paper or other material, or dirty/folded.



Cannot scan text properly

- Scanning over 35 characters at one time may yield poor results.
- Adjust to frame text in []. Letters at the ends may be distorted.

